

**Quality of Workmanship
Innovative Design
Built to Last!**

Salsco, INC.
LEADER BY DESIGN



**MADE IN
THE U.S.A.**

Operators and Parts Manual 20" Shaving Mill



MANUFACTURER OF OUTDOOR POWER EQUIPMENT

Products for Turf & Lawncare, Rental, Construction, Tree Care, Wood Processing, Nursery & Farm Industries

3-1/2" - 18" Capacity, Gas, Diesel, & PTO Wood/Brush Chippers - Slab Chippers
Gas, Electric & Tow Behind Rollers - Tranz-Former Roller - CRV Core Recovery Vehicle
Mini-Paver - Mini-Track Paver - Cobra Curbers - Scorpion Router - Concrete Paver
Chipper Shredder Vacuums - Tailgate & Truckloader Vacuums
9 cu. yds. - 50 cu. yds. Per Hour, Electric, PTO & Diesel Powered Shaving Mills

Salsco, INC.
LEADER BY DESIGN

105 Schoolhouse Road
Cheshire, CT 06410 U.S.A.
800-872-5726 (Toll Free), 203-271-1682, 203-271-2596 (Fax)
www.salsco.com, sales@salsco.com

TABLE OF CONTENTS

20" SHAVING MILL

COVER & TABLE OF CONTENTS.....	Pages 1 – 2
STATEMENT OF FACT	Page 3
MACHINE REGISTRATION	Page 4
MAINTENANCE SCHEDULE.....	Page 5
CUTTER SHAFT BLADE INSTALLATION	Page 6
MAINTENANCE/SERVICE.....	Pages 7- 9
DODGE BEARING LUBRICATION INSTRUCTIONS.....	Pages 10 - 11
PARTS DIAGRAMS	Pages 12 - 24
TORQUE CHARTS	Page 25
WARRANTY POLICY & PROCEDURE	Page 26
COPY OF WARRANTY CLAIM FORM.....	Pages 27 - 28
COPY OF DEALER DELIVERY REPORT & WARRANTY CARD.....	Page 29
SERVICE SCHEDULE LOG	Page 30

SALSCO, INC.

105 Schoolhouse Road
Cheshire, CT 06410 USA
800-872-5726, 203-271-1682
203-271-2596 (Fax)
www.salsco.com, sales@salsco.com

STATEMENT OF FACT

You have just purchased the highest quality, most dependable, Shaving Mill on the market today. This unit has the ability to meet exact standards and perform for years with minimum downtime. **HOWEVER**, it cannot read nor will it understand this manual no matter how long you leave it on top of the machine.

It is your responsibility to read and understand this manual; it is also your responsibility to be certain this information is passed along to anyone who is expected to operate this equipment. Should you choose not to read, understand and pass along the information provided you, please expect equipment failure and possible injuries to persons around this equipment.

For the safety of the operator, it is imperative that this manual is carefully read and understood.

Once you have read this manual, it is your responsibility to be sure that all new operators read and understand this manual, especially all cautions stated.

As a manufacturer of equipment, we have a responsibility to design a safe piece of equipment. **NOTE:** The important safeguards and instructions in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors, which cannot be built into any product. These factors must be supplied by the person(s) caring for and operating this equipment.

ONLY YOU CAN PREVENT ACCIDENTS!

MACHINE REGISTRATION

MANUFACTURED BY:

SALSCO, INC.
105 Schoolhouse Rd., Cheshire, CT 06410
800-872-5726, 203-271-1682, 203-271-2596 (Fax)
sales@salsco.com www.salsco.com

THIS MANUAL COVERS MODEL(s): _____, _____

This company reserves the right to discontinue, add improvements to, or change the design of any model or product at any time without obligation to improve existing machines, either by changing the design or adding new parts.

It has been and will continue to be the policy of SALSCO to update existing machines at its own discretion. Whenever possible, new designs will be made in such a way that they can be "Retro Fit" if so desired.

Record in the space provided below the model and serial number of this unit. Please retain these numbers for future reference.

NO PARTS ORDERS will be accepted **WITHOUT A SERIAL NUMBER, MODEL NUMBER AND PART NUMBERS**. All part numbers are listed in this manual.

Serial Number

Model Number

NOTE: Be sure to complete your warranty card. This will ensure immediate processing of any warranty claims.

READ AND UNDERSTAND THIS MANUAL BEFORE STARTING THE MACHINE

Maintenance Schedule for Salsco Shaving Mills

Electric and Diesel 20" thru 60"

General Notes: This maintenance schedule is to be used in conjunction with your operators/service manual.

Daily service: Every 8 hours of operation

- Grease all Bearings (including but not limited to the following)
 - o Cutter head bearings
 - o Belt drive system
 - o Chain drive system
 - o Wood box wheels
 - o Wood box switcher grease points
 - o Clutch grease points (if equipped with diesel engine and clutch set up)


Note: While using remote greasing system be sure to check the operation of system if there is any change in required pressure when pumping grease.

- Engine oil level
- Hydraulic fluid level
- Any and all daily service recommended by engine manufacturer

Weekly service: Every 40 hours of operation

- Check and adjust all belt tensions
- Check and adjust all chain tensions
- Check cutter head blades. Change the blades if they are dull.

CUTTER SHAFT BLADE INSTALLATION



MAINTENANCE/SERVICE

- 1) Daily greasing is required, and remote grease fittings are located in various spots on the unit. These locations are marked with decals and care should be taken to ensure none of the grease points are missed.
- 2) Chain tension.
 - a. 20" mill
 - i. Under the engine on this unit, you will see an idler sprocket for the main box chain. The only regular maintenance to this assembly should be greasing and inspection. If you ever change the main chain or have a bearing failure on this shaft be sure the sprocket is set so the main chain is not touching the deck.
 - ii. At the rear of the unit, you will find the drive set up which moves the box. This is also where you tension the main drive chain if needed.
 1. Remove the top section of the orange guard exposing the drive system.
 2. Loosen the jam nut and pusher bolt against the drive motor.
 3. Loosen the drive motor pivot bracket putting slack in the chain between the drive motor and the jackshaft #13.
 4. On jackshaft #13 loosen the jam nuts and pusher bolts on the front side of the bearings. Don't touch the rear pusher bolts yet. Loosen the bearing mounting bolt enough so you slide the jackshaft. Now loosen the rear jam nuts and use the rear pusher bolts to slide the jackshaft assembly in turn tensioning the chain from the rear jackshaft to the front jackshaft. Once this chain is tight lock down the rear jam nuts, and then lock down the bearing bolts; now bring the front pusher bolts against the bearings and lock down the jam nuts.
 5. Now, tension the chain from the front jackshaft to the drive motor by reversing steps 3 & 2.
 6. As with the front of the unit the height of the sprocket assembly carrying the main chain should not be changed from the original factory setting.
 7. Tensioning the main drive chain, which moves the box, is done at the rear drive assembly. Once you have tensioned all of the chains in this drive assembly and locked them down in the fashion indicated in this procedure you are ready to tension the main drive chain. The rear drive assembly is mounted on an orange frame, which slides on the main frame for the unit as indicated by # 5 in

MAINTENANCE/SERVICE (Continued)

diagram #11. If you loosen the four bolts which hold the orange mounting frame #5 to the unit's mainframe, this will allow the mounting frame to slide. Loosen the jam nut on the pusher/puller bolt (# 11 diagram #11) and turn the pusher bolt to slide the rear drive assembly to tension the main drive chain. As long as the chain doesn't touch the deck you are fine. Lock down the jam nut on the pusher/puller bolt, the bolts holding down the rear drive assembly and replace the guards and you will be ready to go.

- A. Belt tension, there are two belt systems which are typical to both the 20" & 30" Shaving Mills.
- a. Cutter head to engine belt system, diagram 7.
 - i. First remove the guards. This will make it much easier to tension these belts properly. Start at the cutter shaft and work towards the engine.
 - ii. **(Note: Use the following procedure for each of the jackshaft assemblies.)** Loosen the jam nuts and pusher bolts on the engine side; loosen the bearing mounting bolts so the jackshaft assembly can slide. Now, use the pusher bolts on the cutter shaft side to slide the jackshaft to tension the belt using the 3/8 rule. Lock down the cutter shaft side jam nuts and pusher bolts, bearing bolts and engine side pusher bolts and jam nuts.
 - iii. Now that you have tensioned all of the belts from the cutter shaft up towards the engine, tension the last belt that runs from the last jack shaft to the engine by sliding the engine. Loosen the engine mounting bolts, the jam nuts and the pull/push bolts on the front of the engine mounting area to slide the engine and tension the belt. Be sure to use the 3/8 rule when tensioning this belt.

Note: While these guards are off check the tension of the blower drive system.

- iv. **IT IS IMPERATIVE THAT YOU REPLACE AND SECURE ALL GUARDS PRIOR TO OPERATION OF THIS UNIT. RUNNING THIS UNIT WITHOUT GUARDS IN PLACE CAN CAUSE SERIOUS INJURY OR DEATH.**
- b. Blower assembly belt tensioning, diagram 7.
 - i. First you need to remove the guards. This will make it possible to tension the belts properly.
 - ii. On the back of the actual blower, loosen the bolts holding it to the drop out trough. Loosen the pusher bolt on the top right corner of the blower. This will allow you to relieve the tension on the belt running from the blower to the jackshaft.

MAINTENANCE/SERVICE (Continued)

- iii. Now to tension the belts from the cutter shaft to the jackshaft use the same procedure in step C.a.ii.
 - iv. Now that the belt is tight from the cutter head to the jackshaft reverse the procedure on loosening the blower housing to tension the belt from the jackshaft to the blower.
 - v. Once the belts are tight, using the 3/8 rule, and all the bolts are retightened, you are ready to replace the guards.
 - vi. **IT IS IMPERATIVE THAT YOU REPLACE AND SECURE ALL GUARDS PRIOR TO OPERATION OF THIS UNIT. RUNNING THIS UNIT WITHOUT GUARDS IN PLACE CAN CAUSE SERIOUS INJURY OR DEATH.**
- B. Wood Box Travel Adjustment Diagram #12
- a. By moving plates # 1 & 9 you can adjust how far the box travels relative to the cutter head.
NOTE: USE CAUTION WITH THIS ADJUSTMENT. TEST YOUR ADJUSTMENT WITH THE CUTTERHEAD DISENGAGED TO BE SURE THE BOX IS NOT TRAVELING OVER THE CUTTERHEAD. EXTENSIVE DAMAGE WILL BE CAUSED IF THE BOX TRAVELS INTO THE CUTTERHEAD !!!!
- C. Crossover Relief Valve
- a. The relief valve shown as #14 on diagram #14 has two screws for adjustment on the top and bottom of the valve. Each complete turn of the screw represents 150 psi of hydraulic pressure. Factory settings are set at 4 turns or 600 psi for both the top and bottom screw. This setting should not be changed without contacting a Salsco service representative.
- D. Blade Maintenance
- a. The blades on this unit must be inspected weekly and serviced accordingly.
 - b. Removing the blades (be sure to count the # of exposed grooves on the back of the blades)
 - i. First either run the box over the cutter head or work inside of the box.
 - ii. Clean out the allen head screws.
 - iii. Loosen one set of screws a few turns and tap the keepers for that blade down. Be sure to use a piece of brass or soft material that will not damage the keepers. By loosening the screws and tapping down the keepers you will loosen the blade. Remove and replace all the blades in this pocket. Be sure to set them to factory specs of 1/8 inch above the deck.

PAY SPECIAL ATTENTION TO “TABLE 5 - SUGGESTED LUBRICATION INTERVALS IN WEEKS” ON PAGE 2

INSTRUCTION MANUAL DODGE® GRIP-TIGHT ADAPTER MOUNT BALL BEARINGS

⚠ WARNING


To ensure that drive is not unexpectedly started, turn off, lock out, and tag power source before proceeding. Failure to observe these precautions could result in bodily injury.

Shaft & Mounting Surface Inspection

Shaft should be smooth, straight, & within commercial tolerances (Table 1). Remove burrs & align mounting surfaces within 2 degrees.

Assemble Adapter & Bearing

1) If the locknut is loose from the bearing, FIRST place locknut into bearing inner ring groove, THEN insert adapter into bearing bore until it rests against the locknut. Rotate locknut clockwise to engage adapter sleeve.



Pillow Blocks & Tapped Base Housings

NOTE: For Tapped Base (TB) housings drill mounting holes with 1/16" minimum bolt clearance to assist with proper installation.

2) During installation it is best practice is to remove all of the weight from the bearing via slings or jacks. However, if it is difficult to remove all weight then insure the dead weight on the bearing during installation does not exceed the values listed in Table 2.

Series	Maximum Dead Load Per Bearing (lbs)
203-206	60
207-210	65
211-214	70
215-218	75

3) Slide the unit into position onto the shaft. If the unit will not slip onto the shaft, turn locknut counter-clockwise to expand adapter sleeve.

4) Wearing gloves, rotate locknut clockwise, by hand, as tight as possible until adapter sleeve grips and does not spin on the shaft or move axially. If needed, tap on locknut outer diameter while turning locknut to assist with this step. Scribe the line on the locknut above the adapter sleeve slot.

5) Lock bearing to shaft by rotating locknut, with a spanner wrench or brass bar & hammer, clockwise by amount shown in Table 3. NOTE: The use of air chisels is not recommended.


6) Center housing & mounting bolts over mounting holes & tighten bolts to proper torque (Table 4). Tighten locknut setscrew until 3/32" Allen key bends (25 in-lbs).

7) Repeat above steps for mounting 2nd housing. Do not tighten mounting bolts on 2nd housing until second bearing has been completely locked to the shaft. Bolts must fit freely between housing & mounting surface. If the mounting bolts do not fit freely, loosen mounting bolts on both housings & center both units. If the bolts still will not fit freely, remove one unit from the shaft, reposition housing, & reinstall.

Shaft Size (in)	Commercial Shaft Tolerances (in)
Up to 1 1/2"	+0.000" / - 0.002"
1 5/8" - 2 1/2"	+0.000" / - 0.003"
2 11/16" - 3 7/16"	+0.000" / - 0.004"

Series	Shaft Size GT (Normal Duty)	Shaft Size GTM (Medium Duty)	Locknut Rotation
203 - 204	1/2" - 3/4" 17 - 20 mm	---	1/2 Turn
205 - 210	7/8" - 1 3/4" 25 - 45 mm	3/4" - 1 1/2" 20 - 40 mm	2/3 Turn
211 - 218	1 15/16" - 2 15/16" 50 - 75 mm	1 11/16" - 3 1/2" 45 - 85 mm	1 Turn

Metal Housings		Non-Metallic Polymer Housing			
All Housing Types		Pillow Block, 2 & 4 Bolt Flange, Flange Bracket		Tapped Base	
Bolt Size (in)	Dry Torque (in lbs)	Bolt Size (in)	Dry Torque (18-8 Stainless) (in lbs)	Bolt Size (in)	Dry Torque (18-8 Stainless) (in lbs)
3/8	240	3/8	225	3/8	175
7/16	384	7/16	350	7/16	350
1/2	600	1/2	500	1/2	400
5/8	1200	9/16	650		
3/4	2100	5/8	1000		
7/8	2040				



⚠ WARNING

Because of the possible danger to person(s) or property from accidents which may result from the improper use of products, it is important that the correct procedure be followed. Products must be used in accordance with the engineering information specified in the catalog. Proper installation, maintenance, and operating procedures must be observed. The instructions in the instruction manuals must be followed. Inspections should be made as necessary to ensure safe operation under prevailing conditions. Proper guards and other suitable safety devices or procedures as may be desirable or as may be specified in safety codes should be provided, and are neither provided by Baldor Electric Company nor are the responsibility of Baldor Electric Company. This unit and its associated equipment must be installed, adjusted, and maintained by qualified personnel who are familiar with the construction and operation of all equipment in the system and potential hazards involved. When risk to persons or property may be involved, a holding device or shear bars must be an integral part of the driven equipment.

All Flange Housings

WARNING: Special attention to the installation procedure for flange bearings is necessary to maintain the proper internal clearance & achieve maximum life. The installation of the first flange differs from the installation of the second flange.

(See step 1 Assemble Adapter & Bearing page 1)

2) During installation it is best practice is to remove all of the weight from the bearing via slings or jacks. However, if it is difficult to remove all weight then insure the dead weight on the bearing during installation does not exceed the values listed in Table 2.

3) Slide the FIRST unit into position onto the shaft. If the bearing will not slip onto the shaft or more axially, turn locknut counter clockwise to expand adapter sleeve.

4) (Using gloves) rotate locknut clockwise by hand until it is tight & adapter sleeve grips & does not spin on the shaft. This is the starting point. Scribe a line on the locknut above the adapter sleeve slot.

(If needed, tap on locknut outer diameter while turning locknut to assist with this step.)

5) Lock bearing to shaft by rotating locknut, with a spanner wrench or brass bar & hammer, clockwise by amount shown in Table 2.

NOTE: The use of air chisels is not recommended.

6) Tighten locknut setscrew until 3/32" Allen key bends (or 25 in-lbs). Tighten housing bolts to proper torque (Table 3).


7) Slide the **SECOND** flange onto the shaft and hand tighten as in step 4 but leave 1/16" minimum gap between the flange housing & the mounting surface. See picture to the right.

8) It is important to note that the 1/16" minimum gap between the flange housing and the mounting surface must be maintained while getting the bearing hand tight to the shaft. Wearing gloves, rotate the locknut clockwise, by hand, until adapter sleeve grips and does not spin or move axially on the shaft. If needed, tap on the locknut outer diameter while turning the locknut to assist with this step. At this point you should have difficulty in rotating the locknut by hand and you should not be able to move the bearing axially along the shaft by hand. If the bearing can be moved axially along the shaft by hand then continue rotating the nut gradually until it grips the shaft. Scribe a line on the locknut above the adapter sleeve slot.

9) Insert housing bolts & pull the housing flush with mounting surface by alternately tightening the bolts to the proper torque (Table 4).

10) Lock bearing to shaft by rotating locknut, with a spanner wrench or drift pin & hammer, clockwise by amount shown in Table 3. Tighten locknut setscrew until 3/32" Allen key bends (25 in-lbs).

11) Rotate the shaft by hand, no binding or excessive drag should be felt. If excessive drag is felt, loosen the second bearing & reinstall starting at step 8.



Dismounting All Units

1) Remove all weight from the bearing via slings or jacks & secure the shaft from rotation.

2) **LOOSEN THE HOUSING MOUNTING BOLTS & COMPLETELY REMOVE SETSCREW IN THE LOCKNUT.**

3) Rotate locknut counter clockwise with spanner wrench or drift pin & hammer until bearing is free.

*

LUBRICATION: (Use compatible Mobil SHC 220 PM Grease) The Dodge Grip-Tight Bearing has been greased from the factory and is shaft ready. When re-lubricating slowly add grease until fresh grease is seen purging past the seal. In the higher speed ranges excess grease may cause temporary bearing overheating. The amount of grease a bearing will take for a specific high-speed application is best determined by experience. When establishing a re-lubrication schedule, note that a small amount of grease at frequent intervals is preferred to a large amount of grease at infrequent intervals. Lubrication recommendation: Grease every 10 hours. For modified products, high temperature applications, and other anomalous applications contact product engineering at 864-284-5700.

* **SUPERSEDES ALL OTHER LUBRICATION INSTRUCTIONS - 8/13/2010**

www.baldor.com www.ptplace.com www.dodge-pt.com www.reliance.com

BALDOR
BALDOR • DODGE • RELIANCE

Baldor Electric Company Headquarters

P.O. Box 2400, Fort Smith, AR 72902-2400 U.S.A., Ph: (1) 479.648.5792, Fax (1) 479.648.5792, International Fax (1) 479.648.5895

Baldor - DODGE/Reliance


6040 Ponders Court, Greenville, SC 29615-4617 U.S.A., Ph: (1) 864.297.4800, FAX: (1) 864.281.2433

5.07 Copyright © 2007 Baldor Electric Company All Rights Reserved. Printed in USA.

This material is not intended to provide operational instructions. Appropriate instruction manuals and price should be studied prior to installation, operation or maintenance of equipment.




1M499312




20" SHAVING MILL
 EV 10-23-02 SHT 1 OF 13


DRAWING # 2




20" SHAVING MILL 0014002
REV. 08-03-10 SHEET 2 OF 14




20" SHAVING MILL
 EV 10-23-02 SHT 3 OF 3







20" SHAVING MILL
 EV 10-23-02 SHT 5 OF 13





NOTE: ITEM # 11 – PAY SPECIAL ATTENTION TO THE LUBRICATION INSTRUCTIONS ON PAGES 10 – 11 OF THIS MANUAL.




20" SHAVING MILL - 0014002
REV. 08-03-10 SHEET 7 OF 14








20" SHAVING MILL
 FY 10-23-02 SHT 10 OF 13




20" SHAVING MILL
EV 10-23-02 SHT II OF 13

Below is a quick reference chart for various “Flat Head Cap Screws” and the torque recommendations.



BOLT SIZE	Thds Per Inch	SAE Grade 5	SAE Grade 8
1/4	20	10	14
	28	---	---
5/16	18	19	29
	24	---	---
3/8	16	33	47
	24	---	---
7/16	14	54	78
	20	---	---
1/2	13	78	119
	20	---	---
9/16	12	114	169
	18	---	---
5/8	11	154	230
	11	---	---
3/4	10	257	380
	10	---	---
7/8	9	382	600
	9	---	---
1	8	587	700
	8	---	---

Drive Belt Tension Measurement by Deflection



Deflection should be 3/8" when
8-12 lbs. push is applied at "B"

WARRANTY POLICY

Please remember to complete and return your Warranty Card and Dealer Delivery Report. Warranty Claims will not be considered if the Warranty Card and Dealer Delivery Report have not been returned to Salsco.

Your Salsco Commercial or Turf Equipment product is a commercial type product and is normally manufactured and sold for commercial or industrial use. **Salsco will, for the original purchaser, for (5) years from the date of purchase (90 days if used for rental purposes) repair or replace, free of charge, any part or parts found to be defective in material, workmanship or both.** Any transportation or shipping charges will be borne by the purchaser. If, during the warranty period stated above, the product does not function properly due to defect, simply contact Salsco and follow the Warranty Procedures included in this manual.

This warranty **does not** include:

- Incidental or consequential damages and is exclusive of any implied warranties.
- Normal maintenance parts, including, but not limited to hoses, chains, belts, filters, lubricants, etc.
- Parts or components, which are covered under the original manufacturer warranty, including, but not limited to engines, pumps, and motors.

WARRANTY PROCEDURE

In order for Salsco to consider your warranty claims in a timely manner you must follow the simple procedures listed below:

MACHINE OR PART FAILURE

- Call our service department for helpful instruction on how to correct or repair the problem. Preventive maintenance will also be suggested.
- When ordering parts for Warranty issues, you **MUST** retain possession of the old parts in question until notified with respect to returning the parts to Salsco or other disposition.
- Warranty Claims **MUST** be filed within 30-days from completion of the work performed. Contact our office for an electronic warranty claim form.
- Fill in all information requested on warranty claim form, a copy of which is included in this manual, (date of purchase, company name, address, etc.). List all parts used. Make sure part numbers are correct. You can obtain these from your manual. (include good description of problem; i.e. "leaking from spool" rather than "leaking").
- It is our goal to consider and reach a disposition on each Warranty Claim within 30-days from the date that it is received. Therefore it is important that you respond promptly to any request for further information. Claims with no response to inquiries will be closed as **"denied for lack of response"** 90-days from the date of request.
- Email, Fax or Send Warranty Claim form to our Warranty Department. – **Warranty on parts most often requires return of the parts that were replaced.** DO NOT DISCARD OLD PARTS UNTIL YOU HAVE RECEIVED A DETERMINATION AS TO WHETHER THESE PARTS MUST BE RETURNED.
- Our Warranty Department will contact and instruct you on how to return the Parts to Salsco on an RA #. Returns **MUST** be made within 30-Days from issuance of RA #. **FREIGHT CHARGES ON RETURN OF PARTS IS THE RESPONSIBILITY OF THE CUSTOMER.** Normal pre-delivery adjustments are not covered under warranty. Labor Warranties are based on reasonable time allowances as determined by Salsco, Inc. and paid at 75% of posted labor rate. **TRAVEL TIME IS NOT REIMBURSED UNDER THE WARRANTY POLICY.**
- Be sure to put the RA form inside the box that you are shipping back, also be sure to put on the outside of the box "Return of Goods" and the RA #.
- Ship returns via a traceable method such as UPS Ground Service. Be sure that the shipment is insured for the appropriate value. If uninsured parts are lost, we cannot issue a credit.

PLEASE NOTE: *Warranty forms should be filled out completely.*

PREVENTIVE MAINTENANCE IS YOUR BEST INSURANCE AGAINST EQUIPMENT FAILURE. BE SURE TO READ THIS MANUAL, ESPECIALLY THE MAINTENANCE, OPERATING AND CAUTION SECTIONS.

**SALSCO, INC., 105 Schoolhouse Rd.
Cheshire, CT 06410**

TOLL FREE: 800-872-5726, 203-271-1682, FAX: 203-271-2596. EMAIL: sales@salsco.com, www.salsco.com

SALSCO WARRANTY CLAIM FORM

SALSCO, INC. 105 SCHOOLHOUSE RD. CHESHIRE, CT 06410		PHONE: 203-271-1682, 800-872-5726 FAX: 203-271-2596 EMAIL: f.carrington@salsco.com WEB: www.salsco.com	
END OWNER		PHONE:	
NAME:		FAX:	
EMAIL:			
ADDRESS:			
PURCHASED FROM:		PHONE:	
NAME:		FAX:	
EMAIL:			
ADDRESS:			
EQUIP/WARRANTY INFO: (MUST BE COMPLETE)			
PURCHASE DATE:		INV #:	DATE FAILED:
MODEL #:	SERIAL #		REPAIR DATE:
HRS USED:			
WARRANTY CLAIM/WORK ORDER #			
WAS A SALSCO RETURN AUTH. # ISSUED FOR REPAIRS OR RETURN OF PARTS: YES NO			
IF YES, RA #:			
PROBABLE CAUSE OF FAILURE:			

SALSCO WARRANTY CLAIM FORM – Continued

WORK PERFORMED/COMMENTS ON REPAIR:				
SHOP LABOR RATE:		SUBMITTED BY:		
TOTAL LABOR HRS TO REPAIR:		PRINTED NAME:		
SALSCO PART #:	DESCRIPTION:	QTY	PRICE EACH	TOTAL
<p>FILL IN ALL INFORMATION REQUESTED ON WARRANTY CLAIM FORM. INCOMPLETE FORMS CANNOT BE PROCESSED & WILL BE RETURNED. LIST ALL PARTS USED. MAKE SURE PART NUMBERS ARE CORRECT. ANY PARTS THAT YOU BELIEVE TO BE DEFECTIVE OR ANY PARTS THAT BREAK SHOULD BE RETAINED FOR POSSIBLE INSPECTION UNTIL AFTER THE WARRANTY HAS BEEN PAID OR PART HAS BEEN RETURNED. INV. # NEEDS TO BE INCLUDED ON WARRANTY CLAIM.</p>				
OFFICE USE ONLY				
DATE REC'D:		DLR. DEL REPORT ON FILE: YES NO		
CUST ID:		WARRANTY CLAIM ON FILE: YES NO		
SALSCO WC:		PARTS TOTAL:		
SALSCO RA:		LABOR TOTAL:		
DATE APPROVED:		TOTAL APPROVED:		
DATE REJECTED:		REJECTED DATE:		
PROCESSED BY:		REASON:		

SERIAL # _____	MODEL NO. _____
SALSCO LIMITED WARRANTY CARD	
1. DATE PURCHASED: _____	
2. PURCHASER: _____	
3. PURCHASER ADDRESS: _____ _____	
4. EMAIL ADDRESS: _____	
5. DEALER: _____	
6. DEALER ADDRESS: _____	
7. WILL THIS EQUIPMENT BE USED COMMERCIALY? <input type="checkbox"/> YES <input type="checkbox"/> NO	
8. DID DEALER SERVICE THIS EQUIPMENT AND INSTRUCT YOU IN ITS CARE AND SAFE OPERATION ? <input type="checkbox"/> YES <input type="checkbox"/> NO	
9. DID YOU RECEIVE AN "OPERATION & SERVICE MANUAL" AND SAFETY PAMPHLET? <input type="checkbox"/> YES <input type="checkbox"/> NO	
NOTICE	SIGNED _____ Purchaser
IMPORTANT: THIS CARD MUST BE FILLED OUT COMPLETELY AND MAILED TO THE FACTORY WITHIN 10 DAYS OF PURCHASE DATE, OR YOUR LIMITED WARRANTY WILL BE VOIDED.	
WHITE - DEALER	YELLOW - OWNER
CARD - FACTORY	

SALESMAN ID # _____

SALES MANAGER'S NAME _____

Salsco, Inc.		105 School House Rd. Cheshire, CT 06410 203-271-1682		sales@salsco.com www.salsco.com
800-872-5726 203-271-2596 (Fax)				
DEALER DELIVERY REPORT				
MODEL _____		SERIAL NO _____		
DEALER _____		CITY _____	STATE _____	ZIP _____
PURCHASER (Last Name or Company)	(First Name)	(Middle Name)	ADDRESS _____	CITY _____
			STATE _____	ZIP _____
<p>The undersigned dealer warrants that the above-described machine was carefully inspected, adjusted and prepared for delivery before delivery to the purchaser; that both the operation and maintenance of the machine were explained to the purchaser; and that a copy of the Owner's Instruction Manual were given to the purchaser and his attention called to Our Warranty and any operating instructions included in the manual and caution notes.</p>			<p>The undersigned purchaser certifies that the operation and maintenance of the above-described machine have been explained to him; acknowledges receipt of a copy of the Owners's Instruction Manual and Our Warranty Policy printed in said Instruction Manual and Caution Notes. I also understand that it is my responsibility to explain and make Salsco manuals available to new operators.</p>	
Date _____ Sign By _____ Phone _____			Date _____ Purchaser _____ Sign By _____ Phone _____ Email _____	

FACTORY COPY WHITE - DEALER'S COPY YELLOW - OWNER'S COPY PINK

SERVICE RECORD

If kept properly, this schedule will help track problems in the future.

[illegible]

MODEL # _____ S/N _____

DATE PURCHASED: _____