

# **ACCU-Pro 632 SPIN/RELIEF GRINDER**

## **ASSEMBLY and SERVICE MANUAL**



### **WARNING**

**You must thoroughly read and understand this manual before operating the equipment, paying particular attention to the Warning & Safety instructions.**

# SAFETY INSTRUCTIONS



**Safety Awareness Symbols** are inserted into this manual to alert you to possible **Safety Hazards**. Whenever you see these symbols, follow their instructions.



The **Warning Symbol** identifies special instructions or procedures which, if not correctly followed, could result in personal injury.

The **Caution Symbol** identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

1. **KEEP GUARDS IN PLACE** and in working order.
2. **REMOVE WRENCHES AND OTHER TOOLS.**
3. **KEEP WORK AREA CLEAN.**
4. **DON'T USE IN DANGEROUS ENVIRONMENT.** Don't use Grinder in damp or wet locations. Machine is for indoor use only. Keep work area well lit.
5. **KEEP ALL VISITORS AWAY.** All visitors should be kept a safe distance from work area.
6. **MAKE WORK AREA CHILD-PROOF** with padlocks or master switches.
7. **DON'T FORCE THE GRINDER.** It will do the job better and safer if used as specified in this manual.
8. **USE THE RIGHT TOOL.** Don't force the Grinder or an attachment to do a job for which it was not designed.
9. **WEAR PROPER APPAREL.** Wear no loose clothing, gloves, neckties, or jewelry which may get caught in moving parts. Nonslip foot wear is recommended. Wear protective hair covering to contain long hair.
10. **ALWAYS USE SAFETY GLASSES.**
11. **SECURE YOUR WORK.** Make certain that the cutting unit is securely fastened with the clamps provided before operating.
12. **DON'T OVERREACH.** Keep proper footing and balance at all times.
13. **MAINTAIN GRINDER WITH CARE.** Follow instructions in Service Manual for lubrication and preventive maintenance.
14. **DISCONNECT POWER BEFORE SERVICING,** or when changing the grinding wheel.
15. **REDUCE THE RISK OF UNINTENTIONAL STARTING.** Make sure the switch is OFF before plugging in the Grinder.
16. **USE RECOMMENDED ACCESSORIES.** Consult the manual for recommended accessories. Using improper accessories may cause risk of personal injury.
17. **CHECK DAMAGED PARTS.** A guard or other part that is damaged or will not perform its intended function should be properly repaired or replaced.
18. **KNOW YOUR EQUIPMENT.** Read this manual carefully. Learn its application and limitations as well as specific potential hazards.
19. **KEEP ALL SAFETY DECALS CLEAN AND LEGIBLE.** If safety decals become damaged or illegible for any reason, replace immediately. Refer to replacement parts illustration in Service Manual for the proper location and part numbers of safety decals.
20. **DO NOT OPERATE THE GRINDER WHEN UNDER THE INFLUENCE OF DRUGS, ALCOHOL OR MEDICATION.**

# SAFETY INSTRUCTIONS



## IMPROPER USE OF GRINDING WHEEL MAY CAUSE BREAKAGE AND SERIOUS INJURY

Grinding is a safe operation if the few basic rules listed below are followed. These rules are based on material contained in the ANSI B7.1 Safety Code for "Use, Care and Protection of Abrasive Wheels". For your safety, we suggest you benefit from the experience of others and carefully follow these rules.

### DO

1. **DO** always **HANDLE AND STORE** wheels in a **CAREFUL** manner.
2. **DO VISUALLY INSPECT** all wheels before mounting for possible damage.
3. **DO CHECK MACHINE SPEED** against the established maximum safe operating speed.
4. **DO CHECK MOUNTING FLANGES** for equal and correct diameter.
5. **DO USE MOUNTING BLOTTERS** when supplied with wheels.
6. **DO** be sure **WORK REST** is properly adjusted.
7. **DO** always **USE A SAFETY GUARD COVERING** at least one-half of the grinding wheel.
8. **DO** allow **NEWLY MOUNTED WHEELS** to run at operating speed, with guard in place, for at least one minute before grinding.
9. **DO** always **WEAR SAFETY GLASSES** or some type of eye protection when grinding.

### DON'T

1. **DON'T** use a cracked wheel or one that has become damaged.
2. **DON'T FORCE** a wheel onto the machine **OR ALTER** the size of the mounting hole - if wheel won't fit the machine, get one that will.
3. **DON'T** ever **EXCEED MAXIMUM OPERATING SPEED** established for the wheel.
4. **DON'T** use mounting flanges on which the bearing surfaces **ARE NOT CLEAN, FLAT AND FREE OF BURRS**.
5. **DON'T TIGHTEN** the mounting nut excessively.
6. **DON'T** grind on the **SIDE OF THE WHEEL** (see Safety Code B7. 2 for exception).
7. **DON'T** start the machine until the **WHEEL GUARD IS IN PLACE**.
8. **DON'T JAM** work into the wheel.
9. **DON'T STAND DIRECTLY IN FRONT** of a grinding wheel whenever a grinder is started.
10. **DON'T FORCE GRINDING** so that motor slows noticeably or work gets hot.



AVOID INHALATION OF DUST generated by grinding and cutting operations. Exposure to dust may cause respiratory ailments. Use approved NIOSH or MSHA respirators, safety glasses or face shields, and protective clothing. Provide adequate ventilation to eliminate dust, or maintain dust level below the Threshold Limit Value for nuisance dust as classified by OSHA.

This machine is intended for grinding the reel of reel type mower units ONLY. Any use other than this may cause personal injury and void the warranty.



To assure the quality and safety of your machine and to maintain the warranty, you **MUST** use original equipment manufacturers replacement parts and have any repair work done by a qualified professional.

ALL operators of this equipment must be thoroughly trained **BEFORE** operating the equipment.

Do not use compressed air to clean grinding dust from the machine. This dust can cause personal injury as well as damage to the grinder. Machine is for indoor use only. Do not use a power washer to clean the machine.



### Low Voltage Relay

The grinder is equipped with a high-low voltage relay which is factory preset at 100-140 VAC. If the power supply line does not deliver 100-140 VAC power under load, the relay will open and trip out the starter. If this occurs, your power supply line is incorrect and must be correct before proceeding further with the grinder.

## CONTENTS

Safety Warnings .....	Page 2- 4
Service Data .....	Page 5
Assembly Instructions .....	Page 6 -10
Maintenance Instructions .....	Page 11 -15
Adjustments .....	Page 16 -23
Machine Service .....	Page 24 -26
Electrical Troubleshooting Index .....	Page 27-28
Electrical Troubleshooting .....	Page 29 -45
Mechanical Troubleshooting .....	Page 46 -47
Parts List .....	Page 48 -79
Electrical Diagrams .....	Page 80-82

## SPECIFICATIONS

Electrical Requirements .....	115V 50/60 Hz, 20 amp circuit
Net Weight .....	1490 lbs (676 kg)
Shipping Weight .....	1770 lbs (803 kg)
Maximum Grinding Length .....	34 inches (86cm)

# SERVICE DATA

## SKILL AND TRAINING REQUIRED FOR SERVICING

This Service Manual is designed for technicians who have the necessary mechanical and electrical knowledge and skills to reliably test and repair the ACCU-PRO Spin/Relief Grinder. For those without the background, service can be arranged through your local distributor.

This Manual presumes that you are already familiar with the normal operation of the Grinder. If not, you should read the Operators Manual, or do the servicing in conjunction with someone who is familiar with its operation.

Persons without the necessary knowledge and skills should not remove the control box cover or attempt any internal troubleshooting, adjustments, or parts replacement.

If you have questions not answered in this manual, please call your distributor. They will contact the manufacturer if necessary.

## TORQUE REQUIREMENTS

Throughout this manual we refer to torque requirements as "firmly tighten" or the like. For more specific torque values, refer to the information below.

### Bolts Going Into a Nut, or Into a Thread Hole in Steel.

Refer to the table at the right.

### Bolts Going Into a Thread Hole In Aluminum

Use the Grade 2 values in the table at the right.

### Socket-Head Screws Going Into a Nut or Steel




Use the Grade 8 values in the table at the right.

### Machine Screws

No. 6 screws: 11 in.- lbs (0.125kg - m)

No. 8 screws: 20 in. - lbs (0.23 kg - m)

No. 10 screws: 32 in. - lbs (0.37 kg - m)

	GRADE 2  SMOOTH HEAD	GRADE 5  3 MARKS on HEAD	GRADE 8  6 MARKS on HEAD
1/4 In. thread	6 ft-lbs (0.8 kg-m)	9 ft-lbs (1.25 kg-m)	13 ft-lbs (1.8 kg-m)
5/16 In. thread	11 ft-lbs (1.5 kg-m)	18 ft-lbs (2.5 kg-m)	28 ft-lbs (3.9 kg-m)
3/8 In. thread	19 ft-lbs (2.6 kg-m)	31 ft-lbs (4.3 kg-m)	46 ft-lbs (6.4 kg-m)
7/16 In. thread	30 ft-lbs (4.1 kg-m)	50 ft-lbs (6.9 kg-m)	75 ft-lbs (10.4 kg-m)
1/2 In. thread	45 ft-lbs (6.2 kg-m)	75 ft-lbs (10.4 kg-m)	115 ft-lbs (15.9 kg-m)

# ASSEMBLY INSTRUCTIONS

Remove the sides, front, and back of the crate. Remove the plastic bag, shrink wrap and bubble wrap. Remove the metal clips that secure the grinder to the crate base. With a fork lift, raise the grinder from the wood base and set it in its final position. See FIG. 1 and 2.



**THE UNIT WEIGHS 1490 LBS. (676 kg). USE POWER EQUIPMENT TO LIFT MACHINE.**

Remove shipping straps from traverse carriage. Remove window protective sheets.




FIG. 1

## POSITION BASE

The ACCU-Pro Spin/Relief Grinder will require an operating area of about 120" W x 140" D x 90" H (305 x 356 x 229 cm). The mower reel will be lifted from the front of the machine if using the optional winch & boom and from the rear with the optional workstation. The machine operator will operate the unit from the front of the machine. Position the base to allow sufficient operating room in front of the machine (and behind if using the optional workstation). See FIG. 1 and 2.

The base should be placed on a relatively level concrete floor, with ample ceiling height to allow for the installation of the unit. Do not place the unit across two concrete slab seams or across a large crack.





FIG. 2

# ASSEMBLY INSTRUCTIONS (Continued)

Remove the carton and remove the contents from the carton onto a workbench. The carton includes:



# ASSEMBLY INSTRUCTIONS (Continued)

## LEVEL BASE

Place level on the top of the table. Adjust the leveling feet as necessary to bring to level. See FIG. 4.

Place a level across the table from front to rear. Adjust the leveling feet on the end of the machine as necessary to level. See FIG. 5

When both front to back and side to side leveling procedures have been completed, thread the hex jam nuts up against the nut that is welded to the bottom until they lock into place. Be careful not to move the leveling feet during this process. See FIG. 3. Make certain that all four leveling feet are firmly contacting the floor.

Recheck with level after locking nuts are firmly tightened.




FIG. 3




FIG. 4




FIG. 5




# ASSEMBLY INSTRUCTIONS (Continued)

## APPLY POWER



**BEFORE YOU APPLY POWER TO THE GRINDER, REFER TO THE "IMPORTANT GROUNDING INSTRUCTIONS" ON PAGE 10.**



**FIG. 7**

**115 Volt Model Only.** Plug the control box power cord into a standard 115V AC 20-amp grounded receptacle. See FIG. 7.

**220 Volt Model Only.** For 220 Volt Applications order Part No. 6320916, which includes a prewired 3 KVA 220V step down to 110V 50-60Hz transformer. See Page 10.

**IT IS RECOMMENDED THAT THIS ACCU-PRO SPIN/RELIEF GRINDER HAS ITS OWN PERMANENT POWER CONNECTION FROM THE POWER DISTRIBUTION PANEL, WITH NO OTHER MAJOR POWER DRAW EQUIPMENT ON THE SAME LINE.**

**IT IS REQUIRED THAT THE POWER DELIVERED TO THIS GRINDER IS 115 VAC - 20 AMPS. THE TOLERANCE ON THIS POWER REQUIREMENT IS +/- 5%. THEREFORE THE MINIMUM VOLTAGE REQUIREMENT IS 109VAC WITH 20 AMPS. VOLTAGE MUST BE CHECKED WITH ALL EQUIPMENT UNDER LOAD (OPERATING) ON THE CIRCUIT.**

**DO NOT OPERATE THIS GRINDER WITH AN EXTENSION CORD.**

**DO NOT OPERATE THIS GRINDER ON A GROUND FAULT INTERRUPTER (GFI) CIRCUIT. THE (GFI) WILL TRIP CONSTANTLY.**

**PROPER GROUNDING OF THE RECEPTACLE GROUND IN YOUR BUILDING MUST BE VERIFIED. IMPROPER GROUNDING IN YOUR BUILDING MAY CAUSE THE GRINDER TO MALFUNCTION.**


When installing the grinder, the following guidelines should be used to establish the wire size between the power panel in your building and the grinder receptacle. Note that the wiring in your building must be per code between main power panels and sub panels.

### **FOR 20 AMP RATED LARGE MACHINES**

For 0 to 40 Feet from panel to receptacle = Use 12 Ga. Wire.  
For 40 to 60 Feet from panel to receptacle = Use 10 Ga. Wire.  
For 60 to 100 Feet from panel to receptacle = Use 8 Ga. Wire.  
For 100 to 160 Feet from panel to receptacle = Use 6 Ga. Wire.

For 0 to 12 Meters from panel to receptacle = Use 2.5mm Wire.  
For 12 to 30 Meters from panel to receptacle = Use 4.0mm Wire.

The grinder is equipped with a high-low voltage relay which is factory preset at 100-140 VAC. If the power supply line does not deliver 100-140 VAC power under load, the relay will open and trip out the starter. If this occurs, your power supply line is incorrect and must be correct before proceeding further with the grinder.



## ASSEMBLY INSTRUCTIONS (Continued)


FOR 220 V 50 or 60Hz applications Product No. 6320916 should be ordered.

These models includes a 3 KVA 220V, step down to 110 V 50-60 Hz transformer.

The wiring diagram is shown in FIG. 8.

The power cord has no connector. A connector which is appropriate for your locality and 220 volt, 10 amp application should be installed.

**USE ONLY A QUALIFIED ELECTRICIAN TO COMPLETE THE INSTALLATION.**



INSTALL THE GREEN W/YELLOW STRIPE WIRE SUPPLIED INTO THE TERMINAL BLOCK IN THE HOLE OPPOSITE WIRE X3 AS SHOWN. TO INSTALL THE WIRE INSERT A SMALL SCREWDRIVER INTO THE CAVITY MARKED "A" TO OPEN THE WIRE HOLE.

ATTACH THE OTHER END OF THE GREEN W/YELLOW STRIPE WIRE SUPPLIED TO THE GROUND STUD ON THE TRANSFORMER.

FIG. 8

### IMPORTANT GROUNDING INSTRUCTIONS

In case of a malfunction of electrical breakdown, grounding reduces the risk of electrical shock by providing a path of least resistance for electrical current.

This Grinder has an electrical cord with an equipment grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded according to all local or other appropriate electrical codes and ordinances.

Before plugging in the Grinder, make sure it will be connected to a supply circuit protected by a properly sized circuit breaker or fuse. SEE SERIAL NUMBER PLATE FOR FULL LOAD AMP RATING FOR YOUR MACHINE.

Never modify the plug provided with the machine--if it won't fit the outlet, have a proper outlet and circuit installed by a qualified electrician.



**ALWAYS PROVIDE A PROPER ELECTRICAL GROUND FOR YOUR MACHINE. AN IMPROPER CONNECTION CAN CAUSE A DANGEROUS ELECTRICAL SHOCK. IF YOU ARE UNSURE OF THE PROPER ELECTRICAL GROUNDING PROCEDURE, CONTACT A QUALIFIED ELECTRICIAN.**

# PERIODIC MAINTENANCE

DAILY MAINTENANCE IS SPECIFIED ON PAGE 4 OF THE OPERATOR'S MANUAL, AND IS TO BE PERFORMED BY THE OPERATOR. LISTED BELOW ARE PERIODIC MAINTENANCE ITEMS TO BE PERFORMED BY YOUR COMPANY'S MAINTENANCE DEPARTMENT:

1. Clean the tank and filter of the vacuum system weekly or more often depending on the number of reels ground. (VACUUM SYSTEM IS OPTIONAL EQUIPMENT).
2. Use the grease fitting provided to grease the dove tail with high quality lithium grease monthly. Wipe off excess grease. See FIG. 7.
3. Wipe and re-oil with spray lubricant, the grinding wheel diameter adjusting lead screw every three months. Wipe off all excess lubricant. See FIG. 7.
4. Check the gib adjustment on the Grinding wheel diameter adjustment every 3 months. See FIG. 7.
5. Inspect the Grinding Wheel Poly-V belt for cracking and adjust the belt tension per procedure called out in the adjustment section every six months.
6. Wipe and relube with never-seez, the vertical and horizontal alignment shafts and lead screws, every six months. See FIG. 8.
7. Lift the bellows and wipe off the bearing rails monthly. Lubricate linear bearing, follow the lubrication procedure on the following pages. Generally, this will be every six months to a year.




FIG. 7




FIG. 8

# STORAGE PROCEDURE

It is important to follow the procedures below when placing your grinding in storage for an extended period of time. Proper care will help maintain the working functions of the grinder and decrease maintenance and problems that occur when storing the grinder.

## **BEFORE STORING THE GRINDER:**

-Clean the machine thoroughly. **(DO NOT USE COMPRESSED AIR OR A POWER WASHER TO CLEAN THIS MACHINE!)** See Maintenance section for instructions on cleaning polycarbonate.

-Lubricate the following parts by flooding the area with a spray lubricant and leaving it in place: (Do not use a Teflon based lubricant)

    Traverse Shafts & Linear bearings (see Lubrication section of manual)  
    Remove grinding wheel and spray the movable parts of the finger system  
    Cross slide shafts and adjustment screws (Right side of Traverse Base)  
    Scratches in the paint or any other bare metal surfaces

-Work the lubricant in by moving parts through their full range of motion.

-Make sure all controls are in the off position and unplug the unit from the wall. Turn off the digital alignment gage.

-Cover the unit if possible with a sheet or tarp.

## **BRINGING THE UNIT BACK INTO SERVICE:**

-Remove the cover and reapply lubricant to the items stated above. Wipe off all excess lubricant. (See Lubrication section for more details.)

-Plug the unit into the wall and test all electrical functions.

-Check the belts for cracking and adjust the tension if necessary.

-Check for damaged or missing parts.

# LUBRICATION


## LUBRICATION OF LINEAR BEARINGS

STEP 1--Thoroughly clean the shafts.

STEP 2--Flood spray the two shafts with a spray lubricant (**do not use a teflon based lubricant**) until the lubricant is dripping off the shafts. See FIG. 10 Then run the carriage back and forth through its range of travel. This will carry the lubricant into the bearings.

STEP 3--With a clean rag, wipe off the excess amount of lubricant from the shafts. Run the carriage back and forth through its range of travel and wipe the shafts after each traverse. Repeat until the shafts are dry to the feel. This completes the lubrication process.

If the unit will be shut down for an extended period of time, more than four weeks, then the shafts and other appropriate parts of the unit should be flooded with lubricant and that lubricant left in place until the unit is brought back into service. When the unit is brought back into service the full lubrication procedure as stated above should be repeated.



## MAINTENANCE (Continued)

### CLEANING AND MAINTENANCE GUIDELINES FOR POLYCARBONATE WINDOWS

#### Cleaning Instructions

##### **DO NOT USE GASOLINE**

**Adherence to regular and proper cleaning procedures is recommended to preserve appearance and performance.**

#### Washing to Minimize Scratching

Wash polycarbonate windows with a mild dish washing liquid detergent and lukewarm water, using a clean soft sponge or a soft cloth. Rinse well with clean water. Dry thoroughly with a moist cellulose sponge to prevent water spots. Do not scrub or use brushes on these windows. Also, do not use butyl cellosolve in direct sunlight.

Fresh paint splashes and grease can be removed easily before drying by rubbing lightly with a good grade of VM&P naphtha or isopropyl alcohol. Afterward, a warm final wash should be made, using a mild dish washing liquid detergent solution and ending with a thorough rinsing with clean water.

#### Minimizing Hairline Scratches

Scratches and minor abrasions can be minimized by using a mild automobile polish. Three such products that tend to polish and fill scratches are Johnson paste Wax, Novus Plastic Polish #1 and #2, and Mirror Glaze plastic polish (M.G. M10). It is suggested that a test be made on a corner of the polycarbonate window with the product selected following the polish manufacturer's instructions.

#### Some Important "DON'TS"

- ◆ **DO NOT** use abrasive or highly alkaline cleaners on the polycarbonate windows.
- ◆ **Never** scrape polycarbonate windows with squeegees, razor blades or other sharp instruments.
- ◆ Benzene, gasoline, acetone or carbon tetrachloride should **NEVER** be used on polycarbonate windows.
- ◆ **DO NOT** clean polycarbonate windows in hot sun or at elevated temperatures.

#### Graffiti Removal

- Butyl cellosolve, (for removal of paints, marking pen inks, lipstick, etc.)
- The use of masking tape, adhesive tape or lint removal tools works well for lifting off old weathered paints.
- To remove labels, stickers, etc., the use of kerosene, VM&P naphtha or petroleum spirits is generally effective. When the solvent will not penetrate sticker material, apply heat (hair dryer) to soften the adhesive and promote removal.

**GASOLINE SHOULD NOT BE USED!**

# MAINTENANCE (Continued)



## DIGITAL GAGE

### Important

- Do not mark the scale unit with an electric engraver or scratch the scale.
- Always use an SR44 battery (silver oxide cell)
- If the scale will not be used for more than three months, remove the battery and store it properly. Otherwise, leakage, if any, from the battery may damage the unit.

### Description of Parts


- |                        |                      |
|------------------------|----------------------|
| 1. Beam                | 2. Main Scale        |
| 3. Battery compartment | 4. Output Connection |
| 5. Display             | 6. ON/OFF Power      |
| 7. ZERO/ABS switch     | 8. Origin Switch     |
| 9. Inch/mm Switch      | 10. Tapped hole      |
| 11. Slider             |                      |



### Battery Installation and Origin Setting


Set the origin of the scale after installing the battery. Otherwise, the error sign("E" at the least significant digit) may appear, resulting in incorrect measurements.

- 1) To install the battery, remove the compartment lid and install the SR44 battery with its positive side facing up. After the battery is installed, set the origin.
- 2) To set the origin, move the slider to an area you wish to set as your origin. Turn the power on. Hold the ORIGIN switch down for more than one second. The "0.00" display appears, indicating origin setting is complete. The origin will be retained even if the power is turned off.




### Incremental (INC) & Absolute (ABS) mode

The LCD will display measurements from the origin when turned on (ABS mode). To set the origin see above. The display can be set to zero at any desired position by pressing the ZERO/ABS switch. INC indicator will appear in the display (INC mode), permitting measurements from this zero point. To return to the ABS mode hold the ZERO/ABS button for more than 2 seconds.



### Error Symptoms & Remedies

- **ERRC and display flickering:** Occurs when the scale surface is stained. Clean the scale surface and coat a thin film of low viscosity oil to keep out moisture.
- **E in the least significant digit:** This occurs when the slider is moved too quickly, but it does not affect the measurement. If it stays on when the slider stops, the scale surface is probably stained. If this is the case, take remedies as for ErrC.
- **B indication:** Battery voltage is low. Replace the battery as soon as possible.



### Cleaning

Clean gage with CRC 3-36 Cleaning and Lubrication Oil. Wipe off excess after cleaning. If CRC 3-36 is not available, use Denatured Alcohol to clean, then apply light oil and wipe off excess.

# ADJUSTMENTS

## CARRIAGE LINEAR BEARING REPLACEMENT

**STEP 1**--Detach the bellows mounting brackets from the carriage. Detach front and rear shields. See FIG. 15.

**STEP 2**--Remove the three screws of one linear bearing and slide the linear bearing off the end of the carriage shaft.

**STEP 3**--Insert a new linear bearing onto the end of the carriage shaft with the tension adjustment screw pointing outward. See FIG. 14. Adjust the tension screw of the linear bearing so when you radially rotate the linear bearing around the carriage shaft there should be no free play between the linear bearing and the carriage shaft.

**NOTE:** Tension is too tight if you feel a cogging action when you rotate the linear bearing around the shaft. This cogging is from the skidding of the bearing on the shaft and indicates tension screw is too tight.

Finally, sliding the bearing block back and forth should be a smooth uniform motion.

**!** SETTING THE BEARING TENSION CORRECTLY IS CRITICAL TO PROPER GRINDING. BEARINGS WHICH ARE TOO TIGHT OR TOO LOOSE WILL CAUSE POOR GRIND QUALITY. ALSO, BEARINGS WHICH ARE TOO TIGHT WILL HAVE SUBSTANTIALLY SHORTER LIVES AND MAY DAMAGE THE SHAFT.

**STEP 4**--Slide linear bearing under carriage and attach with the three screws.

**NOTE:** Repeat Steps 2 thru 4 with the other three linear bearings.

**STEP 5**--After all four linear bearings are reattached to the carriage check for correct bearing tension. The bearing tension is correct when you try to lift the carriage and can feel no carriage movement, which is free play up and down. The most dependable method of checking free play is to use a magnetic base dial indicator attached to the traverse frame weldment and reading the vertical movement above each bearing. This movement should be within .001" (.03 mm) Also, when pulling the carriage in the traversing direction, there should be only approximately a 3 lb force, with the belt disengaged. To check this attach a spring scale to the carriage and pull parallel to the carriage shafts. To double check the assembly, slide the carriage assembly from "end of travel" to "end of travel", it should have very uniform resistance through the full range of travel.

**STEP 6**--Replace the bellows carriage mounting brackets onto the carriage. Replace front and rear shields. See FIG. 15.




FIG. 14




FIG. 15



## ADJUSTMENTS (Continued)

### REEL FINGER DOVETAIL GIB AND ADJUSTING KNOB ADJUSTMENTS

The reel finger slide to the reel finger positioner has a dovetail with an adjustable gib for tensioning. Tighten the gib set screws on the side so there is no free play in the dovetail slide. Check for movement when pushing on the relief finger side to side with 20 lbs. (44kg) force. Make sure the knob assembly for adjusting the relief finger to the grinding wheel is rotatable by hand. The gib adjustment should be sufficient to maintain a rigid position of the reel finger. See FIG. 16.

Check the knob assembly rotating tension by checking the tightness of the nylon plug to the knob assembly threads. The tightness has to be sufficient so the knob assembly does not rotate during the relief grinding cycle. See FIG. 17.

NOTE: To adjust the nylon plug you must lock the index finger assembly down and then adjust the reel finger positioner so the clearance holes line up with the nylon plug set screw.

Take up any free play between the tee knob assembly, reel finger slide and .375 threaded split shaft collar. Loosen the shaft collar locking cap screw and rotate the shaft collar until there is no end play. Retighten locking cap screw on the threaded split shaft collar. See FIG. 16.

### GRINDING HEAD BELT TENSION ADJUSTMENT

The left side grip grinding wheel knob must be removed for belt tensioning adjustment. Remove the six screws holding, the two double tube clamps and the belt cover. For grinding motor belt adjustment, loosen the four socket head cap screws that attach the motor. Adjust the grinding motor for proper belt tension by pushing back on the motor and tighten the four socket head cap screws. The proper belt tension for the grinding head is to push down on the poly V belt half way between the two pulleys with 5 lbs. (2KG) of force and belt movement dimensions to be .12 inches (3mm). See FIG. 18. To verify belt tension mount the belt guard with two screws. Turn the motor on. If the belt is tensioned correctly, start-up torque of the motor through the pulley to the belt should have zero slippage. If there is belt slippage when turning on the motor there will be a slight squeal before the belt comes up to speed. When you achieve correct tension, reassemble all of the remaining parts that have been removed.




FIG. 16




FIG. 17




FIG. 18

## ADJUSTMENTS (Continued)

### LOCKING INDEX FINGER PIN

To align the Index Finger Locking Pin to the hole in the Index Finger Assembly loosen the two socket head cap screws so the index sensor block is movable. Push down on the index finger assembly until the spring loaded index finger locks into hole with no binding. Tighten the two socket head cap screws so the index sensor block is secured, and the locking pin moves freely. See FIG. 19.




FIG. 19

### PROXIMITY SWITCH

For the proximity switch to perform properly and reverse the direction of the carriage at each end of the rails, a distance of  $\frac{3}{16}$ " (4 mm) to  $\frac{1}{4}$ " (6 mm) needs to be maintained between the carriage proximity flag bracket and the proximity switch. See FIG. 20.

**NOTE:** Light on proximity activates when metal crosses in front of switch sensor.




FIG. 20

## ADJUSTMENTS (Continued)

### ADJUSTABLE RELIEF TENSION

If the relief angle appears to vary during relief grinding, adjust the tension on the nylon plug and set screw. See FIG. 21.




FIG. 21

### SAFETY SWITCH ALIGNMENT

For the safety switches to work properly they must be adjusted so the sender and receiver are parallel to each other with a maximum gap of .19 inches (5mm). (Adjust by moving the doors or brackers. If this does not help, a special wrench is needed to adjust the safety screws used to hold the switch in place.) See FIG. 22.





FIG. 22

## ADJUSTMENTS (Continued)

### SPIN GRINDING ATTACHMENT ADJUSTMENT


If play develops so crank handle wants to rotate in the scissor action on the spin grinding attachment, the play can be eliminated by tightening the set screw identified in FIG. 23.

If there is too much play in the spin drive pivot points, torque down the hex nut tight so conical washer is completely compressed, then back off 1/2 turn. See FIG. 23.



### REDUCER MOTOR ADAPTER TO ACTUATOR DRIVE SCREW CLAMPING COLLAR POSITIONING

The lower clamp collar, next to the reducer motor adapter, is to be positioned flush to the end of the actuator screw shaft and tighten down with 6 ft. lbs (0.8 kg) of torque. See FIG. 25. The top clamp collar is factory adjusted and does not need any further adjustment. There is to be no slippage between the reducer motor adapter shaft and actuator screw when pushing down on grinding head and stalling the reducer motor.



# ADJUSTMENTS (Continued)

## ADJUSTING CROSS SLIDE ASSEMBLY

If the cross slide becomes very difficult to turn it may become necessary to adjust the assembly. To relieve the tension on the assembly follow the procedure listed below:

**STEP 1**--Using a hydraulic jack, raise the traversing carriage base just enough to alleviate the weight stress on the Cross Slide Assembly.

**STEP 2**--Knock the pins on either side of the Mounting Frame Adjuster and loosen the 4 bolts (B504801) that connect the Carriage Mounting Frame to the frame of the grinder.


**STEP 3**--Jack the traversing carriage base up to put a preload on the Cross Slide Assembly.

**STEP 4**--Tighten the 4 bolts on the Carriage Mounting Frame to 75 ft-lbs.

**STEP 5**--Release the jack pressure and test the vertical and horizontal handwheels for ease of movement through their full range of motion.

**STEP 6**--If the Cross Slides tend to bind, repeat above steps jacking higher or lower (STEP 1) until the handwheels move freely.

**STEP 7**--When the Cross Slides move freely through their full range of motion, drill new holes and repin assembly.



# ADJUSTMENTS (Continued)

## CROSS SLIDE SHAFT REPLACEMENT

If the cross slide shafts become scarred or gnarled, replace them by the following procedure:

**STEP 1**--Use a hydraulic jack to raise the weight off the Cross Slide Assembly.

**STEP 2**--Loosen the two nuts on the support casting that hold the locking studs and tap with plastic hammer to loosen.

**STEP 3**--Loosen the locking handles and tap the center stud with a plastic hammer.

**STEP 4**--Loosen locknut and setscrew and remove the handwheel.

**STEP 5**--Remove the Slide Shaft.

**STEP 6**--Remove all burrs and resurface the shaft to a clean, smooth, polished surface.

(OR REPLACE WITH A NEW SHAFT.)

**STEP 7**--Coat shaft with Never-Cease and re-install the shaft through the Support, Cross Slide Block and the three locking studs. The shaft must move freely inside the Cross Slide Block before reassembling.



**STEP 8**--Retightening the nuts at the end of the locking studs to lock shaft in place.

**STEP 9**--Reinstall the Handwheel by snugging the setscrew to the flat located on the screw shaft, then torque nut until tight and back off 1/2 turn. Torque the setscrew to 70 in-lbs.

**STEP 10**--Test the Cross Slide, the handwheel should turn freely.

**STEP 11**--Lower the jack and retest the Cross Slide Assembly through full range of motion. If binding occurs, follow the procedure under Cross Slide Assembly located on page 21.

**NOTE:** It is also possible to remove the complete Cross Slide Assembly and do the repairs on a bench then reinstall.



## ADJUSTMENTS (Continued)

### TRAVERSE BELT TENSION

To adjust the tension on the traverse belt tighten the screws and nuts located at the left side of the traverse belt. Tighten nuts until the compression springs measure  $3/4"$ . See FIG. 25. If the springs are not tensioned equally, uneven loading on the traverse system may cause parts to fail.



**DO NOT OVERTIGHTEN. OVERTIGHTENING COULD DAMAGE THE BELT OR TRAVERSE DRIVE SYSTEM.**




FIG. 25

### TRAVERSE CLAMP FORCE

If the traverse clamp is slipping during regular operation it may be necessary to tighten the clamp. To tighten, loosen the jam nut on the clamp tip. Screw the tip out so there is  $.10"$  gap between the tip and the Clamp Support Block. See FIG 26. Lock in place by tightening the jam nut against the clamp being careful not to move the tip. Verify the distance between the clamp tip and block is still  $.10"$ . The  $.10"$  setting allows slippage in a jam situation and damage can occur if this adjustment is set to narrow.



**CAUTION SHOULD BE USED AS ADJUSTING THE TIP WILL AFFECT THE SLIP LOAD AND COULD DAMAGE THE CLAMP TIP, BELT OR TRAVERSE DRIVE SYSTEM.**




FIG. 26

# CONTROL BOARD POTENTIOMETER ADJUSTMENTS

## POTENTIOMETER ADJUSTMENTS TRAVERSE DRIVE CONTROL (TDC)

Min. Speed--Factory set at full (CCW) 8:30. Do not change this setting.

(Right Traverse) Forward Torque--Factory set at full (CW) 4:30. Do not change this setting.

(Left Traverse) Reverse Torque--Factory set at full (CW) 4:30. Do not change this setting.

IR COMP--Factory set to 9:00. IR COMP is current (I) resistance (R) compensation (COMP).

IR COMP adjusts the output voltage of the drive which balances load to motor RPM. Regulation of a traverse motor may be improved by slight adjustment of the IR COMP trim pot clockwise from its factory-set position. Overcompensation causes the motor to oscillate or to increase speed when fully loaded. If you reach such a point, turn the IR COMP trim pot counterclockwise until the symptoms disappear.

Max. Speed--Set at 3:30 for maximum voltage of 90 Volts DC to the traverse motor. When voltage is above 90 volts DC, the traverse motor will start to pulsate and not run smoothly.

(Right Traverse) Forward Acceleration--Factory set at full (CCW) 8:30. Do not change this setting.



(Left Traverse) Reverse Acceleration--Factory set at full (CCW) 8:30. Do not change this setting.

(DB) Dead Band is the potentiometer setting for the 50 or 60 Hz cycle control. Factory set to 9:00, works for both 50 and 60 Hz. Do not change this setting.

Calibrating the **DWELL TIME** rotary DIP switch adjusts the amount of time the process remains in the stop position after a limit switch is actuated. The **DWELL TIME** range is adjustable from 0 - 4 seconds. A DIP switch setting of 0 sets the **DWELL TIME** to 0 seconds, while a setting of 8 sets the **DWELL TIME** to 4 seconds. Dwell time is factory preset to #4 setting for a 2 second dwell time when reversing at each end of stroke.

Diagnostic LED's indicate the function that is currently being performed:

- \* **POWER** indicates that ac power is being applied to the control.
- \* **FORWARD** indicates that the process is running in the forward direction (traversing left).
- \* **REVERSE** indicates that the process is running in the reverse direction (traversing right).
- \* **PROX 1 FWD LIMIT** lights when the forward limit switch is actuated (left prox).
- \* **PROX 2 REV LIMIT** lights when the reverse limit switch is actuated (right prox).
- \* **DWELL** lights when the process remains stopped after a proximity switch is actuated.





# CONTROL BOARD POTENTIOMETER ADJUSTMENTS (Continued)

## SPIN DRIVE CONTROL BOARD (SDC)

The Spin Drive Control Board has three potentiometers on the lower board and two potentiometers on the upper board as shown on FIG. 27 and FIG. 28. These potentiometers have been set at the factory to the positions shown on FIG. 27 and FIG. 28.

### In the Relief Grinding Mode--

The remote Relief Speed Pot (RSP) and the Relief Torque Pot (RTP) interact with each other. The (RSP) is located on the upper spin board as a remote speed preset at 9:30. See FIG. 27. The (RTP) is located on the control panel and is for relief torque adjustment.

Remote Relief Speed Pot (RSP) when rotated clockwise will increase maximum spin drive speed when in the relief mode. This speed should never be above the 10:30 setting.

Relief Torque Pot (RTP) can vary the reel to finger holding torque for relief grinding. The recommended starting point is 30 in/lbs of torque setting. Never adjust the (RTP) potentiometer dial past the red line marking. Setting the reel to finger torque to high could cause the traverse motor system to not operate smoothly.

### In the Spin Grinding Mode--

the remote Spin Torque Potentiometer (STP) and the Spin Speed Pot (SSP) interact with each other. The (STP) is located on the upper spin board as remote torque preset at 2:00 for torque setting. See FIG. 27. The (SSP) is located on the control panel and is for spin speed adjustment.

The remote Spin Torque Pot (STP) controls maximum torque allowable in the spin grinding cycle only. This should never be adjusted past the 2:30 position. If the reel does not turn check that the reel is free turning by hand spinning. The Spin speed Pot (SSP) controls reel spin speed, adjust as required. This controls the spin drive speed for spinning the reel.

## POTENTIOMETERS ON THE LOWER BOARD OF THE SPIN DRIVE CONTROL (SDC) See FIG. 28.

### Maximum Speed Pot--

The maximum speed is factory preset to 4:30 (fully clockwise) to allow for maximum spin speed.

### Minimum Speed Pot--

The minimum speed is factory preset at 8:30 (full counterclockwise) so zero speed is obtainable for spin speed.

### IR Compensation Pot--

The IR Compensation is factory set at 9:00.

Regulation of the spin or relief grind spin motor may be improved by a slight adjustment of the IR COMP pot clockwise from its factory-set position. Overcompensation causes the motor to oscillate or to increase speed when fully loaded. If this occurs turn the IR COMP pot counterclockwise until symptoms disappear.

### UPPER SPIN BOARD




FIG. 27

### LOWER SPIN BOARD




FIG. 28

# MACHINE SERVICE (Continued)

## REPLACEMENT OF GRINDING HEAD SHAFT & BEARINGS

Remove grinding wheel and grinding wheel knob. The Grinding Head Spindle Assembly consists of the grinding head spindle and a ball bearing press fit together. The left side ball bearing is slip fit on the opposite end. To replace the spindle assembly remove the left side grinding wheel grip knob, square key and belt cover. See FIG. 29. Loosen the 4 socket head cap screws on the motor plate to remove the poly-V belt. Loosen the 2 set screws on the spindle pulley and remove the pulley, square key and pulley spacer. Push on the right hand side of the spindle assembly to compress conical washers so there is no pressure on the shaft retaining ring. Using a retaining ring pliers remove the small external retaining ring from the spindle assembly. You can now remove the spindle assembly out the right side by lightly tapping on the left end with a rubber mallet. The second ball bearing can be removed from the belt side of the Grinding Head Housing.

To reassemble place the 4 conical washers (2 Pair nested and then place the 2 pairs back to back) against the ball bearing on the new spindle assembly. See FIG. 30. Thoroughly clean the housing bore and the outside diameter of both bearings. Apply blue Loctite #242 to the outside diameter of the two bearings. Slide the spindle assembly into the right side of the Grinding Head Housing. Install the bearing sleeve against the bearing on the spindle assembly. Slip fit the new left side ball bearing onto the spindle assembly and into grinding head housing. Install the 9/16-18 Locknut onto the spindle shaft and using a spanner wrench on the right side of the spindle and a 7/8 deepwell socket on the left side, torque the locknut to 20 Ft. Lbs.

Replace the square key and the pulley pushing the pulley against the locknut with no end play. Apply blue locktie to the pulley bore before installation. Next install blue Loctite #242 on the pulley setscrews and tighten the two pulley set screws. Then remount the poly-V belt. (See Grinding Head Belt Tension Adjustment in the adjusting section). Replace belt cover and square key and mount the left side grinding wheel grip knob and tighten the two set screws.





FIG. 29



FIG. 30

# 632 MANUAL CONTROL PANEL



# ELECTRICAL TROUBLESHOOTING

## SKILL AND TRAINING REQUIRED FOR ELECTRICAL SERVICING

This Electrical Troubleshooting section is designed for technicians who have the necessary electrical knowledge and skills to reliably test and repair the ACCU-Pro electrical system. For those without that background, service can be arranged through your local distributor.

This manual presumes that you are already familiar with the normal operation of the Grinder. If not, you should read the Operators Manual, or do the servicing in conjunction with someone who is familiar with its operation.

Persons without the necessary knowledge and skills should not remove the control box cover or attempt any internal troubleshooting, adjustments, or parts replacement.

If you have any question not answered in this manual, please call your distributor. They will contact the manufacturer if necessary.

## WIRE LABELS

All wires on the ACCU-Pro have a wire label at each end for troubleshooting. The wire label has a code which tells you wiring information. The wire label has a seven or more position code. The first two or three digits are the wire number: 01-999. The next three numbers or letters are the code for the component to which the wire attaches. Example: GMC for Grind Motor Control. The last two numbers or letters are the number of the terminal on the component to which the wire attaches.

## ELECTRICAL TROUBLESHOOTING INDEX

AC Main Power Controls .....	Page 29-31
Spin Drive Controls in Spin Mode .....	Page 32-33
Spin Drive Controls in Relief Mode .....	Page 34-36
Grinding Motor Controls .....	Page 37-38
Traverse Drive Controls-w/prox .....	Page 39-40
Traverse--stopping and reversing .....	Page 41-43
Infeed Controls .....	Page 44-45

# ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--AC Main Power Controls: no electrical power to control panel.**

Verify all wires shown on the wiring diagram on pages 88 are correct and pull on wire terminals with approximately 3 lbs force to verify there are no loose terminal connections and/or no loose crimps between wire and terminal. If problem persists, test as listed below.

Possible Cause	Checkout Procedure	
Emergency Stop Botton(ESS) is Depressed	A. Pull Up on ESS Button	Machine works Yes--end troubleshooting No--go to Step B. next
You must push the System Start Switch (SSS) to get power to control Panel	B. Listen for the Magnetic Starter (MAG) contacts to pull in with a clunk	Machine works Yes--end troubleshooting No--go to step C. next.
Main Power Cord is not plugged in	C. Plug in main power cord	Machine works Yes--end troubleshooting No--go to step D. next.
Guard doors must be closed and ALL Switches <b>MUST</b> be turned <b>OFF</b> for contactor to pull in.	D. Close guard doors and turn off all switches.	Machine works Yes--end troubleshooting No--go to step E. next.
Main 20 amp outlet circuit breaker has tripped	E. Check circuit breaker in your building and reset if necessary. (Check wall outlet with a light to make sure it works)	Machine works Yes--end troubleshooting No--but light works in outlet--go to Step F. next. No--but light does not work in outlet. You must solve your power delivery problem independent of machine.
No 120 Volts AC power to Filter (FTR)	F. Check for 120V at Cord into FTR (Power Cord #32)	FTR "Line" Terminals for 120 Volts AC Yes--Go to Step G. next. No--Replace Power Cord- 6059054
No 120 Volts AC power out of Filter	G. Check for 120V out of FTR	FTR "Load" Terminals for 120 Volts AC Yes--Go to Step H. next. No--Replace Filter
No 120 Volts AC power to Main Circuit Breaker (MCB) 20 Amp.	H. Check for 120V to MCB	MCB (01MCB--) to Terminal Block 4 (Blue) for 120 Volts AC Yes--Go to Step I. next. No--Check wires & replace if needed.
No 120 Volts AC power from Main Circuit Breaker (MCB) 20 Amp.	I. Check for 120V from MCB	MCB (03MCB--) to Terminal Block 4 (Blue) for 120 Volts AC Yes--Go to Step J. next. No--Flip Switch on MCB to "ON" - Machine works-- end trouble shooting Machine does not work-- replace MCB

## ELECTRICAL TROUBLESHOOTING (Continued)

<u>Possible Causes</u>	<u>Checkout Procedure</u>	
No 120 Volts AC power to Secondary Circuit Breaker (SCB) 6 Amp.	J. Check for 120V to SCB	SCB (03SCB--) to neutral (blue) terminal out of FTR for 120VAC Yes--Go to Step K. next. No--Check wires & replace if needed.
No 120 Volts AC power from Secondary Circuit Breaker (SCB) 6 Amp.	K. Check for 120V from SCB	SCB (67SCB--) to neutral (blue) terminal out of FTR for 120 VAC Yes-- Go to Step L. next. No--Flip Switch on SCB to "ON"-Machine works--end of troubleshooting. Machine does not work--replace SCB
120 Volts AC power not delivered to Terminal Strip	L. Check for 120 Volts AC at terminal strip.	Terminal "11" on Terminal Strip 2 "07TB2-11" to Terminal Block 4 (Blue) for 120 Volts AC Yes--Go to Step M. next. No--Check wires #7 & #3, Check Jumper on Terminal Blocks 1-3.
Grinding Motor Switch (GMS) not working	M. Check for 120 Volts AC at GMS Terminals 1	Measure 120 volts AC from GMS Terminal 1 to Term Block 4(Blue) Yes--Go to Step N. next. No--Flip Switch and check again--Works--Switch is upside down. Does not work-- Check wiring/Verify Continuity/ Replace Switch
Spin Motor Switch (SMS) not working	N. Check for 120 Volts AC at SMS Terminals 1	Measure 120 volts AC from SMS Terminal 1 to Term Block 4(Blue) Yes--Go to Step O. next. No--Flip Switch and check again--Works--Switch is upside down. Does not work-- Check Wiring/ Verify Continuity/ Replace Switch
Bad Emergency Stop Switch (ESS)	O. Check voltage after the (ESS) <b>MAKE SURE SWITCH IS PULLED UP!</b>	Measure 120 Volts AC from (ESS) term 2 to Term Block 4(Blue) Yes--Go to Step P. next No--Check wire for continuity, then verify switch continuity. If bad replace ESS contactor (NC)
Bad System Start Switch (SSS)	P. Hold in SSS and Check voltage after the (SSS)	Measure 120 Volts AC from (SSS) term 3 to Term Block 4(Blue) Yes--Go to Step Q. next No--Check wire for continuity, then verify switch continuity. If bad replace SSS contactor (NO)
Low Voltage Relay (REL) not operating	Q. Hold in SSS and Check voltage at LVR. LVR must be installed in 8-pin socket.	Measure 120 Volts AC from LVR term 8 to Term Block 4(Blue) Yes--Go to Step R. next No--Check for 120 Volts AC from LVR term 6 to term 7. Yes--Verify Continuity of term 1 to term 8 on LVR. Replace LVR if bad. No--Verify Continuity of Wires.
Bad Main Contactor (MAG)	P. Hold in SSS and Check voltage at MAG A1 & A2.	Measure 120 Volts AC from MAG Term A1 to Term A2 Yes--MAG Should pull in with clunk, if not replace MAG. No--Verify Continuity of Wires.

## ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM**--Machine Shuts off when you turn on Grind motor switch or Spin Motor Switch.

**Possible Cause**

**Checkout Procedure**

Guard Doors are Open

**A.** Close the front doors and rear slide up door or workstation ramp depending on option installed.

Machine works  
Yes--end troubleshooting  
No--go to Step **B.** next

Door Safety Switches are not working properly

**B.** Check Alignment of Door Safety Switches on Front doors and rear slide up door or workstation ramp depending on option installed.

See Alignment section of this Manual.  
Machine works  
Yes--end troubleshooting  
No--go to Step **C.** next

No 24 Volts DC to Safety Monitor (SSM)

**C.** Check SSM for 24 Volts DC. (Turn switches off and press start switch to pull in MAG before testing voltages)

Measure 24 volts DC from SSM Terminal A1+ to Terminal A2-  
Yes--Go to Step **E.** next.  
No--Go to Step **D.** next.

No Power into 24 Volt DC Power Supply (PWR)

**D.** Check PWR for 120 Volts AC. (Turn switches off and press start switch to pull in MAG before testing voltages)

Measure 120 volts AC from PWR Terminal L to Terminal N  
Yes--Verify 24 VDC out of PWR (V+ to V-). Replace if no Voltage out; or Check Wiring & Verify Continuity to SSM if there is 24 VDC.  
No--Verify Wiring and Continuity from PWR to terminal blocks.

No Power Out to Door Switches

**E.** Verify 24Volts DC out to Door Switches.

Measure approximately 24 volts DC from Terminal Strip 1 Terminal 17 to Terminal Strip 2 Terminal 3  
Yes--Go to Step **F.** next.  
No--Verify Continuity of Wires to Terminal strip, Replace SSM if wires check OK.

Rear Safety Switch on the slide up door or workstation ramp depending on option installed is Bad.

**F.** With Rear slide up door or workstation ramp (depending on option installed) closed Verify 24Volts DC back form rear Safety Switches.

Measure approximately 24 volts DC from Terminal Strip 2 Terminal 3 to Terminal Strip 1 Terminals 14 and 15.  
Yes--Go to Step **G.** next.  
No--Check Alingment of Rear switches. If no Voltage to Term14 or 15 then replace rear switch. If still not working replace cord.

Front Door Switch is Bad

**G.** With Front doors Cloded Verify 24Volts DC back form Front Door Switch.

Measure approximately 24 volts DC from Terminal Strip 1 Terminal 17 to Terminal Strip 2 Terminals 2 and 4.  
Yes--Replace SSM  
No--Check Alingment of Front door switch. If no Voltage to Term2 or 4 then replace front switch.

**PROBLEM**--(MAG) turns on only with System Start Switch held in.

**Possible Cause**

**Checkout Procedure**

(MAG) holding contact has failed

**A.** Check wiring to and from MAG holding contact in. Verify the magnetic starter holding contact is working.

Measure 120 Volts AC at MAG term L3 to Term Block 4(Blue) after SSS is pushed.  
Yes--Verify Wiring to LVR  
No--Check voltage at T3. If 120 Volts AC Replace MAG. If no 120 Volts AC verify wiring to T3.

# ELECTRICAL TROUBLESHOOTING (Continued)

## PROBLEM--SPIN DRIVE NOT WORKING IN SPIN MODE.

Assuming (SSS) System Start Switch is on with 120 volts AC to control panel and all other functions are working.

Verify all wires shown on the wiring diagram on pages 88 are correct and pull on wire terminals with approximately 3 lbs force to verify there are no loose terminal connections and/or not loose crimps between wire and terminal. If loose terminals are found, retighten and retest system. If problem persists, test as listed below.


Spin Speed Pot (SSP) set to zero	A. Set (SSP) to 200 on the control panel.	Spin Motor works Yes--end troubleshooting No--go to Step B next
Spin Motor Switch (SMS) is not on	B. Turn (SMS) switch on	Spin Motor works Yes--end troubleshooting No--go to Step C. next
Spin Rotation Switch (SRS) is not on	B. Turn (SRS) switch to direction of reel rotation required. <b>NOTE: CENTER POSITION IS OFF</b>	Spin Motor works Yes--end troubleshooting No--go to Step C. next
Circuit Breaker is Tripped (4AMP)	C. Reset Circuit Breaker on front of Control Panel. Push in if tripped. If circuit breaker is tripped, verify reel is free spinning.	Spin Motor works Yes--end troubleshooting No--go to Step D. next
Spin Drive Control (SDS) is not working	D. Check (SDS) L1 to L2 for 120 Volts AC	(SDC) Term L1 to term L2 for 120 volts AC Yes--go to Step E. next No--Verify Power to Circuit Breaker, SMS, SRS and continuity of all wires. Replace any components found bad.
	E. Check (SDC) A1 & A2 for approx. 90+ Volts DC (Have Spin Speed Pot set to 400 RPM)	(SDC) Term A1 to A2 for approx 90+ volts DC Yes--go to Step F. next No--go to Step L. next
	F. Check for approx 90+ Volts DC input to (SRS)	(SRS) Term 2 to 3 for approx 90+ Volts DC Yes--go to Step G. next No--replace wires 13 & 14
	G. Check for approx 90+ Volts DC out put from (SRS).	(SRS) Term 6 to 7 for approx 90+ Volts DC Yes--go to Step H. next No--replace (SRS) switch
Spin Drive motor is bad	H. Check spin motor continuity	Remove wires at Terminal Strip 1, Term 4 & 5 check 0 ohms across the black and white wires Yes--end troubleshooting, motor should work (if it does not, replace motor) No--go to Step P. next



**Disconnect Power from Machine!**



# ELECTRICAL TROUBLESHOOTING (Continued)

Possible Cause	Checkout Procedure	
Spin Speed Pot (SSP) is not working	L. (SSP) (10K) on control panel	On (SDC), Remote Speed, check Black wire H terminal to Red wire W terminal for: Pot Full CCW --0 volts DC Pot Full CW--4.4 Volts DC Check White wire L terminal to Red wire W terminal for: Pot Full CCW --4.4 Volts DC Pot Full CW-- DC 0 Volts DC Yes--Go to Step M No--Go to Step N.
Spin Torque Pot (STP) is not set correctly	M. Check (STP) remote torque on the top (SDC) board	(STP) on (SDC) remote torque should be set at 2:00 o'clock position. See Pages 24 and 25. Adjust if incorrect and check Spin Drive Function. Yes--end of troubleshooting No--Replace (SDC)
(SSP) is not working	N. (SSP) (10K) Remove 3 Remote Speed wires. Red wire to term W White wire to term L Black wire to term H	Check for 10,000 ohms Red wire to white wire Full CCW--0 ohms Full CW-10,000 ohms Red wire to black wire Full CCW--10,000 ohms Full CW--0 ohms Yes--replace (SDC) No--replace (SSP)
Worn Motor Brushes	P. Inspect Motor Brushes	Remove the brushes one at a time and maintain orientation for reinsertion. See if brush is worn short 3/8" (10 mm) minimum length. Yes--replace motor brushes No--replace Spin Drive Motor
	<b>DISCONNECT POWER FROM MACHINE !</b>	

# ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--Spin Drive not working in relief mode.**

Assuming (SSS) System Start Switch is on with 115 volts AC to control panel and all other functions are working.

Verify all wires shown on the wiring diagram on pages 88 are correct and pull on wire terminals with approximately 3 lbs force to verify there are no loose terminal connections and/or no loose crimps between wire and terminal. If loose terminals are found, retighten and retest system. If problem persists, test as listed below.

Possible Cause	Checkout Procedure	
Relief Torque Pot (RTP) set to zero	A. Set (RTP) to 20 on the control panel.	Spin Motor works Yes--end troubleshooting No--go to Step B. next
Spin Motor Switch (SMS) is not on	B. Turn (SMS) switch on	Spin Motor works Yes--end troubleshooting No--go to Step C. next
Spin Rotation Switch (SRS) is not on	C. Turn (SRS) switch to direction of reel rotation required. NOTE: center position is off	Spin Motor works Yes--end troubleshooting No--go to step D. next
Circuit Breaker is Tripped (4AMP)	D. Reset Circuit Breaker on front of Control Panel. Push in if tripped.	Spin Motor works Yes--end troubleshooting No--go to step E. next
Spin Drive Control (SDS) is not working	E. Check (SDS) L1 to L2 for 120 Volts AC	(SDC) Term L1 to term L2 for 120 Volts AC Yes--go to Step F. next No--Verify Power to Circuit Breaker and SMS and continuity of wires. Replace CB or SMS if needed.
	F. Check (SDC) A1 & A2 for approx. 20 Volts DC (Have Relief Torque set to Red Line)	(SDC) Term A1 to A2 for approx 20 Volts DC Yes--go to Step G. next No--go to Step L. next
	G. Check for approx 20 Volts DC input to (SRS)	(SRS) Term 2 to 3 for approx 20 Volts DC Yes--go to Step H. next No--replace wires 13 & 14
	H. Check for approx 20 Volts DC out put from (SRS).	(SRS) Term 6 to 7 for approx 20 Volts DC Yes--go to Step I. next No--replace (SRS) switch
Spin Drive motor is bad	I. Check spin motor continuity	Remove wires at Terminal Strip 1, Term 4 & 5 check 0 ohms across the black and white wires Yes--end troubleshooting, motor should work (if it does not, replace motor) No--go to Step P. next



**DISCONNECT POWER FROM THE MACHINE**

# ELECTRICAL TROUBLESHOOTING (Continued)

## Possible Cause

## Checkout Procedure

(RTP) Relief Torque Pot is not working

L. Check (RTP) (50K) on control panel (check voltage with pots at fully clockwise and counterclockwise positions)

On(SDC), Remote Torque check Black wire H terminal to Red wire W terminal for:

Pot CCW-- 0 volts DC

Pot CW-- .2 Volts DC

Check White wire L terminal to Red wire W terminal for:

Pot CCW-- .2 Volts DC

Pot CW-- DC 0 Volts DC

Yes--go to Step M. next

No--go to Step N. next

Relief Speed Pot (RSP) is not set correctly.

M. Check (RSP) remote speed (10k) on (SDC) top board (this is preset to 9:30)

(RSP) to the top (SDC) board should be set at 9:30. See pages 24 and 25. Adjust if incorrect and check Relief Torque function.

Yes--end of troubleshooting

No--replace (SDC)

(RTP) is not working

N. (RTP) (50K) Remove 3 Remote Torque Wires  
red wire to term W  
white wire to term L.  
black wire to term H.

Check for 50,000 ohms

Red wire to white wire

Full CCW--0 ohms

Full CW--50,000 ohms

Red wire to black wire

Full CCW--50,000 ohms

Full CW--0 ohms

Yes--Replace (SDC)

No--replace (RTP)

Worn Motor Brushes



P. Inspect Motor Brushes  
**DISCONNECT POWER FROM MACHINE !**

Remove the brushes one at a time and maintain orientation for reinsertion. See if brush is worn short 3/8" (10 mm) minimum length

**PROBLEM : Spin drive speed goes at one speed only.****Possible Cause****Remedy**

Wiring hookup to potentiometer is improper. (If components have been replaced)

A. Check potentiometer wiring for proper hookup. See that speed pot is wired per electrical diagram

If wiring is wrong, correct and test.

Yes--end of troubleshooting

No--Go to Step B. next

Defective spin speed control (SSP) potentiometer.

B. (SSP) 10K Remove 3 remote speed wires.

red wire to term W

white wire to term L

black wire to term H

Check for 10,000 ohms

Red wire to white wire

Full CCW--0 ohms

Full CW--10,000 ohms

Red wire to black wire

Full CCW--10,000 ohms

Full CW--0 ohms

Yes-- Go to Step C. next

No--Replace (SSP)

Main circuit board dial pot settings not correct. (If board has been replaced)

C. Check all pot settings on both boards as of the (SDC) shown on Pages 24 and 25. (See Adjustment Section Spin Drive Control [SDC] Board Setting).

Yes-- end of troubleshooting

No--replace (SDC)

**PROBLEM: Spin drive motor speed varies**

IR Comp trim pot not adjusted properly.

A. See adjustment section for trim pot setting on Page 24.

Original adjustment was not set properly

Torque to rotate the reel too high.

B. Readjust bearing preload for the reel. Maximum torque load 25 in./lb to rotate reel.

Too much load on drive motor will cause motor to hunt and vary speed.

Check all terminal connections for tightness.

C. When .250 female spade terminals are not tight, remove and crimp slightly together. When reinstalling, push on pressure should have increased for good contact.

When connections are not tight the control board varies voltage to the DC motor which then varies speed.

# ELECTRICAL TROUBLESHOOTING (Continued)

## PROBLEM-- Grinding motor not working.

Assuming (SSS) System Start Switch is on with 120 volts AC to control panel and all other functions are working.

Verify all wires shown on the wiring diagram on pages 74-76 are correct and pull on wire terminals with approximately 3lbs force to verify there are no loose terminal connections and/or no loose crimps between wire and terminal. If loose terminals are found, retighten and retest system. If problem persists, test as listed below.

Possible Cause	Checkout Procedure	
Grinding Motor Switch (GMS) is not on.	A. Turn switch on	Grinding Motor works Yes--end troubleshooting No--go to Step B. next
Guard doors are not closed	B. Close Front guard doors and Rear slide up door or workstation ramp depending on option installed.	Grinding Motor works Yes--end troubleshooting No--go to Step C. next
15 Amp Circuit Breaker (CB) is tripped	C. Check 15 amp CB on front of Control panel. Press in if tripped.	Grinding Motor works Yes--end troubleshooting No--go to Step D. next
GMS not working	D. Check for power to GMS	GMS term 5 to Terminal Block 4 (Blue) for 120 Volts AC Yes--go to Step E. next No--With power off, check continuity of wires to GMS.
	E. Check for power from GMS	GMS Term 6 to Terminal Block 4 (Blue) for 120 Volts AC Yes--Go to Step F. next No--replace GMS
Grinding Motor Relay not working	F. Check for power to relay Coil (Relay should click when GMS is turned on.)	Check for 120 Volts (AC) from A1 to A2 of Grinding motor Relay. Yes--Go to Step G. next No-- check continuity of wires to Grinding motor Relay.
No Power to Relay Contacts	G. Verify Power to Relay Contacts	(REL) Term L1 to Term L2 for 120 Volts (AC) Yes--Go to Step H. next No--Check wires to REL Term L1 & L2

## ELECTRICAL TROUBLESHOOTING (Continued)

Possible Cause	Checkout Procedure	
Bad Contacts in Grinding motor Relay	H. Verify power out of Grinding Motor Relay.	(REL) Term T1 to Term T2 for 120 Volts (AC) Yes--Go to Step I. next No--Replace Grinding Motor Relay
Bad Circuit Breaker	I. Verify Power out of Circuit Breaker.	Check for 120 Volts (AC) from terminals TB2-6 to Terminal Block 4 (Blue) Yes--Go to Step J. next No--Check circuit breaker for continuity. Verify wiring and replace if needed.
Bad Grinding Motor	J. Verify Power to Grinding motor Cord.	Verify wiring at terminals 1, 2 & 3 on Terminal Strip 1. Check TB1-1 to TB1-2 for 120 Volts (AC). Yes-- Check terminals on motor cord. If tight replace motor. No-- Check wires from Grinding Motor Relay and Circuit Breaker to Terminal Strip 1.

## ELECTRICAL TROUBLESHOOTING (Continued)



**PROBLEM--**Traverse Drive not working.

**Assuming (SSS) System Start Switch is on with 120 volts AC to control panel and all other functions are working.**

**Verify all wires shown on the wiring diagram on pages 88 are correct and pull on wire terminals with approximately 3lbs force to verify there are no loose terminal connections and/or no loose crimps between wire and terminal. If loose terminals are found, retighten and retest system. If problem persists, test as listed below.**

Possible Cause	Checkout Procedure	
Traverse Motor Switch (TMS) is not on	A. Turn on (TMS)	Traverse works Yes--end troubleshooting No--got to Step B. next
Traverse Speed Pot (TSP) set to zero	B. Set (TSP) to 35 on the control panel	Traverse works Yes--end troubleshooting No--go to Step C. next
Fuse on Traverse Drive Control (TDC) has failed	C. Check fuse and replace if failed. See Page 23. Too heavy a grind causes grinding head traverse motor to overload and blow the fuse, NOTE: Fuse can not be checked visually. Use Ohm test to check fuse. If needs replacing <b>MUST</b> use a <b>3 amp slo-blo fuse</b> . Part Number 3707546.	Traverse works Yes--end troubleshooting No--go to Step D. next
Traverse Drive Control (TDC) is bad	D. Check for 120 Volts (AC) incoming to (TDC)	On (TDC) Terminal L1 to L2 for 120 Volts AC Yes--Go to Step F. next No--Go to Step E. next
Bad Traverse Motor Switch (TMS)	E. Check for 120 Volts AC at (TMS). (Make certain (TMS) is on)	Measure 120 volts AC from TMS Terminal 5 to Term Block 4(Blue) Yes--Go to Step L. next. No--Flip Switch and check again- Works--Switch is upside down. Does not work-- Check wiring/Verify Continuity/ Replace Switch

# ELECTRICAL TROUBLESHOOTING (Continued)

Possible Cause	Checkout Procedure	
No DC Voltage from (TDC) Traverse Drive Control	<p>F. Check for 90 Volts DC across (TDC) terminals #A1 to #A2 this voltage drives the DC traverse motor. NOTE: Traverse must be on and have (TSP) turned full CW to maximum voltage of 90 VDC</p>	<p>Check (TDC) terminals #A1 to #A2 for 90 Volts DC            Yes--go to Step G. next            No--go to Step H. next</p>
Traverse Motor is bad	<p>G. Check traverse motor continuity</p>  <p><b>DISCONNECT POWER FROM MACHINE</b></p>	<p>Remove motor wires from Terminal Strip 1 terminals #7 &amp; #8 check for 0 ohms across the black and white wires            Yes--end troubleshooting, motor should work (if it does not, replace motor)            No--go to Step K. next</p>
(TSP) is not working	<p>H. Check (TSP) (10K) on control panel</p>	<p>(TDC) Pin #8 to #7            Pot Full CCW    Pot Full CW                      0VDC                    9.75 VDC            Pin #8 to 9            Pot Full CCW    Pot Full CW                      9.75 VDC            0 VDC            Yes--replace the (TDC)            No--go to Step J. next</p>
(TSP) (10K) is bad	<p>J. Check (TSP) for 10,000 ohms. Remove three wires from (TDC)            red from term #8            white from term #7            black from term #9</p>	<p>Check for 10,000 ohms red to white wires            Full CCW--0 ohms            Full CW--10,000 ohms            Red to black wires            Full CCW--10,000 ohms            Full CW--0 ohms            Yes--replace the (TDC)            No--replace (TSP)</p>
Worn motor brushes	<p>K. Inspect Motor Brushes</p>  <p><b>DISCONNECT POWER FROM MACHINE</b></p>	<p>Remove the brushes one at a time and maintain orientation for reinsertion. See if brush is worn short, 3/8" (10 mm) minimum length.            Yes--replace motor brushes            No--replace Traverse Motor</p>



## ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM**--Traverse does not stop to reverse directions when flag goes under the proximity switch on the left side or right side of machine.

### Possible Cause    Checkout Procedure

Gap between flag and prox is incorrect.

A. Gap between flag and prox should be 3/16 to 1/4" (4-6 mm). Prox LED does not light when flag is under prox.

If incorrect, adjust per adjustment section of manual.  
Yes--end troubleshooting  
No--go to Step B. next

Proximity Switch is bad.

B. Proximity switch is not working properly or wire connections are loose.

First check to see if proximity light comes on. When the light is on, it means that there is electricity coming to proximity switch. Actuate prox switches with steel tool to take measurements.

The light coming on shows the proximity is getting electrical contact.

Left proximity (PROX 1) check Traverse drive Control (TDC) between terminals #13 (black wire) and #15 (brown wire).

Proximity light on-  
0 Volts DC  
Proximity light off-  
12 Volts DC

Right proximity (PROX) check #14 (black wire) and #15 (brown wire).

Proximity light on-  
0 Volts DC  
Proximity light off-  
12 Volts DC

Replace proximity switch if the voltages do not read as above.

# ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--**Traverse speed control goes at one speed only.

## Possible Cause

## Checkout Procedure

Defective speed control potentiometer

**A.** Check potentiometer on control panel.

Traverse Drive Control Pin #8 to 7  
 Pot full CCW      Pot Full CW  
 0 VDC                      9.75 VDC  
 Pin #8 to 9  
 Pot full CCW      Pot Full CW  
 9.75 VDC              0 VDC  
 Yes--Pot is OK  
 No--Go to Step **B.** next

**B.** Check potentiometer for 10,000 ohms.  
 Remove three wires from Traverse Drive Control  
 red from term #8  
 white from term #7  
 black from term #9

Check for 10,000 ohms  
 Red to White wires  
 Full CCW - 0 ohms  
 Full CW - 10,000 ohms  
 Red to Black wires  
 Full CCW - 10,000 ohms  
 Full CW - 0 ohms  
 Yes--Go to Step **C.** next  
 No--replace potentiometer.  
 Wiper inside of potentiometer controls speed. Wiper may be bad and not making contact.

Wiring hookup to potentiometer is improper.  
 (If components have been replaced.)

**C.** Check potentiometer wiring for proper hookup. See that speed pot is wired per electrical diagram

Wrong wire hookup effects traverse control. Reversing red and orange wires to potentiometer to the D C motor will run at zero speed but maximum will be too slow. Reversing red and white wires does not affect speed control.  
 Check for Proper function.  
 Yes--end troubleshooting  
 No--Go to Step **D.** next

Main circuit board dial pot settings not correct.  
 (If board has not been replaced.)

**D.** Check all pot settings on circuit board as shown in wiring diagram.  
 (See adjustment section Traverse Motor Control Board Settings.)

Minimum and maximum pot settings effect traverse speed.

## ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--**If the carriage traverses to one end of stroke or the other and it stops and does not reverse direction.

Possible Cause	Remedy	Reason
Proximity switch is not working properly or wire connections are loose	First check to see if proximity light comes on. When the light is on, it means that there is electricity coming to proximity switch. Actuate prox switches with steel tool to take measurements.	The light coming on shows the proximity is getting electrical contact.
	Left proximity (PROX1) check Traverse drive Control (TDC) between terminals #14 (black wire) and #15 (brown wire).	Proximity light on- 0 Volts DC Proximity light off- 12 Volts DC
	Right proximity (PROX) check (TDC) between terminals #13 (black wire) and #15 (brown wire).	Proximity light on- 0 Volts DC Proximity light off- 12 Volts DC
		Replace proximity switch if the voltages do not read as above.

**PROBLEM--**Insufficient hesitation at carriage stops prior to reversing traverse.

The dwell time on the traverse drive control not set properly.	Reset dwell time as required. One increment increases Dwell time by 1/2 second.
--	---

**PROBLEM--**Traverse changes directions erratically while running in traverse cycle.

Loose wire to proximity switch.	Check wire connections from the proximity switches and tighten down screws.	A loose wire connection will give intermittent electrical contact.
---------------------------------	---	--

## ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--Infeed motor not working.**

**Assuming (SSS) System Start Switch is on with 115 Volts AC to control panel and all other functions are working.**

<b>Possible Cause</b>	<b>Checkout Procedure</b>	
Infeed Jog Switch (IJS) is not held to on position	A. (IJS) Hold switch on in either direction	Infeed motor works Yes--end troubleshooting No--go to Step B. next
Infeed Speed Switch (IJS) is not on high speed	B. Put (IJS) on high speed for ease of checkout. (Note: Infeed motor will always be in low if the grinding motor switch is on.)	High speed works Yes--end troubleshooting No--go to Step C. next
Infeed motor/reducer drive coupling is loose	C. Open infeed motor coupling inspection plate to check for loose coupling. Retighten coupling to drive actuator screw. See adjustment section of manual.	Infeed works-- Yes--end troubleshooting No--go to Step D. next
No DC voltage to Grinding Wheel Infeed Motor (GIM)	D. With the Infeed Speed Switch in rabbit position, check for 12+ Volts DC across terminals labeled 2 and 5 of the (IJS) with (IJS) held on.	Check term 2 & 5 of (IJS) for 12+ Volts DC. Yes--go to Step E. next No--go to Step G. next
Infeed Motor/Reducer will not function	E. With the Infeed Speed Switch in rabbit, check for 12 Volts DC at the terminals 137TBB-21 and 137TBG-22.  F. Disconnect (GIM) from the infeed actuator and check (GIM) function under no load.	Check for 12 Volts DC at Term marked 137TBB-21 and 137TBG-22. Yes--Go to Step F. next No--Replace cord wire no. 94  Check (GIM) function when disengaged from Infeed Actuator. Yes--Replaced Infeed Actuator No--Replace (GIM)
Switch (IJS) is bad	G. Check for 12+ Volts to (IJS).	Check for 12+ Volts DC at Term 6 & 4 and 3 & 1 of (IJS). Yes--Replace (IJS) No--go to Step H. next.
No DC Voltage from the Voltage Regulator.	H. Check for 12 volts DC at Bridge Diode output.	Check for 12 Volts DC at term 120BD+ and 133BD-- Yes--Replace Voltage Regulator No--Go to Step I. next.

## ELECTRICAL TROUBLESHOOTING (Continued)

**PROBLEM--Infeed motor not working.**

**Assuming (SSS) System Start Switch is on with 115 volts AC to control panel and all other functions are working**

Possible Cause	Checkout Procedure	
Bad Bridge Diode	I. Verify voltage to bridge diode.	Check 12.6 Volts AC at input of Bridge Diode (BD1) Term 190BD-S(~) to Term 190BD-S(~) Yes--Replace Bridge Diode BD1 No--Go to Step J. next
No AC Voltage to the input side of transformer	J. Check for 115 Volts AC at transformer input black wires.	Check for 115 Volts AC at Term. TBW-13 and TBG-9. Yes-- Replace Transformer No-- Follow separate trouble shooting procedure on AC main power.

**PROBLEM--Infeed motor has no low speed (turtle) function.**

**Assuming (SSS) System Start Switch is on with 115 volts AC to control panel and all other functions are working and infeed motor works in high speed (rabbit position).**

Possible Cause	Checkout Procedure	
Incorrect DC Voltage from the Voltage Regulator in low speed turtle position.	A. Verify voltage to grind infeed motor (GIM). With the infeed speed switch in turtle, check the DC voltage at the terminal strip where the Grinding Wheel Infeed Motor (GIM) cord attaches.	Check 2.7 ±0.5 Volts DC at Term 137TBB-21 and 137TBG-22. Yes--Go to Step B. next. No--Replace Voltage Regulator
Infeed Actuator is bound and will not allow low speed (turtle) function.	B. Disconnect (GIM) from the infeed actuator and check (GIM) function under no load.	Check (GIM) function when disengaged from Infeed Actuator. Motor should step slowly. Yes--Replaced Infeed Actuator No--Replace Grind Infeed Motor.

## MECHANICAL TROUBLESHOOTING (Continued)

### Possible Cause

### Checkout Procedure

#### **PROBLEM--Reels ground have high/low blades**

Traverse Speed set too fast.

Check roundness using a magnetic base dial indicator. Traverse speed should be set approximately 12 ft/min. (4 meters/ min.) if roundness is varying.

Lineal bearings for the grinding head carriage are out of adjustment (loose) or have grit buildup causing uneven traversing load.

Relubricate and adjust linear bearings per adjustment section. If problem persists, replace lineal bearings on the carriage base. Check for any holes in the bellows that would permit any grinding grit penetration. See adjustment section for lineal bearing replacement.

#### **PROBLEM--Excessive grinding stock being removed when traversing to the right in the relief grinding mode.**

Gib adjustment for the relief finger assembly is loose so reel finger has movement. When traversing to the right minimum grinding stock removal should be seen as compared with heavy stock removal when traversing to the left.

Tighten the set screws for the gib adjustment. See procedure in the adjustment section in the manual.

#### **PROBLEM-- Grinding stock removal from reel is irregular during spin grinding.**

Lineal bearings on the grinding head carriage are too loose .

The lineal bearing must be preloaded to the traverse shafts with no vertical movement. See manual adjustment section for carriage bearing adjustments.

#### **PROBLEM--Carriage traversing varies speed while grinding.**

Lineal bearings in the carriage do not rotate freely.

Check for grinding grit getting into the lineal bearings and causing excessive driving torque of carriage. Abrasive noise is detectable when excessive grit is in the lineal bearings. Replace the four lineal bearings in the main carriage. Check bellows for holes and replace if necessary.

Belt is slipping

Belt Clamp may have moved. See manual adjustment section for Traverse Clamp Force.

Traverse Belt tension to loose

Check the spring length on left side of traverse belt. See manual adjustment section for Traverse Belt Tension.

# MECHANICAL TROUBLESHOOTING (Continued)

## Possible Cause

## Checkout Procedure

### PROBLEM--Too heavy a burr on cutting edge of reel blades.

Traverse speed set too high causing a heavy burr on the reel blade when spin grinding.

Traverse speed should be set lower approximately 12 ft/min. (meters/min.) for a smaller burr on cutting edge.

### PROBLEM--Cone shaped reel after grinding.

Grinding head travel not parallel to the reel center shaft.

Grinding head travel was not setup parallel to the reel center shaft in vertical and horizontal planes. See Align the Reel Section in operator's Manual

### PROBLEM--Relief grind on the reel blades do not go the full length of the reel.

The right side corner of the grinding wheel is always to be in contact with the reel blade. This is high point of the relief finger.

The right hand side of the grinding wheel is not in full contact for relief grinding.  
See Operators Manual for NORMAL HELIX AND REVERSE HELIX.

### PROBLEM-- Traverse speed is too slow.

#### Possible Cause

#### Remedy

#### Reason

Lineal bearing in the carriage are set too tight.

A. Readjust bearings for proper tension. (for more detail see lineal bearing replacement in the adjustment section of the manual.)

When bearing preload is too tight, it causes excessive loading to drive the carriage.  
When traverse belt is disengaged, the proper traverse load is 2 to 3 lbs. Use a tension scale to check. (A general guide only.)

### PROBLEM--Spin Drive cranks up and down too hard.


The two top and two bottom pivot screws are compressing the conical washer too tight.

A. Tighten down the locknut until it bottoms out and back off 1/2 turn. Check to see if there is a cone shape to the washer. Four (4) pivot points.

Have enough play so the crank turns snugly but during operation it is free.

Check screw adjustment tension on nylon plug riding against the screw thread.

B. Loosen set screw and check. (See adjustment section.)







# PARTS LIST

# 6329546 CANOPY ASSEMBLY

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B250816 .....	Button Head Cap Screw 1/4-20 x 1/2 Long
2 .....	B251001 .....	Hex Head Cap Screw 1/4-20 x 5/8 Long
3 .....	B250801 .....	Hex Head Cap Screw 1/4-20 x 1/2 Long
4 .....	B371216 .....	Button Head Cap Screw 3/8-16 x 3/4 Long
5 .....	B371611 .....	Socket Head Cap Screw 3/8-16 1 Long
6 .....	J257000 .....	1/4-20 Nylon Jam Locknut
7 .....	R000536 .....	Internal Tooth Lock Washer 1/4
8 .....	J377000 .....	3/8-16 Nylon Jam Locknut
9 .....	K250001 .....	1/4 Flat Washer
10 .....	K251501 .....	1/4 Split Lockwasher [Gage Holder]
11 .....	K370001 .....	3/8 Flat Washer SAE
12 .....	K371501 .....	3/8 Split Lockwasher
13 .....	R000454 .....	Flat Washer (1 OD x .44 ID)
14 .....	09394 .....	2 Prong Knob
15 .....	3589106 .....	Flat Washer (1.38 OD x .39 ID)
16 .....	3707009 .....	Liquid Tight Strain Relief .27-.47 Wire
17 .....	3707029 .....	Liquid Tight Strain Relief .19-.30 Wire
18 .....	3707093 .....	Liquid Tight Strain Relief .43-.55 Wire
19 .....	3707595 .....	7/8 Hole Plug
20 .....	3707597 .....	5/8 Hole Plug
21 .....	3708448 .....	Electrical Warning Decal
22 .....	3708458 .....	Sharp Warning Decal
23 .....	3708521 .....	Plastic Rivet
24 .....	3708605 .....	Respirator Warning Decal
25 .....	3708606 .....	Hearing Protection Warning Decal
26 .....	3708612 .....	No Fuel Warning Decal
27 .....	3708703 .....	Multiple Safety Symbols Decal
28 .....	B190613 .....	10-24 x 3/8 Button Head Socket Cap Screw
29 .....	3708872 .....	Patent Decal
30 .....	3709990 .....	Foley United Decal
31 .....	6309039 .....	Gage Mounting Pin
32 .....	6329022 .....	Side Frame Spacer Plate
33 .....	6329024 .....	Canopy Boom Support Bracket
34 .....	J197000 .....	10-24 Lock Nut
35 .....	6329053 .....	ACCUPro Decal
36 .....	6329047 .....	Door Guide Bracket RH
37 .....	6329048 .....	Door Slide
38 .....	6329049 .....	Door Guide Bracket LH
39 .....	6329059 .....	Canopy Support Bracket
40 .....	J167000 .....	8-32 Lock Nut
41 .....	6329543 .....	Guard Weldment - RH
42 .....	6329542 .....	Guard Weldment - LH
43 .....	3707273 .....	Strain Relief
44 .....	6329533 .....	Front Guard Door Assembly (see page 60)
45 .....	3707563 .....	Liquid Tight Strain Relief
46 .....	3707728 .....	Safety Switch
47 .....	3708865 .....	Safety Screw 8-32 x 1.5 Long
48 .....	6329109 .....	Right Hand Rear Guard Panel
49 .....	6329110 .....	Left Hand Rear Guard Panel
50 .....	6329112 .....	Boom Hole Cover Panel




<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B250816 .....	Button Head Cap Screw 1/4-20 x 1/2 Long
2 .....	B252416 .....	Button Head Cap Screw 1/4-20 x 1 1/2 Long
3 .....	D161266 .....	Pan Head Machine Screw #8 x 3/4 Long
4 .....	J167000 .....	8-32 Nylon Jam Locknut
5 .....	J257000 .....	1/4-20 Nylon Jam Locknut
6 .....	K250001 .....	1/4 Flat Washer
7 .....	R000453 .....	Flat Washer
8 .....	3707647 .....	Door Safety Switch Coded Magnet
9 .....	3708458 .....	Sharp Warning Decal
10 .....	3708675 .....	3/16 Blind Rivet
11 .....	3708820 .....	Button Head Safety Screw #8-32 x 1/2 Long
12 .....	3708855 .....	Extension Spring
13 .....	3708857 .....	Black Pull Handle
14 .....	6059013 .....	Front Outside Window
15 .....	6059029 .....	Front Center Hinge
16 .....	6059030 .....	Front End Hinge
17 .....	6059036 .....	Center Window Support
18 .....	6059044 .....	Spring Cover Sleeve
19 .....	6059021 .....	Door Safety Switch (Front)
20 .....	6059066 .....	Bottom Window Support
21 .....	6059067 .....	Top Window Support
22 .....	6059068 .....	Short Window Support
23 .....	6059069 .....	Front RH Window Frame Weldment
24 .....	6059072 .....	Front LH Window Frame Weldment
25 .....	6309038 .....	Door Bracket
26 .....	6329046 .....	Front Inside Window
27 .....	6329071 .....	Window Retainer/ Switch Mount
28 .....	6329512 .....	Front RH Inside Window Frame Weldment
29 .....	6329513 .....	Front LH Inside Window Frame Weldment




**PARTS LIST****6329544 REAR SLIDE UP GUARD DOOR ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B190613 .....	Button Head Socket Cap Screw 10-24 x 3/8 Long
2 .....	B251016 .....	Button Head Socket Cap Screw 1/4-20 x 5/8 Long
3 .....	B250816 .....	Button Head Socket Cap Screw 1/4-20 x 1/2 Long
4 .....	B372016 .....	Button Head Socket Cap Screw 3/8-16 x 1-1/4 Long
5 .....	B372416 .....	Button Head Socket Cap Screw 3/8-16 x 1-1/2 Long
6 .....	J167000 .....	8-32 Lock Nut Jam
7 .....	J197000 .....	10-24 Lock Nut Jam
8 .....	J257100 .....	1/4-20 Lock Nut
9 .....	J377000 .....	3/8-16 Lock Nut Jam
10 .....	K370001 .....	3/8 Flat Washer
11 .....	K371501 .....	3/8 Lock Washer
12 .....	K160001 .....	No. 8 Flat Washer
13 .....	6329135 .....	Rear Door Slide
14 .....	6329551 .....	Slide Up Rear Door Weldment
15 .....	6329136 .....	Rear Slide Spacer Plate
16 .....	K251501 .....	1/4 Lock Washer
17 .....	3708819 .....	8-32 x .75 Button Head Safety Screw
18 .....	3708992 .....	Folding Handle
19 .....	3708997 .....	Compression Spring .24 OD x 1.5 Long
20 .....	3708998 .....	Wave Spring .35 ID
21 .....	6209165 .....	Lower Guide Bar
22 .....	6329029 .....	Hinged Walker Panel
23 .....	3708869 .....	Spring Hinge
24 .....	6329127 .....	Door Safety Switch Key
25 .....	6329128 .....	Door Key Housing
26 .....	6329131 .....	Catch
27 .....	6329132 .....	Catch Bracket
28 .....	6329133 .....	Catch Pin
29 .....	6329134 .....	Catch Spacer Plate



<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	B251001	Hex Head Cap Screw 1/4-20 x 5/8
2	B251011	Socket Head Cap Screw 1/4-20 x 5/8
3	B310813	Button Head Socket Cap Screw 5/16-18 x 1/2
4	B311213	Button Head Socket Cap Screw 5/16-18 x 3/4
5	B371211	Socket Head Cap Screw 3/8-16 x 3/4
6	B502801	Hex Head Cap Screw 1/2-13 x 1 3/4
7	B504801	Hex Head Cap Screw 1/2-13 x 3
8	B506801	Hex Head Cap Screw 1/2-13 x 4.25
9	H371602	Roll Pin .375 Dia. x 1 Long
10	H372002	Roll Pin .375 Dia. x 1 1/4 Long
11	J317100	5/16-18 Locknut
12	J507100	1/2-13 Locknut
13	K251501	1/4 Split Lockwasher
14	K310001	5/16 Flat Washer SAE
15	K311501	5/16 Split Lockwasher
16	K371501	3/8 Split Lockwasher
17	K500001	1/2 Flat Washer SAE
18	R000453	Flat Washer (.88 OD x .31 ID x .104 T)
19	3707595	7/8" Hole Plug
20	3708419	Wave Spring
21	3708421	Flat Washer (1.0 OD x .75 ID x .08T)
22	3708542	5/8" Hole Plug
23	3708612	Fuel Warning Decal
24	3708867	Swell Latch
25	3709372	1/2" Hole Plug
26	6309111	Decal - Up/Down
27	6309039	Gage Pin Mounting
28	6329098	Vac Door
29	3707601	Proximity Switch Head
30 a	6329075	LH Traverse Proximity Switch Cord
30 b	6329076	RH Traverse Proximity Switch Cord
31	3707459	Proximity Switch Nut
32	6329501	Cabinet Weldment
33	6329504	Front Panel Weldment
34	6329525	Traverse Base Assembly (see page 64)
35	6329535	Mower Support Assembly (see page 78)
36	6509035	Cross slide Mount
37	6509389	Tooling Bar Shim
38	6509465	Spin Drive Assembly (see page 80)
39	6509510	Tooling Bar Weldment
40	6509560	Proximity Switch Bracket Weldment RH
41	6509561	Proximity Switch Bracket Weldment LH
42	J992000	1-8 Hex Jam Nut
43	A993201	Adjustable Leveling Bolt
44	6509039	Right-Hand Access Panel
45	6509040	Left-Hand Access Panel - Small
46	B250816	1/4-20 x 1/2 Button Head Socket Cap Screw
47	50382	Hinge
48	3659083	Bumper
49	3708458	Warning Decal - Sharp
50	B370816	3/8-16 x 1/2 Button Head Socket Cap Screw







# PARTS LIST

# 6329525 TRAVERSE BASE ASSEMBLY

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B190611 .....	Socket Head Cap Screw 10-24 x 3/8 Long
2 .....	B191211 .....	Socket Head Cap Screw 10-24 x 3/4 Long
3 .....	B250616 .....	Button Head Socket Cap Screw 1/4-20 x 3/8 Long
4 .....	B250811 .....	Socket Head Cap Screw 1/4-20 x 1/2 Long
5 .....	B250818 .....	Pan Head Machine Screw 1/4-20 x 1/2 Long
6 .....	B250819 .....	Button Head Socket Cap Screw 1/4-20 x 1/2 Long
7 .....	B251211 .....	Socket Head Cap Screw 1/4-20 x 3/4 Long
8 .....	B251411 .....	Socket Head Cap Screw 1/4-20 x 7/8 Long
9 .....	B252011 .....	Socket Head Cap Screw 1/4-20 x 1 1/4 Long
10 .....	B253211 .....	Socket Head Cap Screw 1/4-20 x 2 Long
11 .....	B256411 .....	Socket Head Cap Screw 1/4-20 x 4 Long
12 .....	B310813 .....	Button Head Socket Cap Screw 5/16-18 x 1/2 Long
13 .....	B311611 .....	Socket Head Cap Screw 5/16-18 x 1 Long
14 .....	B503211 .....	Socket Head Cap Screw 1/2-13 x 2 Long
15 .....	C250420 .....	Socket Head Set Screw Cup Point 1/4-20 x 1/4 Long
16 .....	H184002 .....	3/8 Diameter Roll Pin x 2 1/2 Long
17 .....	J257000 .....	1/4-20 Nylon Locknut Thin
18 .....	J257100 .....	1/4-20 Nylon Locknut
19 .....	J627200 .....	5/8-18 Nylon Locknut Thin
20 .....	J757300 .....	3/4-16 Nylon Locknut
21 .....	K191501 .....	No. 10 Washer
22 .....	K250001 .....	1/4 Flat Washer SAE
23 .....	K251501 .....	1/4 Split Lockwasher
24 .....	K311501 .....	5/16 Split Lockwasher
25 .....	K501501 .....	1/2 Split Lockwasher
26 .....	R000376 .....	Square Key 1/8 x 3/4 Long
27 .....	R000377 .....	Square Key 3/16 x 3/4 Long
28 .....	28192 .....	Traverse Pulley Support
29 .....	50309 .....	Traverse Pulley Shaft
30 .....	50354 .....	Drive Pulley (Cog)
31 .....	55553 .....	Idler Pulley Assembly
32 .....	80335 .....	Destaco Clamp
33 .....	80354 .....	Cog Belt
34 .....	80355 .....	Thrust Washer (1 1/4OD x 3/4 ID)
35 .....	3708195 .....	External Retaining Ring
36 .....	3708419 .....	Wave Spring (.78 ID)
37 .....	3708436 .....	Wave Spring
38 .....	3708658 .....	Compression Spring
39 .....	3708884 .....	Spacer 5/8 OD x 9/32 ID x 3/8 Long
40 .....	3709044 .....	Linear Ball Bearing




<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
41 .....	3709072 .....	Compression Spring
42 .....	3709331 .....	External Retaining Ring
43 .....	6059062 .....	Traverse Motor Assembly
44 .....	6309573 .....	Finger & Body Assembly (see page 74)
45 .....	6329032 .....	Traverse Base
46 .....	6329034 .....	5/8 Shaft Coupler
47 .....	6329035 .....	Motor Extension Shaft 6.00 Long (Prior to 8-08)
.....	6329141 .....	Motor Extension Shaft 5.75 Long (After 8-08)
48 .....	6329036 .....	Pulley Mount Bracket
49 .....	6329507 .....	Prox Flag Bracket Weldment
50 .....	6329511 .....	Shaft Support Block Assembly
51 .....	6329526 .....	Grinding Head Assembly (see page 70)
52 .....	6329527 .....	Carriage Assembly (see page 72)
53 .....	6509020 .....	Traverse Base Adjuster End Cap
54 .....	6509021 .....	Bellows Bracket Carriage Mount
55 .....	6509025 .....	Bellows Bracket End Mount
56 .....	6509054 .....	Plunger Pin Retainer
57 .....	6509055 .....	Belt Cover
58 .....	6509063 .....	Carrier Shaft
59 .....	6509210 .....	Belt Cover Gasket
60 .....	6509221 .....	Traverse Base Fixed Bracket
61 .....	6509238 .....	Grinding Wheel Grip Knob
62 .....	6509250 .....	Bellows - Way cover
63 .....	6509253 .....	Carriage Dust Cover Bracket
64 .....	6509484 .....	Plunger Pin
65 .....	6509565 .....	Cross Slide Assembly (see page 68)




**PARTS LIST****6509565 CROSS SLIDE ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	C311220 .....	Socket Set Screw CPPT 5/16-18 x 3/4 Long
2 .....	J371000 .....	3/8-16 Hex Nut
3 .....	J377000 .....	3/8-16 Hex Jam Nylon Locknut
4 .....	K371501 .....	3/8 Split Lockwasher
5 .....	3579109 .....	3/16 Dia. Nylon Plug
6 .....	3708148 .....	Handwheel 4.5 Dia. .38 Bore
7 .....	3709062 .....	Bell V Washer .75 O. D. x .035 T
8 .....	3709304 .....	Thrust Washer
9 .....	3708705 .....	Adjustable Handle 5/16-18 Female - Orange
10 .....	6509390 .....	Adjusting ACME Shaft
11 .....	6009035 .....	Locking Stud Shaft
12 .....	6009082 .....	Cross Slide Support
13 .....	6009095 .....	Slide Shaft
14 .....	6509011 .....	Cross Slide
15 .....	6509015 .....	Cross Slide Horizontal support
16 .....	C310820 .....	Socket Set Screw 5/16-18 x 5/8 Long
17 .....	3708665 .....	Flat Washer
18 .....	6309115 .....	Grey Decal
19 .....	6309114 .....	Orange Decal
20 .....	6309113 .....	5/16-18 Locking Stud
21 .....	3708706 .....	Adjustable Handle 5/16-18 Female - Grey
22 .....	3969065 .....	Spacer .406 ID x .75 OD x 1.0 Long
23 .....	B372011 .....	Socket Head Cap Screw 3/8-16 x 1 1/4 Long
24 .....	H371602 .....	Rollpin 3/8 Dia. x 1 Long
25 .....	K371501 .....	3/8 Split Lockwasher
26 .....	6509010 .....	Traverse Base Adjuster Bracket




**PARTS LIST****6329526 GRINDING HEAD ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B251411 .....	Socket Head Cap Screw 1/4-20 x 7/8 Long
2 .....	B371611 .....	Socket Head Cap Screw 3/8-16 x 1 Long
3 .....	C250627 .....	Socket Set Screw Cup Pt 1/4-20 x 3/8 Long - Lock Patch
4 .....	K250001 .....	1/4 Flat Washer SAE
5 .....	K251501 .....	1/4 Split Lockwasher
6 .....	K371501 .....	3/8 Split Lockwasher
7 .....	R000376 .....	Square Key 1/8 x 3/4 Long
8 .....	3707690 .....	1 HP 120 VAC Motor
9 .....	3708193 .....	Conical Washer 1.36 OD x .88 OD
10 .....	3708194 .....	Internal Retaining Ring
11 .....	3708204 .....	Double Row Ball Bearing
12 .....	3708202 .....	Poly-V Belt
13 .....	6329089 .....	Bearing Sleeve
14 .....	6329041 .....	Motor Mount Plate
15 .....	6329042 .....	Pulley - Poly V 1.80 Diameter
16 .....	6329100 .....	Pulley - Poly V 1.44 Diameter
17 .....	6509018 .....	Grinding Head Housing
18 .....	J567200 .....	9/16-18 Locknut Nylon Insert Jam
19 .....	6329523 .....	Grinding Head Spindle Assembly
20 .....	6509237 .....	Grinding Wheel Knob
21 .....		Grinding Wheel (see page 83)
22 .....	3708870 .....	Retaining Ring - External .50 Shaft Heavy Duty






<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B250616 .....	Button Head Cap Screw 1/4-20 x 3/8 Long
2 .....	B252016 .....	Button Head Cap Screw 1/4-20 x 1 1/4 Long
3 .....	B253216 .....	Button Head Cap Screw 1/4-20 x 2 Long
4 .....	K251501 .....	1/4 Split Lockwasher
5 .....	J252000 .....	1/4-20 Jam Nut
6 .....	J887300 .....	7/8-14 Nylon Jam Locknut
7 .....	R602031 .....	#4 x .31 Drive Screw
8 .....	28187 .....	Traverse Clamp Block
9 .....	28188 .....	Traverse Clamp Spacer Plate
10 .....	28189 .....	Clamp Support Block
11 .....	50310 .....	Belt Clamp Tip
12 .....	3708105 .....	Compression Spring
13 .....	3708184 .....	Retaining Ring
14 .....	3708186 .....	Ball Bearing
15 .....	3708208 .....	Shoulder Bolt .250 Dia. x .387 Long
16 .....	3708462 .....	Decal - RPM, Symbol
17 .....	6329040 .....	Traverse Clamp
18 .....	6329058 .....	Carriage Base
19 .....	6509023 .....	Grinder Head Pivot Shaft
20 .....	6509251 .....	Swing Door Latch
21 .....	6509584 .....	Swing Door Weldment



## PARTS LIST


## 6309573 FINGER AND BODY ASSEMBLY

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B190631 .....	Socket Head Cap Screw 10-32 x 3/8 Long
2 .....	B190634 .....	Button Head Socket Cap Screw 10-32 x 3/8 Long
3 .....	B251011 .....	Socket Head Cap Screw 1/4-20 x 5/8 Long
4 .....	B254811 .....	Socket Head Cap Screw 1/4-20 x3 Long
5 .....	C190460 .....	Socket Set Screw 10-24 x 1/4
6 .....	C190467 .....	Socket Set Screw - Nylok Cup 10-32 x .25 Long
7 .....	C190860 .....	Socket Set Screw - CP-PT 10-32 x 1/2 Long
8 .....	C190860 .....	Socket Set Screw - 10-32 x 1/2 Long
9 .....	H122002 .....	Roll Pin 1/8 Dia. x 1 1/4 Long
10 .....	H250813 .....	Dowel Pin 1/4 Dia. x .5 Long
11 .....	H253202 .....	Drive Lock Pin 1/4 x 1.75 Long
12 .....	J191100 .....	10/32 Hex Nut
13 .....	J377200 .....	3/8-24 Jam Nylok Locknut
14 .....	K191501 .....	No. 10 Lock Washer
15 .....	R000351 .....	Square Key .093 x .75 Long
16 .....	3579284 .....	1/8 Dia. Nylon Plug
17 .....	3709304 .....	Thrust Washer
18 .....	3708107 .....	Compression Spring
19 .....	3708175 .....	Compression Spring
20 .....	3708199 .....	3/8-16 Dia. Split Shaft Collar
21 .....	3709472 .....	Straight Grease Fitting
22 .....	6509432 .....	Relief Finger
23 .....	6509004 .....	Reel Finger Slide
24 .....	6509357 .....	Reel Finger Positioner
25 .....	6509007 .....	Index Stop Pin
26 .....	6509008 .....	Index Sensor Block
27 .....	6509009 .....	Slide Washer
28 .....	6509058 .....	Eccentric Index Pin
29 .....	6509060 .....	Gib Stop Plate
30 .....	6509215 .....	Adjustable Index Lever
31 .....	6509229 .....	Locking Index Finger Pin
32 .....	3579284 .....	1/8" Diameter Nylon Plug
33 .....	6509239 .....	Anti Rotation Plate
34 .....	6509258 .....	Dovetail Gib
35 .....	6509501 .....	Tee Knob Assembly
36 .....	6509547 .....	Knob Assembly
37 .....	6329592 .....	Index Finger Assembly
38 .....	6329593 .....	Index Lock Handle Weldment
39 .....	6509592 .....	Index Finger Positioner Weldment
40 .....	H120402 .....	1/8" Diameter x 1/4" Long Pin Roll
41 .....	6509358 .....	Stop Plate
42 .....	6509356 .....	Reel Positioner Adjuster




**PARTS LIST****6309574 STEPPER & MOUNTING ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B161811 .....	Socket Head Cap Screw 8-32 x 1 1/8 Long
2 .....	B252011 .....	Socket Head Cap Screw 1/4-20 x 1 1/4 Long
3 .....	C250825 .....	Socket Set Screw 1/4-20 x 1/2
4 .....	C251020 .....	1/4-20 x 5/8" Set Screw
5 .....	6309500 .....	DC Motor/Reducer Assembly
6 .....	J377200 .....	3/8-24 Nylok Jam Locknut
7 .....	K161501 .....	#8 Split Lockwasher
8 .....	3708187 .....	Ball Bearing
9 .....	3708189 .....	Retaining Ring
10 .....	3708192 .....	Hose Clamp 2.25 Dia.
11 .....	3709304 .....	Thrust Washer
12 .....	6509048 .....	Hex Pivot Pin
13 .....	6509051 .....	Trunion Block
14 .....	6509056 .....	Bellows, 1.88 I.D.
15 .....	6309052 .....	Actuator Motor Mounting Bracket
16 .....	6309053 .....	Calibration ring
17 .....	B191611 .....	Socket Head Cap Screw 10-24 x 1" Long
18 .....	K191501 .....	#10 Lockwasher
19 .....	B160407 .....	8-32 x 1/4 Button Head Socket Cap Screw
20 .....	3708424 .....	Retaining Ring Ext. 1.75
21 .....	6509384 .....	Infeed Stepper Assembly
22 .....	3708629 .....	Split Shaft Collar .25 I.D.
23 .....	6309055 .....	Window
24 .....	C250420 .....	1/4-20 x 1/4 Socket Set Screw
25 .....	C160420 .....	8-32 x 1/4 Socket Set Screw
26 .....	6309040 .....	Adapter
27 .....	6509381 .....	Base Cover Plate
28 .....	B190613 .....	Socket Head Cap Screw 10-24x 3/8 Long




**PARTS LIST****6329535 MOWER SUPPORT ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B190614 .....	Pan Head Machine Screw 10-24 x 3/8 Long
2 .....	K191501 .....	No.10 Lockwasher
3 .....	6009577 .....	Knob Assembly
4 .....	3708364 .....	Quick Release Pin .31 Dia.
5 .....	3708158 .....	Shoulder Bolt .375 Dia. x .50 Long
6 .....	3708366 .....	6" type B Lanyard
7 .....	6509128 .....	Horizontal Scale Decal RH
8 .....	6329072 .....	Vertical Scale Decal
9 .....	6509507 .....	Bar Mounting Weldment Bracket
10 .....	6509517 .....	L.H. Front Roller Horiz. Weldment Bracket
11 .....	6329587 .....	L. H. Roller Clamp Weldment Bracket
12 .....	6509559 .....	Knob Assembly
13 .....	6509564 .....	L.H. Front Roller Clamp Weldment
14 .....	6509588 .....	Knob Assembly
15 .....	6509515 .....	R.H. Front Roller Horiz. Weldment Bracket
16 .....	6329586 .....	R.H. Roller Clamp Weldment Bracket
17 .....	3709304 .....	Thrust Washer
18 .....	B311211 .....	Socket Head Cap Screw 5/16-18 x 3/4 Long
19 .....	K311501 .....	5/16 Lockwasher
20 .....	70512 .....	Rear Roller Support Bracket Weldment
21 .....	C500861 .....	1/2-20 x 1/2 Flat Pt Socket Head Set Screw
22 .....	6509576 .....	R.H. Front Roller Clamp Weldment
23 .....	3708881 .....	Rear Clamp
24 .....	6329514 .....	Rear Clamp Base Weldment
25 .....	6509304 .....	Horizontal Scale Decal LH





<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	6329155 .....	Gearmotor, DC (Spin)
4 .....	3709586 .....	Flange Coupler .50
5 .....	3709585 .....	Sleeve Coupler
6 .....	3709584 .....	Flange Coupler 5/8
7 .....	6009217 .....	Drive Coupling Adapter
9 .....	09394 .....	Tee Knob Assembly
10 .....	3709073 .....	Retaining Ring
11 .....	6009051 .....	Drive Adapter 1/2 Square
12 .....	6009052 .....	Adapter
13 .....	R000376 .....	Square Key 1/8 x .75 Long
14 .....	6009078 .....	Gearbox Slide Bracket
15 .....	3707279 .....	Strain Relief Wire
16 .....	6009079 .....	Gearbox Clamp Bracket
17 .....	6009580 .....	Gearbox Slide Weldment Bracket
18 .....	3708262 .....	T-Knob - 5/16-18
19 .....	6009045 .....	Linkage Spacer 2.29 Long
20 .....	6009046 .....	Linkage Spacer R.H. Thread
21 .....	3709062 .....	Belleville .75 Dia. x .35 T
22 .....	3709809 .....	Shoulder Bolt .375 Dia. x .375 Long
23 .....	3709705 .....	Nylon Ball 5/32 Dia.
24 .....	C310420 .....	Socket Set Screw 5/16-18 x 1/4
25 .....	6009047 .....	Linkage spacer L. H. Thread
26 .....	6009048 .....	Linkage Spacer 2.5 Long
27 .....	B375611 .....	Socket Head Cap Screw
28 .....	J377100 .....	Nylok Hex Locknut 3/8-16
29 .....	6509519 .....	Support Bracket Weldment
30 .....	3708148 .....	Handwheel 4.5 Dia.
31 .....	3709370 .....	Handle
32 .....	J252000 .....	Hex Jam Nut 1/4-20
33 .....	J257000 .....	1/4-20 Nylok Locknut
34 .....	C310620 .....	Socket Set Screw 5/16-18 x 3/8 Long
35 .....	6009076 .....	Double Thread Rod
36 .....	6009555 .....	Knob Assembly
37 .....	6509114 .....	Spin Drive Plate Lock
38 .....	6009067 .....	Geared Linkage
39 .....	B255011 .....	Socket Head Cap Screw 1/4-20 x 3 1/8 Long
40 .....	R000377 .....	Square Key 3/16 x .75 Long




## PARTS LIST (Continued)

## 6329529 MISCELLANEOUS PARTS

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	3700088 .....	Grinding Wheel 3.5" Dia. x .38 Wide
2 .....	3700086 .....	Grinding Wheel 3.5" Dia. x 1" Wide
3 .....	3700087 .....	Grinding Wheel 5" Dia. x .38" Wide
4 .....	3700089* .....	Grinding Wheel 5" Dia. x 1" Wide
5 .....	R000863 .....	5/16 Allen Key
6 .....	K251501 .....	1/4 Lockwasher
7 .....	80396 .....	T-Knob Assembly
8 .....	3529069 .....	Space
9 .....	6329555 .....	Alignment Extension Weldment
10 .....	6329518 .....	Gage Bar Weldment
11 .....	6509349 .....	Retaining Plate
12 .....	6509418 .....	Plate-Pivot
13 .....	3708094 .....	Adjustable Handle 5/16-18 x 1.25 Long
14 .....	3708894 .....	T-Knob Assembly
15 .....	B120611 .....	Socket Head Cap Screw 5-40 x .38 Long
16 .....	B161011 .....	Socket Head Cap Screw 8-32 x 5/8 Long
17 .....	J161000 .....	8-32 Hex Nut
18 .....	K121501 .....	No. 5 Split Lockwasher
19 .....	K161501 .....	No. 8 Lockwasher
20 .....	6509359 .....	Digital Gage
.....	3707712 .....	Battery Cover - Digital Gage
21 .....	6329556 .....	Base Weldment Indicator
22 .....	H060302 .....	1/16 x 3/16L Roll Pin
23 .....	B190811 .....	Socket Head Cap Screw 10-24 x 1/2
24 .....	J197100 .....	10-24 Nylok Locknut
25 .....	3708384 .....	Magnet
26 .....	6509474 .....	Reel Positioner Gage
27 .....	6509557 .....	Drip Pan Weldment

\* 3700089- Grinding wheel is installed on grinding head when shipped. The other wheels are located in the carton assembly.



**PARTS LIST****6329554 CONTROL PANEL ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	B190834 .....	Button Head Cap Screw 10-32 x 1/2 Long
2 .....	B250816 .....	Button Head Cap Screw 1/4-20 x 1/2 Long
3 .....	D250800 .....	Thread Cutting Screw 1/4-20 x 1/2 Long
5 .....	J257000 .....	1/4-20 Nylon Jam Locknut
6 .....	R000536 .....	1/4 Lock Washer
7 .....	3707075 .....	Toggle Switch Boot
8 .....	3707080 .....	Toggle Switch
9 .....	3707342 .....	Yellow Emergency Stop Ring
10 .....	3707367 .....	Rocker Switch DPST
11 .....	3707428 .....	Rocker Switch Momentary (On-Off-On)
12 .....	3707429 .....	Rocker Switch DPDT
13 .....	3707443 .....	4-Amp Circuit Breaker
14 .....	3707446 .....	Potentiometer Knob
15 .....	3707547 .....	15-Amp Circuit Breaker
16 .....	3707564 .....	Green Start Push-button
17 .....	3707565 .....	Normally Open Contact Block
18 .....	3707566 .....	Switch Mounting Latch
19 .....	3707567 .....	Push/Pull Red Emergency Stop Button
20 .....	3707568 .....	Normally Closed Contact Block
21 .....	6329054 .....	Control Panel Decal
22 .....	6329528 .....	Control Panel Top Weldment
23 .....	6329070 .....	Hinge
24 .....	6329509 .....	Control Box Weldment
25 .....	6329553 .....	Electrical Panel Sub-Assembly
26 .....	6509446 .....	Potentiometer Assembly - Spin Speed
27 .....	6509447 .....	Potentiometer Assembly - Relief Torque
28 .....	6059050 .....	Potentiometer Assembly - Traverse Speed

**Cords Not Shown**

.....	6329078 .....	Main Power Cord
.....	6329079 .....	Infeed Motor Cord
.....	6329080 .....	Light Receptacle Cord
.....	6329081 .....	Dust Collector Receptacle Cord
.....	6329124 .....	Sliding Door Safety Switch Cord
.....	3707224 .....	Cable Tie Mount (used throughout machine)
.....	3707225 .....	Cable Tie 6.5 Long x .18 Wide
.....	3707255 .....	Cable Tie 4.0 Long x .10 Wide




**PARTS LIST****3707774 & 6329553 CONTROL PANEL SUB-ASSEMBLY**

<u>DIAGRAM NUMBER</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1 .....	D160666 .....	Pan Head Self-Tapping Screw #8 x 3/8 Long
2 .....	D161266 .....	Pan Head Self-Tapping Screw #8 x 3/4 Long
3 .....	R000480 .....	#8 Lockwasher
4 .....	55223 .....	Terminal Strip Decal
5 .....	3707073 .....	8-Pin socket
6 .....	3707163 .....	Primary Ground Decal
7 .....	3707164 .....	Primary Ground Lug
8 .....	3707378 .....	14" Din Rail
9 .....	3707764 .....	Power Line Filter 20 Amp
10 .....	3707550 .....	Traverse Control Board
11 .....	3707556 .....	Magnetic Starter
12 .....	3707688 .....	High/Low Voltage Sensor Relay
13 .....	3707625 .....	Screwless Terminal Block End Stop
14 .....	3707626 .....	Terminal Block Jumper
15 .....	3707627 .....	Terminal Block End Plate
16 .....	3707628 .....	2-Conductor Terminal Block - Grey
17 .....	3707629 .....	2-Conductor Terminal Block - Blue
18 .....	3708920 .....	Low Voltage Warning Decal
19 .....	6009270 .....	Electrical Sub Panel
20 .....	80259 .....	20-Amp Circuit Breaker
21 .....	3707706 .....	19 Pole Terminal Strip
22 .....	3707707 .....	Double Spade Terminal
23 .....	3707709 .....	Single Spade Terminal 90°
24 .....	3707708 .....	Double Spade Terminal 90°
25 .....	3707624 .....	Ground Terminal Block
26 .....	3707779 .....	6 Amp Circuit Breaker
27 .....	3707781 .....	Infeed Transformer Assembly
28 .....	3707524 .....	Spin/Relief Control Board
29 .....	3707526 .....	25-Amp Bridge Diode
30 .....	3707594 .....	Voltage Regulator Assembly
31 .....	3707602 .....	6" Din Rail
32 .....	3707328 .....	Door Safety Switch Monitor
33 .....	3707741 .....	Flat Single Spade
34 .....	3707742 .....	90° Single Spade
35 .....	3707333 .....	24 VDC Power Supply

# 6324553 WIRING DIAGRAM


- BD1 - BRIDGE DIODE 1
- CB1 - CIRCUIT BREAKER 1 15AMP
- CB2 - CIRCUIT BREAKER 2 4AMP
- DSS1 - FRONT DOOR SAFETY SWITCH
- DSS2 - REAR DOOR SAFETY SWITCH
- ESS - EMERGENCY STOP SWITCH
- FTR - LINE FILTER
- GMS - GRINDING MOTOR SWITCH
- IJS - INFEEED JOG SWITCH
- ISS - INFEEED SPEED SWITCH
- LVR - LOW VOLTAGE RELAY
- MAG - MAGNETIC STARTER
- PWR - 24V POWER SUPPLY
- PX1 - RIGHT PROXIMITY SWITCH
- PX2 - LEFT PROXIMITY SWITCH
- REL - GRINDING MOTOR RELAY
- RTP - RELIEF TORQUE POT
- SCB - SECONDARY CIRCUIT BREAKER
- SDC - SPIN DRIVE CONTROL
- SMS - SPIN MOTOR SWITCH
- SRS - SPIN ROTATION SWITCH
- SSM - SAFETY SWITCH MONITOR
- SSP - SPIN SPEED POT
- SSS - SYSTEM START SWITCH
- STS - SPIN/TORQUE SELECTOR SWITCH
- TB1 - TERMINAL STRIP 1
- TB2 - TERMINAL STRIP 2
- TBG - TRERMINAL BLOCK GREY
- TBW - TERMINAL BLOCK BLUE
- TDC - TRAVERSE DRIVE CONTROL
- TMS - TRAVERSE MOTOR SWITCH
- TRF - TRANSFORMER
- TSP - TRAVERSE SPEED POT
- VRA - VOLTAGE REGULATOR ASSEMBLY







# 632 WIRING SCHEMATIC



- BD1 - BRIDGE DIODE 1
- CB1 - CIRCUIT BREAKER 1 15 AMP
- CB2 - CIRCUIT BREAKER 2 4 AMP
- DSS1 - FRONT DOOR SAFETY SWITCH
- DSS2 - REAR DOOR SAFETY SWITCH
- ESS - EMERGENCY STOP SWITCH
- FTR - LINE FILTER
- GMS - GRINDING MOTOR SWITCH
- IJS - INFEED JOG SWITCH
- ISS - INFEED SPEED SWITCH
- LVR - LOW VOLTAGE RELAY
- MAG - MAGNETIC STARTER
- PWR - 24V POWER SUPPLY
- PX1 - RIGHT PROXIMITY SWITCH
- PX2 - LEFT PROXIMITY SWITCH
- REL - GRINDING MOTOR RELAY
- RTP - RELIEF TORQUE POT
- SCB - SECONDARY CIRCUIT BREAKER
- SDC - SPIN DRIVE CONTROL
- SMS - SPIN MOTOR SWITCH
- SRS - SPIN ROTATION SWITCH
- SSM - SAFETY SWITCH MONITOR
- SSP - SPIN SPEED POT
- SSS - SYSTEM START SWITCH
- STS - SPIN/TORQUE SELECTOR SWITCH
- TB1 - TERMINAL STRIP 1
- TB2 - TERMINAL STRIP 2
- TBG - TRERMINAL BLOCK GREY
- TBW - TERMINAL BLOCK BLUE
- TDC - TRAVERSE DRIVE CONTROL
- TMS - TRAVERSE MOTOR SWITCH
- TRF - TRANSFORMER
- TSP - TRAVERSE SPEED POT
- VRA - VOLTAGE REGULATOR ASSEMBLY