

FOLEY

▶ COMPANY

ACCU-Master 653

ACCU-Pro 633

AUTO - INDEX

SPIN / RELIEF

REEL MOWER GRINDER

with **ACCU-Touch 3**

ORIGINAL INSTRUCTIONS

Patent No. 6,010,394

6,290,581 & 6,685,544

SERVICE MANUAL

 **WARNING**

You must thoroughly read and understand this manual before assembling or maintaining the equipment, paying particular attention to the Warning & Safety Instructions.



IMPORTANT SAFETY MESSAGE



As manufacturers of sharpening equipment, we want to confirm to you, our customers, our concern for safety. We also want to remind you about the simple, basic, and common sense rules of safety when using this equipment. Failure to follow these rules can result in severe injury or death to operators or bystanders.

It is essential that everyone involved in the assembly, operation, transport, maintenance, and storage of this equipment be aware, concerned, prudent, and properly trained in safety. Always use proper shielding and personal protective equipment as specified by the manufacturer.

Our current production machines include, as standard equipment, guards or shields for the grinding wheel, safety signs, and operators and service manuals. Never bypass or operate the machine with any of the guards or safety devices removed or without the proper personal safety equipment.

Read and fully understand all the safety practices discussed in this manual and the Operator's Manual. All safety rules must be understood and followed by anyone who works with reel grinders.

Before operating this grinder, an operator must read and understand all of the information in the operators manual and understand all of the safety signs attached to the product. A person who has not read or understood the Operator's Manual and safety signs is not qualified to operate the unit. Accidents occur often on machines that are used by someone who has not read the operators manual and is not familiar with the equipment. If you do not have an operators manual or current production safety signs, contact the manufacturer or your dealer immediately.

The equipment is designed for one-man operation. Never operate the equipment with anyone near, or in contact with, any part of the grinder. Be sure no one else, including bystanders, are near you when you operate this product.

Follow these simple, basic safety rules, as well as others, including:

- Find and understand all safety signs in the operators manual and on the equipment. This will help minimize the possibility of accidents and increase your productivity in using this product.
- Be careful and make sure that everyone who operates the grinder knows and understands that it is a very powerful piece of machinery, and if used improperly, serious injury or death may result. The final responsibility for safety rests with the operator of this machine.

Throughout this manual, the following safety symbols will be used to indicate the degree of certain hazards.



This symbol is used throughout this manual to call attention to the safety procedures.

 **DANGER**

The word **DANGER** indicates an immediate hazardous situation, which if not avoided, will result in death or serious injury.

 **WARNING**

The word **WARNING** indicates a potential hazardous situation, which if not avoided, could result in death or serious injury.

 **CAUTION**

The word **CAUTION** preceded with a safety alert symbol indicates a potential hazardous situation which, if not avoided, may result in minor or moderate injury.

TABLE OF CONTENTS

| | |
|------------------------------------|---------|
| Safety Message..... | 2 |
| Safety Instructions..... | 3 -6 |
| Service Data and Adjustments | 7 - 21 |
| Trouble-shooting | 22 - 29 |
| Parts Diagrams..... | 30 - 71 |
| Wiring Diagrams..... | 72 - 75 |
| Wiring Schematics | 75 - 81 |
| PLC Input & Output Lights | 82 |

Read the Operator's Manual before operating this equipment. Keep this manual handy for ready reference. Require all operators to read this manual carefully and become acquainted with all adjustments and operating procedures before attempting to operate the equipment. Replacement manuals can be obtained from your selling dealer or the manufacturer.

The equipment you have purchased has been carefully engineered and manufactured to provide dependable and satisfactory use. Like all mechanical products, it will require cleaning and upkeep. Lubricate and clean the unit as specified in the Operator's Manual. Please observe all safety information in this manual, the Operator's Manual and the safety decals on the equipment.



This machine is designed for sharpening reel type mower ONLY. Any use other than this may cause personal injury and void the warranty.

To assure the quality and safety of your machine and to maintain the warranty, you MUST use original equipment manufacturer's replacement parts and have any repair work done by a qualified professional.

ALL operators of this equipment must be thoroughly trained BEFORE operating the equipment.

Do not use compressed air to clean grinding dust from the machine. This dust can cause personal injury as well as damage to the grinder.



INSTALLATION, DAILY MAINTENANCE, AND BASIC UPKEEP IS DISCUSSED IN THE OPERATOR'S MANUAL. THIS MANUAL SHOULD BE USED IN CONJUNCTION WITH THE OPERATOR'S MANUAL FOR PERFORMING SERVICE ON THIS EQUIPMENT.

SAFETY INSTRUCTIONS

WARNING

TO AVOID INJURY, READ AND UNDERSTAND THE SAFETY ITEMS LISTED BELOW. IF YOU DO NOT UNDERSTAND ANY PART OF THIS MANUAL AND NEED ASSISTANCE, CONTACT YOUR LOCAL DEALER.

1. **KEEP GUARDS IN PLACE** and in working order.
2. **REMOVE WRENCHES AND OTHER TOOLS.**
3. **KEEP WORK AREA CLEAN.**
4. **DON'T USE IN DANGEROUS ENVIRONMENT.**
Don't use grinder in damp or wet locations. Machine is for indoor use only. Keep work area well lit.
5. **KEEP ALL VISITORS AWAY.** All visitors should be kept a safe distance from work area.
6. **MAKE WORK AREA CHILD-PROOF** with padlocks or master switches.
7. **DON'T FORCE THE GRINDER.** It will do the job better and safer if used as specified in this manual.
8. **USE THE RIGHT TOOL.** Don't force the Grinder or an attachment to do a job for which it was not designed.
9. **WEAR PROPER APPAREL.** Wear no loose clothing, gloves, neckties, or jewelry which may get caught in moving parts. Nonslip footwear is recommended. Wear protective hair covering to contain long hair. Wear respirator or filter mask where appropriate. Wear protective gloves.
10. **ALWAYS USE SAFETY GLASSES.**
11. **SECURE YOUR WORK.** Make certain that the cutting unit is securely fastened with the clamps provided before operating.
12. **DON'T OVERREACH.** Keep proper footing and balance at all times.
13. **MAINTAIN GRINDER WITH CARE.** Follow instructions in Service Manual for lubrication and preventive maintenance.
14. **DISCONNECT POWER BEFORE SERVICING,** or when changing the grinding wheel.
15. **REDUCE THE RISK OF UNINTENTIONAL STARTING.** Make sure the switch is OFF before plugging in the Grinder.
16. **USE RECOMMENDED ACCESSORIES.** Consult the manual for recommended accessories. Using improper accessories may cause risk of personal injury.
17. **CHECK DAMAGED PARTS.** A guard or other part that is damaged or will not perform its intended function should be properly repaired or replaced.
18. **NEVER LEAVE GRINDER RUNNING UNATTENDED. TURN POWER OFF.** Do not leave grinder until it comes to a complete stop.
19. **KNOW YOUR EQUIPMENT.** Read this manual carefully. Learn its application and limitations as well as specific potential hazards.
20. **KEEP ALL SAFETY DECALS CLEAN AND LEGIBLE.** If safety decals become damaged or illegible for any reason, replace immediately. Refer to replacement parts illustrations in Service Manual for the proper location and part numbers of safety decals.
21. **DO NOT OPERATE GRINDER WHEN UNDER THE INFLUENCE OF DRUGS, ALCOHOL, OR MEDICATION.**

SAFETY INSTRUCTIONS



WARNING

IMPROPER USE OF GRINDING WHEEL MAY CAUSE BREAKAGE AND SERIOUS INJURY.

GRINDING IS A SAFE OPERATION IF THE FEW BASIC RULES LISTED BELOW ARE FOLLOWED. THESE RULES ARE BASED ON MATERIAL CONTAINED IN THE ANSI B7.1 SAFETY CODE FOR "USE, CARE AND PROTECTION OF ABRASIVE WHEELS". FOR YOUR SAFETY, WE SUGGEST YOU BENEFIT FROM THE EXPERIENCE OF OTHERS AND CAREFULLY FOLLOW THESE RULES.

DO

1. **DO** always **HANDLE AND STORE** wheels in a **CAREFUL** manner.
2. **DO VISUALLY INSPECT** all wheels before mounting for possible damage.
3. **DO CHECK MACHINE SPEED** against the established maximum safe operating speed marked on wheel.
4. **DO CHECK MOUNTING FLANGES** for equal and correct diameter.
5. **DO USE MOUNTING BLOTTERS** when supplied with wheels.
6. **DO** be sure **WORK REST** is properly adjusted.
7. **DO** always **USE A SAFETY GUARD COVERING** at least one-half of the grinding wheel.
8. **DO** allow **NEWLY MOUNTED WHEELS** to run at operating speed, with guard in place, for at least one minute before grinding.
9. **DO** always **WEAR SAFETY GLASSES** or some type of eye protection when grinding.

DON'T

1. **DON'T** use a cracked wheel or one that **HAS BEEN DROPPED** or has become damaged.
2. **DON'T FORCE** a wheel onto the machine **OR ALTER** the size of the mounting hole - if wheel won't fit the machine, get one that will.
3. **DON'T** ever **EXCEED MAXIMUM OPERATING SPEED** established for the wheel.
4. **DON'T** use mounting flanges on which the bearing surfaces **ARE NOT CLEAN, FLAT AND FREE OF BURRS.**
5. **DON'T TIGHTEN** the mounting nut excessively.
6. **DON'T** grind on the **SIDE OF THE WHEEL** (see Safety Code B7.2 for exception).
7. **DON'T** start the machine until the **WHEEL GUARD IS IN PLACE.**
8. **DON'T JAM** work into the wheel.
9. **DON'T STAND DIRECTLY IN FRONT** of a grinding wheel whenever a grinder is started.
10. **DON'T FORCE GRINDING** so that motor slows noticeably or work gets hot.



WARNING

AVOID INHALATION OF DUST generated by grinding and cutting operations. Exposure to dust may cause respiratory ailments. Use approved NIOSH or MSHA respirators, safety glasses or face shields, and protective clothing. Provide adequate ventilation to eliminate dust, or to maintain dust level below the Threshold Limit Value for nuisance dust as classified by local codes.

SERVICE DATA

WARNING



UNPLUG THE EQUIPMENT PRIOR TO DOING ANY SERVICE ON THIS EQUIPMENT. FAILURE TO REMOVE POWER TO THIS EQUIPMENT BEFORE SERVICING MAY RESULT IN INJURY OR DEATH.

IF POWER IS REQUIRED FOR TESTING OR TROUBLESHOOTING, THIS SHOULD BE PERFORMED BY A TRAINED PROFESSIONAL OR LICENSED ELECTRICIAN.

REVIEW THE SYMBOLS AND DESCRIPTIONS ON PAGES 10 AND 11 OF THE OPERATOR'S MANUAL. UNDERSTAND ALL SYMBOLS BEFORE OPERATING OR SERVICING THIS EQUIPMENT.



This is the electrical hazard symbol. It indicates that there are **DANGEROUS HIGH VOLTAGES PRESENT** inside the enclosure of this product. TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, do not attempt to open the enclosure or gain access to areas where you are not instructed to do so. **REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.**

IMPORTANT GROUNDING INSTRUCTIONS

If electrical testing is required, always verify the machine has a proper ground before performing any tests.

In case of a malfunction or breakdown, grounding reduces the risk of electrical shock by providing a path of least resistance for electrical current.

This Grinder has an electrical cord with an equipment grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded according to all local or other appropriate electrical codes and ordinances.

Before plugging in the Grinder, make sure it will be connected to a supply circuit protected by a properly sized circuit breaker or fuse. SEE SERIAL NUMBER PLATE FOR FULL LOAD AMP RATING OF YOUR MACHINE.

Never modify the plug provided with the machine--if it won't fit the outlet, have a proper outlet and circuit installed by a qualified electrician.

WARNING

ALWAYS PROVIDE A PROPER ELECTRICAL GROUND FOR YOUR MACHINE. AN IMPROPER CONNECTION CAN CAUSE A DANGEROUS ELECTRICAL SHOCK. IF YOU ARE UNSURE OF THE PROPER ELECTRICAL GROUNDING PROCEDURE, CONTACT A QUALIFIED ELECTRICIAN.

SERVICE DATA

SKILL AND TRAINING REQUIRED FOR SERVICING

This Service Manual is designed for technicians who have the necessary mechanical and electrical knowledge and skills to reliably test and repair the this Spin/Relief Grinder. For those without the background, service can be arranged through your local distributor.

This section presumes that you are already familiar with the normal operation of the grinder. If not, you should read the operators manual, or do the servicing in conjunction with someone who is familiar with its operation.

WARNING

Persons without the necessary knowledge and skills should not remove any panels or shields, or attempt any internal troubleshooting, adjustments, or parts replacement.

If you have questions not answered in this manual, please contact your distributor.

TORQUE REQUIREMENTS

Throughout this manual we refer to torque requirements as "firmly tighten" or the like. For more specific torque values, refer to the information below.

Bolts Going Into a Nut, or Into a Thread Hole in Steel.

Refer to the Table at the right.

Bolts Going Into a Thread Hole In Aluminum

Use the Grade 2 Values in the Table at the right.

Socket-Head Screws Going Into a Nut or Steel




Use the Grade 8 Values in the Table at the right.

Machine Screws

No. 6 screws: 11 in.- lbs (0.125kg - m)

No. 8 screws: 20 in. - lbs (0.23 kg - m)

No. 10 screws: 32 in. - lbs (0.37 kg - m)

| | GRADE 2 | GRADE 5 | GRADE 8 |
|----------------------------|---|---|---|
| |  SMOOTH HEAD |  3 MARKS on HEAD |  6 MARKS on HEAD |
| 1/4 In. thread | 6 ft-lbs (0.8 kg-m) | 9 ft-lbs (1.25 kg-m) | 13 ft-lbs (1.8 kg-m) |
| 5/16 In. thread | 11 ft-lbs (1.5 kg-m) | 18 ft-lbs (2.5 kg-m) | 28 ft-lbs (3.9 kg-m) |
| 3/8 In. thread | 19 ft-lbs (2.6 kg-m) | 31 ft-lbs (4.3 kg-m) | 46 ft-lbs (6.4 kg-m) |
| 7/16 In. thread | 30 ft-lbs (4.1 kg-m) | 50 ft-lbs (6.9 kg-m) | 75 ft-lbs (10.4 kg-m) |
| 1/2 In. thread | 45 ft-lbs (6.2 kg-m) | 75 ft-lbs (10.4 kg-m) | 115 ft-lbs (15.9 kg-m) |

PERIODIC MAINTENANCE

DAILY MAINTENANCE IS SPECIFIED ON PAGE 5 OF THE OPERATOR'S MANUAL, AND IS TO BE PERFORMED BY THE OPERATOR.

LISTED BELOW ARE PERIODIC MAINTENANCE ITEMS TO BE PERFORMED BY YOUR COMPANY'S MAINTENANCE DEPARTMENT:

1. Clean the tank and filter of the vacuum system weekly or more often depending on the number of reels ground. (Vacuum system is optional equipment on the 633.)

2. Inspect the grinding wheel poly-V belt for cracking and adjust the belt tension per procedure called out in the adjustment section every six months.

3. Wipe and re-lube the vertical and horizontal alignment shafts and lead screws with Never-Seez™ every six months. See FIG. 1.

4. Lift the bellows and wipe off the bearing rails monthly. To lubricate linear bearing, follow the lubrication procedure on the following pages. Generally, this will be every six months to a year.

5. Wipe and re-oil the index finger adjustment screw with spray lubricant every 3 months. Wipe off excess lubricant.

6. Check the traverse belt for cracking, uneven wear or other defects every 6 months to a year.

7. Clean the indicator rod on the Accu-Positioning Gauge. Wipe with a clean rag until the unit moves smoothly. Generally, this will be every six months to a year.




FIG. 1




FIG. 2

PERIODIC MAINTENANCE

STORAGE PROCEDURE

It is important to follow the procedures below when placing your grinder in storage for an extended period of time. Proper care will help maintain the working functions of the grinder and decrease maintenance and problems that occur when storing the grinder.

BEFORE STORING THE GRINDER:

-Clean the machine thoroughly.

DO NOT USE COMPRESSED AIR OR A POWER WASHER TO CLEAN THIS MACHINE!

-Lubricate the following parts by flooding the area with a spray lubricant and leaving it in place:

DO NOT USE A TEFLON BASED LUBRICANT!

1. Traverse Shafts & Linear bearings (see Lubrication Section of manual).
2. Remove grinding wheel and spray the movable parts of the finger system.
3. Cross slide shafts and adjustment screws (Right side of Traverse Base).
4. Scratches in the paint or any other bare metal surfaces.

-Work the lubricant in by moving parts through their full range of motion.

-Make sure all controls are in the OFF position and unplug the unit from the wall.

-Cover the unit if possible with a sheet or tarp.

BRINGING THE UNIT BACK INTO SERVICE:

-Remove the cover and reapply lubricant to the items stated above. Wipe off all excess lubricant. (See Lubrication section for more details.)

-Plug the unit into the wall and test all electrical functions.

-Check the belts for cracking and adjust the tension if necessary.

-Check for damaged or missing parts.

LUBRICATION


LUBRICATION OF LINEAR BEARINGS

STEP 1--Thoroughly clean the shafts.

STEP 2--Flood spray the two shafts with a spray lubricant (**do not use a Teflon based lubricant**) until the lubricant is dripping off the shafts. See FIG. 3 Then run the carriage back and forth through its full range of travel, this will carry the lubricant into the bearings.

STEP 3--With a clean rag, wipe off the excess amount of lubricant from the shafts. Run the carriage back and forth through its full range of travel and wipe the shafts after each traverse. Repeat until the shafts are dry to the touch.

If the unit will be shut down for an extended period of time (more than four weeks) the shafts and other appropriate parts of the unit should be flooded with lubricant and that lubricant left in place until the unit is brought back into service. When the unit is brought back into service the full lubrication procedure as stated above should be repeated.



ADJUSTMENTS

CARRIAGE LINEAR BEARING REPLACEMENT

STEP 1--Detach the bellows mounting brackets from the carriage. Detach front and rear shields. See FIG. 5.

STEP 2--Remove the three screws of to remove one of the linear bearing. Slide the linear bearing off the end of the carriage shaft.

STEP 3--Insert a new linear bearing onto the end of the carriage shaft with the tension adjustment screw pointing outward. See FIG. 4. Adjust the tension screw of the linear bearing so when you radially rotate the linear bearing around the carriage shaft there should be no free play between the linear bearing and the carriage shaft.

NOTE: Tension is too tight if you feel a cogging action when you rotate the linear bearing around the shaft. This cogging is from the skidding of the bearing on the shaft and indicates tension screw is too tight.

Finally, sliding the bearing block back and forth should be a smooth uniform motion.

SETTING THE BEARING TENSION CORRECTLY IS CRITICAL TO PROPER GRINDING. BEARINGS WHICH ARE TOO TIGHT OR TOO LOOSE WILL CAUSE POOR GRIND QUALITY. ALSO, BEARINGS WHICH ARE TOO TIGHT WILL HAVE SUBSTANTIALLY SHORTER LIVES AND MAY DAMAGE THE SHAFT.

STEP 4--Slide linear bearing under carriage and reinstall the three screws.

Repeat Steps 2 thru 4 with the other three linear bearings.

STEP 5 -Position a dial indicator assembly on the machine grinding head assembly next to the bearing to be tested. The dial indicator should be within 1" of the side of the grinding head carriage directly above the bearing being tested. It is best to use a wide flat tip on the end of the dial indicator.

- Insert Bearing Testing Fork 3706055 until the fork contacts the wiper bracket or the bearing.

-With the tip of the dial indicator on the traverse shaft, zero out the Dial Indicator.

-Use your hand and press down on the end of the bearing tester fork until it contacts the traverse rail. See FIG. 5. Read the movement on the dial indicator. If the movement exceeds .003" the bearing needs to be adjusted. Retest the bearing after adjusting the tension on the bearing. If the bearing does not improve to below the .003" reading then the bearing needs to be replaced.

Repeat Step 5 for the other three bearings.

STEP 6--Reattach the shaft bellows and reinsert the plugs in the front and rear dust shields. See FIG. 6.

Dial Indicator must be positioned over the bearing being tested and located within 1" of the side of the carriage base.





FIG. 5

If dial reads more than .003" of movement, adjust bearing tension using the tension screw. See FIG. 4.

Press down on Bearing Tester Fork and Read Dial.



FRONT DUST SHIELD

REAR DUST SHIELD

FIG. 6

ADJUSTMENTS

RELIEF ASSEMBLY INDEX FINGER ADJUSTING KNOB AND FREE-PLAY SETSCREWS.

If the index finger stop position is moving during grinding, adjust the tightness of the nylon plug to the knob assembly threads. The tightness has to be sufficient so the knob assembly does not rotate during grinding cycle. See FIG 7.

If the finger assembly does not move freely or has too much free-play when loosened, Adjust the 2 nylon tip set screws on the side of the assembly. FIG. 8

NOTE: To adjust the nylon plug you must allow the index finger to travel to its furthest UP position.




FIG. 7




FIG. 8

GRINDING HEAD BELT TENSION ADJUSTMENT

The left side grip grinding wheel knob must be removed for belt tensioning adjustment. Remove the screws holding the vacuum hose bracket, the two double tube clamps and the belt cover. For grinding motor belt adjustment, loosen the four socket head cap screws that attach the motor mounting plate. Adjust the grinding motor for proper belt tension and tighten the four socket head cap screws. Proper belt tension is achieved when 5 lbs of force applied to the belt halfway between the two pulleys results in .12" (3 mm) of deflection. See FIG 9.

To verify belt tension mount the belt guard with two screws. Turn the motor on. If the belt is tensioned correctly, start-up torque of the motor through the pulley to the belt should have zero slippage. If there is belt slippage there will be a slight squeal before the belt comes up to speed. When you achieve correct tension, reassemble all of the remaining parts that have been removed.




FIG. 9


ADJUSTMENTS

INDEX FINGER SENSOR SETTING

Press the machine system start switch, so the grinder is operational.


Push down on the index finger until the stop pin is within .06 inches (1.5 mm) of bottoming out. (You can use a 1/16" gauge pin or rod stock between the stop pin and index finger). Set the proximity switch to activate the light at this setting. This assures the index finger to be close to its final stop position so the reel is completely indexed before the carriage starts to traverse. See FIG. 10.

The spring load force pushing up on the index finger brings it away from the proximity when released.



STEPPER INFEEED TRAVEL LIMITS

The infeed stepper maximum extension is 6.0" (152 mm) and minimum compression is 3.5" (89 mm). If you experience a situation where the grind does not properly finish, check that you have not exceeded stepper travel by checking the values per FIG. 11.




ADJUSTMENTS

TRAVEL LIMITS

For the TRAVEL LIMITS to perform properly and reverse the direction of the carriage at each end of the rails, a distance of $3/16"$ [4 mm] to $1/4"$ [6 mm] needs to be maintained between the limit sensor bracket and the TRAVEL LIMIT. See FIG. 12.

NOTE: the light on the TRAVEL LIMIT switch activates when metal crosses in front of the switch.




$3/16"$ [4 mm] to $1/4"$ [6mm]

FIG. 12

ADJUSTABLE RELIEF TENSION

If the relief angle appears to vary during relief grinding adjust the tension on the nylon plug and set screw. See FIG. 13.



SET SCREW WITH
NYLON PLUG

FIG. 13

SAFETY SWITCH ALIGNMENT

For the safety switches to work properly they must be adjusted so the sender and receiver are parallel to each other with a maximum gap of .19 inches (5 mm). A special wrench is needed to adjust the safety screws used to hold the switch in place.




FIG. 14

ADJUSTMENTS

SPIN MOTOR ADJUSTMENT

If the spin drive motor is moving during operation, or does not move freely into position, adjust the tension of the 2 T-Handles. See FIG. 15.

T-HANDLES



FIG. 15

TRAVERSE BELT TENSION

To adjust the tension on the traverse belt, tighten the screws and nuts located at the left side of the traverse belt. Tighten the nuts until the compression springs measure $3/4$ " [19mm]. See FIG. 16. If the springs are not tensioned equally, uneven loading on the traverse system may cause parts to fail.

DO NOT OVERTIGHTEN. OVERTIGHTENING COULD DAMAGE THE BELT OR TRAVERSE DRIVE SYSTEM.




FIG. 16

TRAVERSE CLAMP FORCE

If the traverse clamp is slipping during regular operation it may be necessary to tighten the clamp. To tighten, loosen the jam nut on the clamp tip. Screw the tip out so there is $.10$ " gap between the tip and the Clamp Support Block. See FIG 17. Lock in place by tightening the jam nut against the clamp being careful not to move the tip. Verify the distance between the clamp tip and block is still $.10$ ". The $.10$ " setting allows slippage in a jam situation and damage can occur if this adjustment is set to narrow.

CAUTION SHOULD BE USED AS ADJUSTING THE TIP WILL AFFECT THE SLIP LOAD AND COULD DAMAGE THE CLAMP TIP, BELT OR TRAVERSE DRIVE SYSTEM.




FIG. 17

ADJUSTMENTS

ADJUSTING CROSS SLIDE ASSEMBLY

If the cross slide becomes very difficult to turn it may become necessary to adjust the assembly. To relieve the tension on the assembly follow the procedure listed below:

STEP 1—Turn the vertical handwheel on the cross-slide counter-clockwise to raise the carriage base up until you are able to slide a piece of wood or metal (such as two 2 x 4s) under the carriage base. Be sure to insert this on the seam of the floor pan under where the right side leg is welded. Release the pressure on the cross slide by lowering the base until the base is supported by the wood/metal piece and the pressure on the cross slide is removed.

STEP 2—Knock out the pins on either side of the mounting frame adjuster and loosen the 4 bolts (B504801) that connect the carriage mounting bracket to the frame of the grinder.

STEP 3—Turn the Vertical handwheel clockwise to raise the cross slide assembly, this will put a preload on the cross slide assembly to the up position.

STEP 4—Tighten the 4 bolts on the Carriage Mounting Frame to 75 ft-lbs.

STEP 5-- Turn the vertical handwheel counter-clockwise to raise the carriage base and remove the wood/metal support (example: the two 2 x 4s). Test the vertical and horizontal handwheels for ease of movement through their full range of motion.

STEP 6—If the cross slides tend to bind, repeat above steps 3-5 above until the handwheels move freely through there full range of travel.

STEP 7—when the cross slides move freely drill new holes and repin the assembly.




FIG. 18

ADJUSTMENTS

CROSS SLIDE SHAFT REPLACEMENT

If the cross slide shafts become scarred or gnarled, replace them by the following procedure:

STEP 1--Turn the vertical handwheel on the cross-slide counter-clockwise to raise the carriage base up until you are able to slide a piece of wood or metal (such as two 2 x 4s) under the carriage base. Be sure to insert this on the seam of the floor pan under where the right side leg is welded. Release the pressure on the cross slide by lowering the base until the base is supported by the wood/metal piece and the pressure on the cross slide is removed.

STEP 2--Loosen the two nuts on the support casting that hold the locking stud and tap the ends of the studs with plastic or rubber hammer to loosen.

STEP 3--Loosen the lock handles and tap the center of the handle with a plastic hammer to loosen.

STEP 4--Loosen locknut and setscrew on the handwheels and remove.

STEP 5--Remove the Slide Shafts.

STEP 6--Remove all burrs and resurface the shaft to a clean, smooth, polished surface. (OR REPLACE WITH A NEW SHAFT.)

STEP 7--Coat the shaft with Never-Seez™ and re-install the shaft through the Support, Cross Slide Block and the three locking studs. The shaft must move freely inside the Cross Slide Block before reassembling.

STEP 8--Retightening the nuts at the end of the locking studs to lock shaft in place.

STEP 9--Reinstall the Handwheel by snugging the setscrew to the flat located on the screw shaft, now tighten the nut until tight then back the nut off by 1/2 turn. Tighten the setscrew to 70 in-lbs.

STEP 10--Test the Cross Slide, the handwheel should turn freely.

STEP 11-- Turn the Vertical Handwheel to raise the Carriage Base and remove the wood/metal supports (two 2 x 4s). Test the vertical and horizontal handwheels for ease of movement through their full range of motion. If binding occurs, follow the procedure under Cross Slide Assembly located on the previous page.

NOTE: it is also possible to remove the complete Cross Slide Assembly and do the repairs on a bench then reinstall.




FIG. 19




FIG. 20

MACHINE SERVICE

REPLACEMENT OF GRINDING HEAD SHAFT & BEARINGS

Remove grinding wheel and grinding wheel knob. The Grinding Head Spindle Assembly consists of the grinding head spindle and a ball bearing press fit together. The left side ball bearing is slip fit on the opposite end. To replace the spindle assembly remove the left side grinding wheel grip knob, square key and belt cover. See FIG. 21. Loosen the 4 socket head cap screws on the motor plate to remove the poly-V belt. Loosen the 2 set screws on the spindle pulley and remove the pulley, square key and pulley spacer. Push on the right hand side of the spindle assembly to compress conical washers so there is no pressure on the shaft retaining ring. Using a retaining ring pliers remove the small external retaining ring from the spindle assembly. You can now remove the spindle assembly out the right side by lightly tapping on the left end with a rubber mallet. The second ball bearing can be removed from the belt side of the Grinding Head Housing.

To reassemble place the 4 conical washers (2 Pair nested and then place the 2 pairs back to back) against the ball bearing on the new spindle assembly. See FIG. 22. Thoroughly clean the housing bore and the outside diameter of both bearings. **APPLY BLUE LOCTITE #243 TO THE OUTSIDE DIAMETER OF THE TWO BEARINGS.** Slide the spindle assembly into the right side of the Grinding Head Housing. Install the bearing sleeve against the bearing on the spindle assembly. Slip fit the new left side ball bearing onto the spindle assembly and into grinding head housing. **APPLY BLUE LOCTITE #243 TO THE INSIDE THREAD OF THE 9/16-18 NUT** and install onto the spindle shaft with the grooved side toward the bearing onto the spindle shaft and using a spanner wrench on the right side of the spindle and a 7/8 deep-well socket on the left side, torque the locknut to 15 Ft/Lbs.

APPLY BLUE LOCTITE #243 TO THE BORE OF THE PULLEY BEFORE INSTALLATION. Replace the square key and install the new pulley pushing the counter-bore side of the pulley against the spindle nut with no end play. **NEXT INSTALL BLUE LOCTITE #243 ON THE PULLEY SETSCREWS AND TIGHTEN THE TWO PULLEY SET SCREWS.** Then install the new external retaining ring on the spindle shaft. Mount the new poly-V belt. (See Grinding Head Belt Tension and Alignment Adjustments in the adjusting section of the manual). Install the new belt cover gasket on the belt cover and install the belt cover and square key. Mount the left side grinding wheel grip knob with a slight gap to the cover and tighten the two set screws.




FIG. 21



FIG. 22

MACHINE SERVICE

TRAVERSE DRIVE CONTROL BOARD (TDC)

The Traverse Drive Control Board has nine potentiometers and four switches as shown on drawing 6524511 which is included. These potentiometers and switches have been set at the factory to the positions shown on the drawing. Also see FIG. 23 and FIG. 24.

Fwd Accel & Rev Accel---FWD ACC & REV ACC

The potentiometer is factory preset to the minimum full counterclockwise 8:30 position. This position turns the Acceleration/Deceleration off for this application.

Maximum Speed---MAX SPD

The maximum speed potentiometer is preset to position for 90 Volts DC output to the traverse motor at terminals A1 and A2.

IR Compensation---IR COMP

The IR Comp control is preset to 3:00 position. Never adjust past the 4:30 position.

Regulation of the traverse motor may be improved by slight adjustment of the IR COMP trim pot clockwise from its factory set position. Overcompensation causes the motor to oscillate or to increase speed when fully loaded. If you reach such a point, turn the IR COMP trim pot counterclockwise until the symptoms just disappear.

Rev Torque---REV TQ

The Reverse Torque setting determines the maximum current limit for driving the motor in the reverse direction. The potentiometer is preset to the 10:30 position. It should not require adjustment.

Fwd Torque---FWD TQ

The Forward Torque setting determines the maximum current limit for driving the motor in the forward direction. The potentiometer is preset to

the 10:30 position. It should not require adjustment.
Deadband---DB

This motor control board has a potentiometer which must be set for 50 HZ or 60 HZ operation. For 60 HZ set to 3:00 position. For 50 HZ set to 9:00 position.

Minimum Speed---MIN SPD

The potentiometer is factory preset to the minimum full counterclockwise 8:30 position.

Tach---TACH

The tach potentiometer is not used in this application. It should be a the factory setting of 8:30.

Armature Switch---ARMATURE 90-180

This switch is factory preset to the 90 position for a 90 VDC motor..

Feedback Switch--- FEEDBACK ARM-TACH

This switch is factory preset to the ARM position.

The lower control board has two switches. Both switches are factory preset to 115 for 115 VAC operation.





FIG. 23



Potentiometer Clock Orientation




FIG. 24

Terminal ends (Feet) are always at the 6:00 position, no matter how the potentiometer is orientated on the board.

MACHINE SERVICE

SPIN DRIVE CONTROL BOARD (SDC)

The Spin Drive Control Board has four potentiometers, two switches and one dial as shown on FIG. 24. These potentiometers, switches and dial have been set at the factory to the positions shown on FIG. 24.

Relief Grinding Mode

The Torque Shut Off mode selector allows you to turn on or off the Torque Shut Off feature. When switch 1 is set to ON, the board will decrease the spin motor torque once the shut time is achieved after leaving the right proximity sensor. The amount of time it takes before the torque is decreased is set with the Torque Shut Off Delay dial. The spin motor torque will be increased to the higher value once the right proximity switch is activated again. If the Torque Shut Off selector is in the OFF position the torque will remain constant during relief grinding.

Torque Shut Off Delay dial is used to set the duration of time before the torque is decreased after leaving the right proximity sensor during relief grinding. If the dial is turned clockwise (higher number) the higher torque value will stay on for a longer period of time.

The Relief Speed (RSP) and the Relief Torque Pot (RTP) interact with each other. The (RSP) is located on the spin board as a remote speed preset at 12:00 (20 Volts DC). See FIG. 24. The (RTP) is located on the control panel and is for relief torque adjustment.

Relief Speed Pot (RSP) when rotated clockwise will increase spin drive speed (the speed at which the reel indexes to the next blade). This speed should never be above the 3:00 setting.

Relief Torque Pot (RTP) is used to vary the reel to finger holding torque for relief grinding. The recommended starting point is 30 in/lbs of torque setting. Never adjust the (RTP) potentiometer dial past the red line marking. Setting the reel to finger torque to high could cause the spin motor system to not operate smoothly.

Relief Idle Torque Pot (ITP) is used to vary the reel to finger holding torque once the shut time is achieved after leaving the right proximity sensor if the Torque Shut Off Selector is set to ON.

Spin Grinding Mode

The Spin Torque Potentiometer (STP) and the Spin Speed Pot (SSP) interact with each other. The (STP) is located on the spin board as remote torque preset at 2:00 for torque setting. See FIG. 25. The (SSP) is located on the control panel and is for spin speed adjustment.

Spin Torque Pot (STP) controls maximum torque allowable in the spin grinding cycle only. This should never be adjusted past the 3:00 position. If the reel does not turn check that the reel is free turning by hand spinning with the power off and the spin drive disconnected.

The Spin speed Pot (SSP) controls reel spin speed, adjust as required. This controls the spin drive speed for spinning the reel.

IR COMP Pot

The IR Compensation is factory set at 9:00.

Regulation of the spin or relief grind spin motor may be improved by a slight adjustment of the IR COMP pot clockwise from its factory-set position. Overcompensation causes the motor to oscillate or to increase speed when fully loaded. If you reach such a point, turn the IR COMP pot counterclockwise until symptoms disappear.

MACHINE SERVICE

SPIN TORQUE POT (STP) 2:00

RELIEF SPEED POT (RSP) 12:00

DELAY SET TO 1

SWITCH 1 SET TO OFF





FIG. 25

IR COMP POT 9:00

IDLE TORQUE POT (ITP) 10:00

STEPPER INFEEED CONTROLLER (SIC)

The Stepper Infeed Controller has a set of 4 dip switches on the side SWB1-4 and 8 dip switches on the top SWA1-8 . See FIG. 26.

DIP SWITCH SETTINGS:

Switches SWB1-3 are on the side of the control and are used to select the motor type used.

- SWB1= ON
- SWB2=ON
- SWB3= OFF

Switch SWB4 located on the side and controls the LOAD INERTIA.

SWB4= ON

Switches SWA1- SWA8 are located on top:

Switch SWA1 can be used to preform a self test

SWA1 - OFF

Switch SWA2 selects the noise filter setting

SWA2 - ON

Switch SWA3 selects the IDLE CURRENT (on=50%, Off=90%)

SWA3 - ON

Switches SWA4-5 select the % Max Current

SWA4 - OFF

SWA5 - OFF

Switches SWA6-8 select the Steps/revolution.

SWA6 - ON

SWA7 - OFF

SWA8 - ON

SWITCHES ON SIDE

B-1,2,4 = ON

3 = OFF




FIG. 26

ELECTRICAL TROUBLESHOOTING

ACCU-TOUCH CONTROL PANEL




FIG. 27

ELECTRICAL TROUBLESHOOTING

ACCU-TOUCH CONTROL PANEL

1. Stepper Infeed Controller (SIC)
2. Output Control Relays (RYX)
3. Door Safety Switch Monitor (SSM)
4. Tiered Terminal Block (TT0- TT6)
5. Programmable Logic Controller (PLC)
6. Low Voltage Relay (LVR)
7. Main Circuit Breaker (MCB)
8. Magnetic Contactor (MAG)
9. Power Filter (FTR)
10. Terminal Blocks
 - (TBG) - GRIND MOTOR
 - (TBS) - SPIN MOTOR
 - (TBT) - TRAVERSE MOTOR
 - (TBF) - FLASHER
 - (TBW) - WINCH
 - (TBV) - VACUUM
 - (TBL) - LIGHT
11. Start Relay (SRL)
12. Grinding Motor Overload Relay
13. Grinding Motor Relay (REL)
14. Grey Terminal Blocks (GTX)
Blue Terminal Blocks (BTX)
15. Grind Motor Circuit Breaker (GCB)
16. Vacuum/Winch Circuit Breaker (VCB)
17. Traverse Drive Control Board (TDC)
18. Spin Drive Control Board (SDC)
19. Gauge/Spin Interface Board (GSI)
20. 24 VDC Power Supply (PWR)

ELECTRICAL TROUBLESHOOTING

SKILL AND TRAINING REQUIRED FOR ELECTRICAL SERVICING

This Electrical Troubleshooting section is designed for technicians who have the necessary electrical knowledge and skills to reliably test and repair the ACCU-Touch electrical system. For those without that background, service can be arranged through your local distributor.

This manual presumes that you are already familiar with the normal operation of the grinder. If not, you should read the Operator's Manual, or do the servicing in conjunction with someone who is familiar with its operation.

Persons without the necessary knowledge and skills should not remove the control box cover or attempt any internal troubleshooting, adjustments, or parts replacement.

If you have any question not answered in this manual, please call your distributor. They will contact the manufacturer if necessary.

WIRE LABELS

All wires on the ACCU-Master have a wire label at each end for assembly and troubleshooting. The wire label has a code which tells you wiring information. The first set of two or three numbers are the Foley wire number. The next group of letters or numbers are the code for the component to which the wire attaches. Example: RT1 for Relay Terminal 1. The last set of numbers or letters is the name of the terminal on the component to which the wire attaches.

TERMINAL BLOCKS:

To insert or remove a wire from the terminal block, insert a small screw driver into the square hole. Then insert or remove wire from the round hole. Remove screwdriver to lock the wire in place.

Note the square hole can also be used when checking for voltages. The probe tip of the multimeter can be inserted into the square hole to take readings.




FIG. 28

ELECTRICAL TROUBLESHOOTING

PROBLEM--Machine will not power up or is stuck in E-stop. In your Product Packet Assembly, there are a series of prints. Find the print titled ACCU-Touch Wiring Diagram, before starting the troubleshooting below. Verify all wires shown on that drawing are correct and pull on wire terminals with approximately 3 lbs force to verify there are no loose terminal connections and/or no loose crimps between wire and terminal. If loose terminals are found, retighten and retest system. If problem persists, test as listed below.

| Possible Cause | Checkout Procedure | |
|--|---|--|
| You must turn ON the Switch on the Side of the machine | A. Turn switch to the on Position. Look for screen to come on. | Machine works: Yes--End Trouble Shooting No-- Go go Step B. next |
| Main Power Cord is not plugged in | B. Plug in the main power cord | Machine works: Yes--End Trouble Shooting No-- Go go Step B. next |
| Building Circuit breaker has tripped | C. Check circuit breaker in building electrical panel. Reset if needed. (Check wall outlet to make sure it works.) | Machine works: Yes--End Trouble Shooting No--but a light works in the outlet. Go to step D. next No- Light does not work in outlet. Solve power issue to outlet. |
| No DC power in machine | D. Is the touch screen on? The E-stop Screen should be visible. | Touch screen is on E-stop screen : Yes--SKIP to step N No-- Touch Screen is not on. Go to Step E. next No-- touch screen is on but not on E-stop Screen. Verify PLC has power LED on PLC. REPLACE TCH to PLC cord. |
| Circuit breaker in machine has tripped | E. Check Main 20A Circuit breaker (MCB) to see if tripped. Turn off and on to reset. Look for Light on Low Voltage Monitor LVR. | Steady Red light on on LVR is on: Yes--SKIP to Step K. No-- No Light on LVR Go go Step F. next No-- LVR light is blinking SKIP to STEP Q. |
| Bad Fuse | F. Remove fuse and use meter to check continuity of Fuse. | Remove DC power Fuse on right side of machine. Check continuity of fuse. Replace if bad. Machine works: Yes--End Trouble Shooting No-- Go go Step G. next |
| Bad power cord | G. Check for power into Line Filter FTR. Check between input of main power cord brown to blue wire. | Measure 120VAC at output of main power cord . Remove wires(#32) if necessary. Measure between brown and blue wires on power cord. Yes--I have 120 VAC, go to Step H. next. No-- REPLACE Power Cord. 220VAC machines check/replace transformer |
| Bad Filter | H. Check for power out of of Line Filter FTR. Check between output terminals FTR | Measure 120VAC at output of FTR . Remove wires(#01 and #02) if necessary. Measure between tabs on filter. Yes--I have 120 VAC, go to Step I. next. No-- REPLACE Filter (FTR) |

ELECTRICAL TROUBLESHOOTING

Possible Cause

Checkout Procedure

| | | |
|--------------------------|--|---|
| Bad Main Circuit Breaker | I. Check for power out of of MCB. Check between output of MCB top screw and ground. | Measure 120VAC at output of MCB (wire 03MCB--) to Neutral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step J. next. No-- REPLACE Main Circuit Breaker (MCB) |
| Bad Power Switch | J. Check Power back from power switch at Grey Terminal Block 2. | Measure 120VAC at GT2 (wire #06) to Neutral (light blue wire from Line Filter - Wire #02). Use square hole in Grey Terminal Block GT2 : Yes--I have 120 VAC, go to Step K. next. No-- REPLACE Power Switch PSW |
| Bad Power Supply | K. Check Power LED light on Power Supply. If no Light then measure 120VAC at wires into Power Supply PWR | LED Light on PWR is ON? If not then Measure power into PWR for 120VAC at L (08PWR-L) to L2 (25PWRL2). Yes--LED light is on, go to Step L. next. No-- LED light is NOT on, but I have 120VAC at L and L2. - REPLACE PWR. |
| | L. Check power out of PWR. | Measure power out of PWR for 24VDC at V+ (92PWRV-) to V-(91PWRV+). Yes--I have 24VDC at PWR. Go to Step M. No--I do not have 24VDC at PWR. REPLACE PWR. |
| Bad Touch Screen | M. Open front control box. Check power into touch screen TCH. | Measure power into TCH for 24VDC at V+ (93TCHV+) to V- (94TCV-). Yes--I have 24VDC at TCH V+ TO V- . REPLACE TCH. No--I do not have 24VDC at TCH. REPLACE CORD to TCH |
| E-Stop Relay is off | N. Look for the LED light on Relay F. | LED Light on Relay F is ON? Yes--LED light is on, SKIP to Step R No-- LED light is NOT on. Go to Step O. next. |
| PLC issue | O. Look for LED light on right side of PLC next to YF. | LED Light on PLC next to YF is ON? Yes--LED light is on, REPLACE Relay terminal block F. Bad relay block No-- LED light is NOT on. Go to Step P. next. |
| | P. Look for LED light on right side of PLC next to X5. LVR input. | LED Light on PLC next to X5 is ON? Yes--LED light is on, Power off machine and restart. If problem is still there replace PLC. No-- LED light is NOT on. Go to Step Q. next. |
| LVR Tripped/Bad | Q. Look at LVR. If the light on the LVR is blinking press the reset button. | Was the LVR Blinking? A blinking LVR means the power to the machine is not adequate to run the machine. See operators manual for connecting power to this machine. Yes--LED light on LVR was blinking. Press reset. Fix power delivery issue . No-- LED light on LVR was NOT blinking. It is Steady RED. Replace LVR. No-- I do not have a Light on the LVR. No Light means the LVR has failed. REPLACE LVR. |

ELECTRICAL TROUBLESHOOTING

| Possible Cause | Checkout Procedure | |
|----------------------------|--|---|
| Relay F is bad | R. Check 120VAC out of Relay F. at terminal 11. | Measure 120VAC at output of relay F. Use the square hole on Relay to measure. Measure between Terminal 11 (11RYF11) to Nuetral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step S. next. No-- REPLACE relay YF. |
| Bad E-stop Contact | S. Check 120VAC back from Emergency Stop Switch ESS | Measure 120VAC from start relay terminal 24 (13SRL24)to Nuetral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step T. next. No-- Check wires going to and from ESS. REPLACE ESS contact block. |
| Bad Start Switch Contact | T. Check 120VAC back from System Start Switch SSS at MAG. Measure to Screw on MAG at T3 | Measure 120VAC from MAG terminal T3 (14MAGT3) to Nuetral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step U. next. No-- Check wires going to and from SSS. REPLACE SSS contact block. |
| Bad Y6NC relay | U. Press and hold the Green Start button and check for 120VAC out of RELAY Y6-NC. | Measure 120VAC from Y6-NC terminal11 (40RY6NC11) to Nuetral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step V. next. No--The light on RELAY Y6NC should be off. If not then reboot machine. REPLACE relay Y6NC if light is off and there is not 120VAC at terminal RY6NC terminal 11 |
| Bad Grind Motor Relay REL | V. Press and hold the Green Start button and check for 120VAC out of REL at terminal 22. Measure to Screw on REL at 22. REL should not be engaged. | Measure 120VAC from REL terminal11 (18REL22) to Nuetral (light blue wire from Line Filter - Wire #02): Yes--I have 120 VAC, go to Step W. next. No--I do not have 120 VAC. REPLACE Grind Motor Relay REL. |
| Bad Magnetic Starter (MAG) | W. Press and hold the Green Start button and check for 120 VAC at MAG coil A1 and A2. | Measure 120VAC from MAG terminal A1 (45MAGA1) to A2 (24MAGA2): Yes--I have 120 VAC, but MAG is not engaged (pulled in). REPLACE MAG STARTER No--I do not have 1120VAC. Check nuetral side of MAG (A2) to Brown wire on Filter. Check for loose wires to Terminal block Grey 5. |

ELECTRICAL TROUBLESHOOTING

PROBLEM--Machine will go back to E-stop after releasing the Green Start Button.

| Possible Cause | Checkout Procedure | |
|---|---|--|
| Bad SLR Relay | A. Press and hold Green Start button. Check for 120 VAC to Start Relay SRL at A1 and A2. | Check for 120 VAC from SRL A1 (44SRLA1) to A2 (22SRLA2) with Green Start button held in. Yes--I have 120 VAC at A1 to A2. Go to step B. Next No-- I do not have 120VAC from A1 to A2. Check Blue Terminal Block 1 and Grey Terminal Block 5. REPLACE wires if bad. |
| BAD SLR Relay or BAD MAG starter contact. | B. Release the Green start button. Remove Relay from SRL. To Remove, rotate arm holding relay into SRL until the relay pops up. Then pull out on relay to remove from terminal block. Then Press and hold Green Start Button and Check for 120 VAC at MAG L3. | Remove SRL relay and check for 120 VAC from MAG L3 (43 MAGL3) to Nuetral (light blue wire from Line Filter - Wire #02) with Green Start button held in. Yes--I have 120 VAC . REPLACE relay in SRL. No-- I do not have 120VAC, REPLACE MAG starter. |


ELECTRICAL TROUBLESHOOTING

PROBLEM-- Grind Motor is not working

| Possible Cause | Checkout Procedure | |
|--|--|---|
| Bad Signal | A. Press the Troubleshooting Icon on the start screen. Then press the arrow next to Grind Motor Troubleshooting. Shut the doors, then press and hold the Grind Motor Icon. | Grinding motor works. Yes--End Troubleshooting. No-- Grinding motor is not turning. Go to step B. next |
| Bad Control Relay | B. While pressing the Grind Motor Icon (see step A.). Check the indicators on the screen. Grinding motor control relay should be on. | When pushing the button the Grinding motor control relay (Y5) is: ON--Go to step C. next Off -- Turn off machine and reboot system. Retest, if still not functioning check PLC, Touch Screen, and cord connections and replace bad component. |
| | C. While pressing the Grind Motor Icon (see step A.). Check the indicators on the screen. Grinding motor relay should be on. | When pushing the button the Grinding motor Relay (REL) is: ON--Skip to step F. Off -- Go to step D. next |
| Bad Fuse | D. Release button on screen. Press Red E-stop Button in. Remove Fuse maked SPIN and Check fuse using Ohm meter. | When checked with an meter the fuse is good (0 Ohms from end to end): Yes --Go to step E. next No-- Replace fuse and test starting at step A. |
| Bad Control Relay Y5 | E. Reinstall fuse. Pull up on Red E-stop and press green reset button. Return to the Grinding Motor Troubleshooting Screen (see step A). Press and hold Grind Motor Icon and measure voltage into coil of Grind motor Relay (REL) A1 to A2 | Use meter to check for 120 VAC from Grind motor relay A1 (39REL1) to A2 (60REL2) while pressing icon. Is there 120 VAC from A1-A2? Yes --If Relay (REL) does not activate then replace REL. If it does activate then check signal wires #74 and #150 to PLC. No-- Replace Relay Y5. |
| Grinding Motor Circuit breaker has tripped | F. Flip Grinding motor Circuit breaker to reset. Retest - press icon on screen. | Reset circuit breaker (GCB). Machine works. Yes --End Troubleshooting. No-- go to step G. next |
| Grinding Motor Overload tripped | G. Press reset on Overload on bottom of Grinding Motor Relay (REL). | Reset Overload on REL. Machine works. Yes --End Troubleshooting. No-- go to step H. next |

PARTS LIST

6539523 FRONT DOOR ASSEMBLY- 653




PARTS LIST**6539523 FRONT DOOR ASSEMBLY- 653**

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B230611..... | M6 x 10 SOCKET HEAD CAP SCREW |
| 2..... | B251011..... | 1/4-20 x 5/8 SOCKET HEAD CAP SCREW |
| 3..... | B310113..... | 5/16-18 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B371216..... | 3/8-16 x 3/4 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | 3706231..... | 3/8-16 x 3 SOCKET HEAD CAP SCREW FULL THRD |
| 6..... | B374811..... | 3/8-16 x 3 SOCKET HEAD CAP SCREW |
| 7..... | J167000..... | 8-32 LOCKNUT JAM NUT |
| 8..... | J257100..... | 1/4-20 LOCKNUT FULL |
| 9..... | J311000..... | 5/16-18 HEX NUT FULL |
| 10..... | J317100..... | 5/16-18 LOCKNUT FULL |
| 11..... | J372000..... | 3/8-16 HEX JAM NUT |
| 12..... | J377000..... | 3/8-16 LOCKNUT JAM NUT |
| 13..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 14..... | 3969065..... | SPACER .406 ID x .750 |
| 15..... | 3706118..... | PUSH IN CABLE TIE |
| 16..... | 3706186..... | WINDOW GASKET |
| 17..... | 3706215..... | LEDGE HANDLE |
| 18..... | 3706247..... | SHOULDER BOLT .5 DIA x 2.5 LG |
| 19..... | 3706218..... | SHOULDER BOLT .38 DIA x 2.5 LG |
| 20..... | 3707908..... | DOOR SWITCH W/DISC |
| 21..... | 3706232..... | 3/8-16 x 4.5 SOCKET HEAD CAP SCREW |
| 22..... | 3708820..... | 8-32 x .50 BUTTON SAFETY HEAD |
| 23..... | 3706226..... | COMPRESSION SPRING .75 |
| 24..... | 3706052..... | FOAM SEAL ADHESIVE BACK |
| 25..... | 3708889..... | FOAM SEAL 50" |
| 26..... | 3709027..... | THRUST WASHER .507 x .917 OD |
| 27..... | 3709304..... | THRUST WASHER .375 x .812 OD |
| 28..... | 3708379..... | STRIP FOAM .50 THICK |
| 29..... | 6339039..... | DOOR PIVOT BRACKET |
| 30..... | 6339051..... | DOOR PIVOT ARM |
| 31..... | 6339202..... | UPPER DOOR PIVOT |
| 32..... | 6539007..... | WINDOW 18.5 x 36 |
| 33..... | 6539086..... | DOOR UPPER ARM |
| 34..... | 6539002..... | ACCU-MASTER 653 DECAL |
| 35..... | 6539057..... | FRONT DOOR BACK PANEL |
| 36..... | 6539088..... | DOOR SHIPPING BRACKET |
| 37..... | 6539521..... | 653 RH DOOR WELDMENT |
| 38..... | 6539522..... | 653 LH DOOR WELDMENT |
| 39..... | 6339524..... | DOOR PIVOT ARM WELDMENT |
| 40..... | 6539061..... | FRONT DOOR CORD - AT3 |

PARTS LIST

6539516 FIXED CABINET ASSEMBLY




PARTS LIST

6539516 FIXED CABINET ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|----------------------------------|
| 1..... | B311401..... | 5/16-18x7/8 HEX HEAD CAP SCREW |
| 2..... | B371216..... | 3/8-16x3/4 BUTTON HEAD CAP SCREW |
| 3..... | J311000..... | 5/16-18 HEX NUT FULL |
| 4..... | J371000..... | 3/8-16 HEX NUT |
| 5..... | K310001..... | FLAT WASHER 5/16 SAE |
| 6..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 7..... | K370001..... | FLAT WASHER 3/8 SAE |
| 8..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 9..... | 3706045..... | VACUUM MASTERCRAFT |
| | 3706046..... | VACUUM BAG (MASTERCRAFT 652) |
| | 3706067..... | GREY FILTER INNER BAG |
| | 3708874..... | SIZING ADAPTER |
| 10..... | 3707958..... | MACHINE LIGHT - LED |
| 11..... | 3708378..... | STRIP FOAM .25 THICK |
| 12..... | 3708675..... | RIVET - BLIND .188 DIAMETER |
| 13..... | 6529083..... | FOAM PAD CANOPY BACK WINCH |
| 14..... | 6539008..... | LEFT SIDE FRAME FOAM SHEET |
| 15..... | 6539009..... | RIGHT SIDE FRAME FOAM SHEET |
| 16..... | 6539013..... | TOP CANOPY FOAM SHEET |
| 17..... | 6539507..... | TOP WELDMENT |
| 18..... | 6539508..... | FIXED BACK WELDMENT |
| 19..... | 3706250..... | HOLE PLUG .375 DIAMETER BLACK |
| 20..... | 3706224..... | HOLE PLUG 1.13 DIAMETER |
| 21..... | 3706260..... | GROMMET 1 INCH |

PARTS LIST

6539517 SLOTTED TOP CABINET ASSEMBLY




PARTS LIST

6539517 SLOTTED TOP CABINET ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---|
| 1..... | B250816..... | 1/4-20 x 1/2 BUTON HEAD CAP SCREW |
| 2..... | B311201..... | 5/16-18 x 3/4 HEX HEAD CAP SCREW |
| 3..... | B371216..... | 3/8-16 x 3/4 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | J257100..... | 1/4-20 LOCKNUT |
| 5..... | J311000..... | 5/16-18 HEX NUT |
| 6..... | J371000..... | 3/8-16 HEX NUT |
| 7..... | K310001..... | FLAT WASHER 5/16 |
| 8..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 9..... | K370001..... | FLAT WASHER 3/8 SAE |
| 10..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 11..... | 3708378..... | STRIP FOAM .25T |
| 12..... | 3706045..... | VACUUM MASTERCRAFT |
| | 3706046..... | CLOTH FILTER BAG |
| | 3706067..... | GREY FILTER INNER BAG |
| | 3708874..... | SIZING ADAPTER |
| 13..... | 3706250..... | HOLE PLUG .375 |
| 14..... | 3706251..... | NYLON BRUSH 24" |
| 15..... | 3706224..... | HOLE PLUG 1.13 DIAMETER |
| 16..... | 3707958..... | MACHINE LED LIGHT |
| 17..... | 3708675..... | 3/16 - BLIND RIVET |
| 18..... | 6529083..... | FOAM PAD CANOPY BACK |
| 19..... | 6539008..... | LEFT SIDE FRAME FOAM |
| 20..... | 6539009..... | RIGHT SIDE FRAME FOAM |
| 21..... | 6539013..... | TOP CANOPY FOAM SHEET |
| 22..... | 6539102..... | BRUSH HOLDER |
| 23..... | 6539508..... | FIXED BACK WELDMENT |
| 24..... | 6539513..... | TOP WELDMENT |
| 25..... | 3706260..... | GROMMET 1 INCH |

PARTS LIST REAR DOOR OPTION 6539506 CABINET REAR DOORS -653




PARTS LIST REAR DOOR OPTION 6539506 CABINET REAR DOORS -653

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B311013..... | 5/16-18 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 2..... | B250816..... | 1/4-20 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 3..... | B251005..... | 1/4-20 x 5/8 FLAT HEAD SOCKET CAP SCREW |
| 4..... | B311201..... | 5/16-18 x 3/4 HEX HEAD CAP SCREW |
| 5..... | B371611..... | 3/8-16 x 1 SOCKET HEAD CAP SCREW |
| 6..... | B371625..... | 3/8-16 x 1 FLAT HEAD SOCKET CAP SCREW |
| 7..... | B372416..... | 3/8-16 x 1-1/2 BUTTON HEAD CAP SCREW |
| 8..... | B373216..... | 3/8-16 x 2 BUTTON HEAD SOCKET CAP SCREW |
| 9..... | J197100..... | 10-24 LOCKNUT JAM NYLON INSERT |
| 10..... | J251000..... | 1/4-20 HEX NUT |
| 11..... | J257000..... | 1/4-20 LOCKNUT JAM |
| 12..... | J311000..... | 5/16-18 HEX NUT |
| 13..... | J377000..... | 3/8-16 LOCKNUT JAM |
| 14..... | K250001..... | FLAT WASHER 1/4 SAE |
| 15..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 16..... | K310001..... | FLAT WASHER 5/16 SAE |
| 17..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 18..... | K370001..... | FLAT WASHER 3/8 SAE |
| 19..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 20..... | 55476..... | DOOR SWITCH BRACKET |
| 21..... | 3706045..... | VACUUM MASTERCRAFT |
| | 3706046..... | CLOTH FILTER BAG |
| | 3706067..... | GREY FILTER INNER BAG |
| 22..... | 3706062..... | 1/4-20 ACORN NUT |
| 23..... | 3706063..... | WIRE ROPE PULLEY |
| 24..... | 3706205..... | FLUSH MOUNT DOOR |
| 25..... | 3706206..... | 28 IN DRAWER SLIDE |
| 26..... | 3706208..... | WIRE ROPE ASSEMBLY |
| 27..... | 3708416..... | SOFT LATCH SOUTHCO |
| 28..... | 3707273..... | STRAIN RELF .33-.39 |
| 29..... | 3707908..... | DOOR SWITCH W/DISCONNECT |
| 30..... | 3708036..... | BALL BRG R6-2RS |
| 31..... | 3708379..... | STRIP FOAM .50 THICK |
| 32..... | 3708820..... | 8-32 x .50 BUTTON HEAD SAFETY SCREW |
| 33..... | 3708999..... | WASHER FLAT .38 x .56 x .03 THICK |
| 34..... | 4609049..... | SPACER .385 ID x .75 OD x .38 LONG |
| 35..... | 6539008..... | LEFT SIDE FRAME |
| 36..... | 6539009..... | RIGHT SIDE FRAME |
| 37..... | 6539011..... | FOAM REAR DOORS |
| 38..... | 6539012..... | FOAM REAR DOOR SIDE |
| 39..... | 6539013..... | TOP CANOPY FOAM |
| 40..... | 6539032..... | LEFT REAR DOOR RAIL |
| 41..... | 6539033..... | RIGHT REAR DOOR RAIL |
| 42..... | 6539034..... | LEFT REAR DOOR GUIDE |
| 43..... | 6539035..... | RIGHT REAR DOOR GUIDE |
| 44..... | 6539036..... | REAR DOOR TRAP |
| 45..... | 6539041..... | CABLE TOP GAURD |
| 46..... | 6539042..... | CABLE GUARD |
| 47..... | 6539044..... | FOAM REAR DOORS |
| 48..... | 6539045..... | FOAM REAR DOOR SIDE |
| 49..... | 6539062..... | REAR DOOR CORD |
| 50..... | 3706052..... | FOAM SEAL ADHESIVE |
| 51..... | 6509269..... | BRACKET VAC HOSE |
| 52..... | 6539504..... | LEFT REAR DOOR WELDMENT |
| 53..... | 6539505..... | RIGHT REAR DOOR WELDMENT |
| 54..... | 6539507..... | TOP WELDMENT |
| 55..... | 3708675..... | 3/16 - BLIND RIVET |
| 56..... | 3707958..... | MACHINE LIGHT - LED |
| 57..... | 6339201..... | REAR BUMPER |
| 58..... | B190811..... | 10-24 x 1/2 SOCKET HEAD CAP SCREW |
| 59..... | 6309038..... | BRACKET - DOOR |
| 60..... | B371216..... | 3/8-16 x 3/4 BUTTON HEAD CAPSCREW |
| 61..... | J167000..... | 8-32 LOCKNUT JAM NYLON INSERT |
| 62..... | J251001..... | 1/4-28 HEX NUT |

PARTS LIST

MODEL 633 -6339520 FRONT DOOR ASSEMBLY




PARTS LIST

MODEL 633 -6339520 FRONT DOOR ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---|
| 1..... | B230611..... | M6 x 10 SOCKET HEAD CAP SCREW |
| 2..... | B251011..... | 1/4-20 x 5/8 SOCKET HEAD CAP SCREW |
| 3..... | B310813..... | 5/16-18 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B311016..... | 5/16-18 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | B311213..... | 5/16-18 x .75 BUTTON HEAD SOCKET CAP SCREW |
| 6..... | B371216..... | 3/8-16 x 3/4 BUTTON HEAD SOCKET CAP SCREW |
| 7..... | B372811..... | 3/8-16 x 1-3/4 SOCKET HEAD CAP SCREW FULL THD |
| 8..... | B374811..... | 3/8-16 x 1-3/4 SOCKET HEAD CAP SCREW FULL THD |
| 9..... | J167000..... | 8-32 LOCKNUT JAM NYLON INSERT |
| 10..... | J252000..... | 1/4-20 HEX JAM NUT |
| 11..... | J311000..... | 5/16-18 HEX NUT FULL |
| 12..... | J317100..... | 5/16-18 LOCKNUT FULL NYLON INST |
| 13..... | J372000..... | 3/8-16 HEX JAM NUT |
| 14..... | J377000..... | 3/8-16 LOCKNUT JAM NYLON INSERT |
| 15..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 16..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 17..... | 3706039..... | HOLE PLUG .687 DIA. x .125 THK |
| 18..... | 3706186..... | WINDOW GASKET |
| 19..... | 3706215..... | LEDGE HANDLE |
| 20..... | 3706217..... | SHOULDER BOLT .5 x 2.5L |
| 21..... | 3706218..... | SHOULDER BOLT .38 x 2.5L |
| 22..... | 3706226..... | COMP. SPRING 3 L x .72 OD x .085 DIA WIRE |
| 23..... | 3706232..... | 3/8 16 x 4.5" SOCKET HEAD CAP SCREW FULL THREAD |
| 24..... | 3707908..... | DOOR SWITCH W/DISCONNECT |
| 25..... | 3708820..... | 8-32 x .50 BUTTON HD SAFETY SCREW |
| 26..... | 3708889..... | SEAL FOAM .50 HIGH |
| 27..... | 3709027..... | THRUST WASHER .507 x .917 x .062 T |
| 28..... | 3709304..... | THRUST WASHER .375 x .812 x .032 T |
| 29..... | 4609063..... | SPACER .385 x .625 x .25 L |
| 30..... | 6339039..... | DOOR PIVOT BRACKET |
| 31..... | 6339050..... | ACCU-PRO 633 DECAL |
| 32..... | 6339051..... | DOOR PIVOT ARM MACHINED ecp |
| 33..... | 6339056..... | WINDOW 18.5 x 26 (633) |
| 34..... | 6339057..... | DOOR CENTER PLATE |
| 35..... | 6539086..... | UPPER DOOR PIVOT ARM |
| 36..... | 6339189..... | DOOR UPPER ARM BRACKET |
| 37..... | 6339201..... | REAR BUMPER |
| 38..... | 6339202..... | UPPER DOOR PIVOT |
| 39..... | 6339521..... | 633 DOOR WELDMENT RH |
| 40..... | 6339522..... | 633 DOOR WELDMENT LH |
| 41..... | 6339524..... | DOOR PIVOT ARM WELDMENT |
| 42..... | 6539088..... | DOOR SHIPPING BRACKET |

PARTS LIST

MODEL 633- 6339545 REAR DOOR ASSEMBLY




PARTS LIST

MODEL 633- 6339545 REAR DOOR ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|----------|---|
| 1 | B190411 | 10-24 x 1/4 SOCKET HEAD CAP SCREW |
| 2 | B190613 | 10-24 x 3/8 BUTTON HEAD SOCKET SCREW CAP |
| 3 | B250816 | 1/4-20 x 1/2 BUTTON HEAD SOCKET SCREW CAP |
| 4 | B251016 | 1/4-20 x 5/8 BUTTON HEAD SOCKET SCREW CAP |
| 5 | B251216 | 1/4-20 x 3/4 BUTTON HEAD SOCKET SCREW CAP |
| 6 | B310813 | 5/16-18 x 1/2 BUTTON HEAD SOCKET SCREW CAP |
| 7 | B370801 | 3/8-16 x 1/2 HEX HEAD CAP SCREW |
| 8 | B370816 | 3/8-16 x 1/2 BUTTON HEAD SOCKET SCREW CAP |
| 9 | B372001 | 3/8-16 x 1-1/4 HEX HEAD CAP SCREW |
| 10 | B372016 | 3/8-16 x 1.25 BUTTON HEAD SOCKET SCREW CAP |
| 11 | B372401 | 3/8-16 x 1-1/2 HEX HEAD CAP SCREW |
| 12 | B372416 | 3/8-16 x 1-1/2 BUTTON HEAD SOCKET SCREW CAP |
| 13 | H371202 | ROLL PIN .375 D x .75 |
| 14 | J167000 | 8-32 LOCKNUT JAM |
| 15 | J191000 | 10-24 HEX NUT |
| 16 | J252000 | 1/4-20 HEX JAM NUT |
| 17 | J257000 | 1/4-20 LOCKNUT JAM |
| 18 | J257100 | 1/4-20 LOCKNUT |
| 19 | J371000 | 3/8-16 HEX NUT |
| 20 | J377000 | 3/8-16 LOCKNUT JAM |
| 21 | J627100 | 5/8-11 LOCKNUT |
| 22 | K190001 | FLAT WASHER #10 SAE |
| 23 | K191501 | #10 LOCKWASHER SPLIT |
| 24 | K250001 | FLAT WASHER 1/4 SAE |
| 25 | K251501 | 1/4 LOCKWASHER SPLIT |
| 26 | K370001 | FLAT WASHER 3/8 SAE |
| 27 | K371501 | 3/8 LOCKWASHER SPLIT |
| 28 | 09054 | FLAT WASHER .387 x .625 x .065 |
| 29 | 55492 | DOOR SAFETY SWITCH PLATE |
| 30 | 80406 | FLAT WASHER .27 ID x .50 x .06 |
| 31 | 80418 | STUD GAS SPRING |
| 32 | 80421 | RETAINING CLIP GAS |
| 33 | 3249153 | FLAT WASHER .252 x .375 x .018 |
| 34 | 3706032 | BALL BEARING R10 W/OIL |
| 35 | 3706097 | PULLEY 1.75 OD x .37 ID |
| 36 | 3706098 | PULLEY 1.5 OD x .25 ID |
| 37 | 3706099 | CLEVIS ROD END M8 |
| 38 | 3706100 | GAS SPRING 202# 3.9 STROKE |
| 39 | 3706212 | CABLE ASSY REAR DOOR |
| 40 | 3707029 | STRAIN RELF LIQUID TIGHT |
| 41 | 3707908 | DOOR SWITCH WITH DISCONNECT |
| 42 | 3708820 | 8-32 x .50 BUTTON HEAD SAFETY SCREW |
| 43 | 3708869 | SPRING HINGE |
| 44 | 3708998 | WAVE SPRING .35 ID |
| 45 | 3709597 | BALL BEARING |
| 46 | 6329131 | CATCH |
| 47 | 6329133 | CATCH PIN |
| 48 | 6329136 | REAR SLIDE SPACER |
| 49 | 6329137 | REAR SLIDING DOOR |
| 50 | 6329163 | REAR DOOR ARM |
| 51 | 6329164 | PULLEY BLOCK |
| 52 | 6329165 | DOOR SWITCH BRACKET |
| 53 | 6329166 | CABLE GUIDE |
| 54 | 6329167 | BEARING BLOCK |
| 55 | 6329172 | REAR DOOR INNER SLIDE |
| 56 | 6329174 | REAR DOOR LIFT HANDLE |
| 57 | 6329175 | REAR DOOR STIFFENER |
| 58 | 6329179 | REAR DOOR OUTER PLATE |
| 59 | 6329180 | DOOR STOP BLOCK |
| 60 | 6329181 | HINGED WALKER PANE |
| 61 | 6329182 | DOOR STOP SPACER PLATE |
| 62 | 6329183 | DOOR CATCH BRACKET |
| 63 | 6339168 | REAR DOOR SLIDE UP |
| 64 | 6339169 | REAR DOOR CABLE BRACKET |
| 65 | 6339170 | CABLE CLAMP BLOCK |
| 66 | 6339171 | DOOR STOP BLOCK |
| 67 | B190813 | 10-24 x 1/2 BUTTON HEAD SOCKET CAP SCREW |

PARTS LIST

6332901 COMMON ASSEMBLY




PARTS LIST

6332901 COMMON ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | 6339516..... | TRAVERSE BASE ASSEMBLY |
| 2..... | 6339537..... | CROSS SLIDE SUB ASSEMBLY |
| 3..... | 6339505..... | SPIN DRIVE ASSEMBLY |
| 4..... | 6339530..... | FRONT TOOLING ASSEMBLY |
| 5..... | 6339534..... | REAR TOOLING ASSEMBLY |
| 6..... | 6339538..... | POSITION GAUGE ASSEMBLY |
| 7..... | 6339544..... | FRAME WELDMENT PAINT |
| 8..... | B130412..... | 6-32 x 1/4 PAN HEAD MACHINE SCREW |
| 9..... | B190634..... | 10-32 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 10..... | B250616..... | 1/4-20 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 11..... | B250816..... | 1/4-20 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 12..... | B250819..... | 1/4-20 x 1/2 TRUSS HEAD MACHINE SCREW |
| 13..... | B251016..... | 1/4-20 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 14..... | B310813..... | 5/16-18 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 15..... | B311013..... | 5/16-18 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 16..... | B311613..... | 5/16-18 x 1.0 BUTTON HEAD SOCKET CAP SCREW |
| 17..... | B314811..... | 5/16-18 x 3 SOCKET HEAD CAP SCREW FULL |
| 18..... | B371211..... | 3/8-16 x 3/4 SOCKET HEAD CAP SCREW |
| 19..... | B502811..... | 1/2-13 x 1-3/4 SOCKET HEAD CAP SCREW |
| 20..... | B503211..... | 1/2-13 x 2 SOCKET HEAD CAP SCREW |
| 21..... | B504801..... | 1/2-13 x 3 HEX HEAD CAP SCREW |
| 22..... | H371602..... | ROLL PIN .375 D x 1.0 |
| 23..... | J137000..... | 6-32 LOCKNUT JAM NUT |
| 24..... | J257100..... | 1/4-20 LOCKNUT FULL |
| 25..... | J317100..... | 5/16-18 LOCKNUT |
| 26..... | J507100..... | 1/2-13 LOCKNUT FULL |
| 27..... | K191501..... | #10 LOCKWASHER SPLIT |
| 28..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 29..... | K310001..... | FLAT WASHER 5/16 SPLIT |
| 30..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 31..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 32..... | K501501..... | 1/2 LOCKWASHER SPLIT |
| 33..... | 3706193..... | GRAB CATCH - METAL |
| 34..... | 3706219..... | .25" PLASTIC WASHER |
| 35..... | 3706220..... | WING HANDLE CAM LATCH |
| 36..... | 3708543..... | SHOULDER BOLT .313 DIA x .32 LG |
| 37..... | 3708908..... | ADJUSTABLE HANDLE 3/8-16 x .78 LG |
| 38..... | 6059030..... | HINGE - FRONT END |
| 39..... | 6329070..... | HINGE PAINTED |
| 40..... | 6339083..... | ELECTRICAL PANEL |

PARTS LIST

6339516 TRAVERSE BASE




PARTS LIST

6339516 TRAVERSE BASE

| DIA NO. | PART NO. | DESCRIPTION | DIA NO. | PART NO. | DESCRIPTION |
|---------|----------|--|--|----------|-------------------------------------|
| 1 | B190611 | 10-24 x 3/8 SOCKET HEAD CAP SCREW | 42 | 3709044 | BALL BEARING |
| 2 | B191211 | 10-24 x 3/4 SOCKET HEAD CAP SCREW | 43 | 3709072 | COMPRESSION SPRING .48OD |
| 3 | B250616 | 1/4-20 x 3/8 BUTTON HEAD CAP SCREW | 44 | 3709331 | RETAINING RING EXTERNAL |
| 4 | B250811 | 1/4-20 x 1/2 SOCKET HEAD CAP SCREW | 45 | 3709372 | HOLE PLUG .50 DIA. |
| 5 | B250818 | 1/4-20 x 1/2 PAN HEAD MACHINE SCREW | 46 | B251018 | 1/4-20 x 5/8 PAN HEAD MACHINE SCREW |
| 6 | B251205 | 1/4-20 x 3/4 FLAT HEAD SOCKET CP SCREW | 47 | 6339510 | RELIEF ANGLE POSITIONER ASSEMBLY |
| 7 | B251211 | 1/4-20 x 3/4 SOCKET HEAD CAP SCREW | 48 | 6329034 | COUPLER .625 DIA. |
| 8 | B251411 | 1/4-20 x 7/8 SOCKET HEAD CAP SCREW | 49 | 6329036 | PULLEY MOUNT BRACKET |
| 9 | B252011 | 1/4-20 x 1-1/4 SOCKET HEAD CAP SCREW | 50 | 6329141 | MOTOR EXTENSION SHAFT |
| 10 | B253211 | 1/4-20 x 2 SOCKET HEAD CAP SCREW | 51 | 6339533 | LIMIT SENSOR AND CLAMP |
| 11 | B256411 | 1/4-20 x 4 SOCKET HEAD CAP SCREW | 52 | 6329511 | SHAFT SUPPORT BLOCK |
| 12 | B310813 | 5/16-18 x 1/2 BUTTON HEAD CAP SCREW | 53 | 6539095 | BELLOWS WAY COVER (VELCRO) |
| 13 | B311611 | 5/16-18 x 1 SOCKET HEAD CAP SCREW | 54 | 6339214 | RELIEF ANGLE DECAL |
| 14 | B503211 | 1/2-13 x 2 SOCKET HEAD CAP SCREW | 55 | 6509054 | RETAINER PLUNGER |
| 15 | C250420 | 1/4-20 x 1/4 SOCKET SET SCREW | 56 | 6509055 | BELT COVER |
| 16 | H184002 | ROLL PIN .188 D x 2 | 57 | 6509063 | CARRIER SHAFT |
| 17 | J257000 | 1/4-20 LOCKNUT JAM | 58 | 6509210 | GASKET BELT COVER |
| 18 | 6539094 | BELLOWS CARRIAGE MOUNTING BRACKET | 59 | 6509221 | FIXED TRAV BASE END BRACKET |
| 19 | J627200 | 5/8-18 LOCKNUT JAM | DIA NO. PART NO. DESCRIPTION | | |
| 20 | J757300 | 3/4-16 LOCKNUT FULL | 60 | 6509238 | GRIP KNOB GRINDING WHEEL |
| 21 | K191501 | #10 LOCKWASHER SPLIT | 61 | B250618 | 1/4-20 x 3/8 PAN HEAD MACHINE SCREW |
| 22 | K250001 | FLAT WASHER 1/4 SAE | 62 | 6509253 | CARRIAGE DUST COVER BRACKET |
| 23 | K251501 | 1/4 LOCKWASHER SPLIT | 63 | 6339023 | PLUNGER PIN |
| 24 | K311501 | 5/16 LOCKWASHER SPLIT | 64 | 6339132 | LIMIT SENSOR BRACKET |
| 25 | K501501 | 1/2 LOCKWASHER SPLIT | 65 | 3709257 | BALL BEARING |
| 26 | R000376 | SQUARE KEY 1/8 x .75 | 66 | 3709304 | THRUST WASHER .375 |
| 27 | R000377 | SQUARE KEY 3/16 x .75 | 67 | B371216 | 3/8-16 x 3/4 BUTTON HEAD CAP SCREW |
| 28 | 28192 | TRAVERSE PULLEY SUPPORT | 68 | B371616 | 3/8-16 x 1 BUTTON HEAD CAP SCREW |
| 29 | 50309 | TRAVERSE PULLEY SHAFT | 69 | J377000 | 3/8-16 LOCKNUT JAM |
| 30 | 3706056 | DRIVE COG PULLEY | 70 | B160607 | 8-32 x 3/8 BUTTON HEAD CAP SCREW |
| 31 | 55553 | IDLER PULLEY ASSEMBLY | 71 | K161501 | #8 LOCKWASHER SPLIT |
| 32 | 80335 | CLAMP DESTACO 602 | 72 | 6339127 | RELIEF ANGLE POINTER |
| 33 | 80354 | COG BELT | 73 | 3706194 | COMPRESSION SPRING .60Dx |
| 34 | 80355 | THRUST WASHER .75 ID | 74 | 6329032 | TRAVERSE BASE MACHINED |
| 35 | 3707224 | CABLE TIE MOUNT | 75 | 3708121 | DOUBLE CORD CLAMP |
| 36 | 3707225 | CABLE TIE 6.5 L x.18 | 76 | 6339515 | GRINDING HEAD ASSEMBLY |
| 37 | 3708195 | RETAINING RING EXTERNAL | 77 | 6339531 | CARRIAGE ASSEMBLY BELT TRAVERSE |
| 38 | 3708419 | WAVE SPRING .78 ID | 78 | 80380 | GEARMOTOR 1/20 HP |
| 39 | 3708436 | WAVE SPRING | 79 | 3707601 | PROXIMITY SENSOR |
| 40 | 3708658 | COMPRESSION SPRING | 80 | 6539082 | HEAD POSITION SENSOR CORD |
| 41 | 3708884 | SPACER .28 ID x .62 OD | 81 | 6509269 | VACUUM HOSE BRACKET |
| | | | 82 | 6509216 | HEAD SENSOR BRACKET |

PARTS LIST

6339531 CARRIAGE ASSEMBLY




PARTS LIST

6339531 CARRIAGE ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---|
| 1..... | B130412..... | 6-32 x 1/4 PAN HEAD MACHINE SCREW |
| 2..... | B190509..... | 10-24 x 5/16 PAN HEAD MACHINE SCREW |
| 3..... | B191013..... | 10-24 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B250616..... | 1/4-20 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | B252016..... | 1/4-20 x 1-1/4 BUTTON HEAD SOCKET CAP SCREW |
| 6..... | B253216..... | 1/4-20 x 2 BUTTON HEAD SOCKET CAP SCREW |
| 7..... | J137000..... | 6-32 LOCKNUT JAM NUT |
| 8..... | J252000..... | 1/4-20 HEX JAM NUT |
| 9..... | J887300..... | 7/8-14 LOCKNUT |
| 10..... | K191501..... | #10 LOCKWASHER SPLIT |
| 11..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 12..... | 28187..... | BLOCK TRAVERSE CLAMP |
| 13..... | 28188..... | SPACER TRAVERSE CLAMP |
| 14..... | 28189..... | BLOCK CLAMP SUPPORT |
| 15..... | 50310..... | TIP BELT CLAMP |
| 16..... | 3706193..... | GRAB CATCH - METAL |
| 17..... | 3708184..... | RETAINING RING INTERNAL |
| 18..... | 3708186..... | BALL BEARING DOUBLE ROW 5 |
| 19..... | 6329040..... | TRAVERSE CLAMP MACHINED |
| 20..... | 6329058..... | CARRIAGE BASE BELT |
| 21..... | 6339130..... | CATCH BRACKET |
| 22..... | 6339532..... | DUST DOOR WELDMENT |
| 23..... | 6339559..... | PIN PLATE WELDMENT |
| 24..... | 6509023..... | GRINDING HEAD PIVOT SHAFT |

PARTS LIST

6339568 FINGER AND BODY ASSEMBLY




PARTS LIST

6339568 FINGER AND BODY ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---|
| 1..... | B190631..... | 10-32 x 3/8 SOCKET HEAD CAP SCREW |
| 2..... | B190634..... | 10-32 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 3..... | B251016..... | 1/4-20 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B251216..... | 1/4-20 x 3/4 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | B254811..... | 1/4-20 x 3 SOCKET HEAD CAP SCREW |
| 6..... | C160420..... | 8-32 x 1/4 SOCKET SET SCREW CUP POINT |
| 7..... | C190460..... | SOCKET SET SCREW 10-32X1/4 |
| 8..... | C190467..... | 10-32 x 1/4 SOCKET SET SCREW NYLON |
| 9..... | C250427..... | 1/4-20 x 1/4 NYLON |
| 10..... | K191501..... | #10 LOCKWASHER SPLIT |
| 11..... | J191100..... | 10-32 HEX NUT |
| 12..... | J197000..... | 10-24 LOCKNUT JAM |
| 13..... | J377200..... | 3/8-24 LOCKNUT JAM |
| 14..... | 3579284..... | NYLON PLUG 1/8 DIA |
| 15..... | 3706170..... | COMPRESSION SPRING .42 OD x .31 ID |
| 16..... | 3706171..... | COMPRESSION SPRING .42 OD x .33 ID |
| 17..... | 3706172..... | 1/4-20 x 3/8 SET SCREW |
| 18..... | 3706187..... | WAVE SPRING .2 ID |
| 19..... | 3706188..... | WAVE SPRING .24 ID |
| 20..... | 3708107..... | COMPRESSION SPRING .24 OD |
| 21..... | 3708999..... | WASHER FLAT .376 x .563 x .03 |
| 22..... | 6339014..... | SPACER .5 OD x .33 ID |
| 23..... | 6339016..... | FINGER STOP POSITION |
| 24..... | 6339017..... | PIN BLOCK |
| 25..... | 6339020..... | FINGER SLIDE BASE |
| 26..... | 6339507..... | INDEX FINGER ASSEMBLY |
| 27..... | 6339508..... | RELIEF ADJUSTER LOCK HANDLE |
| 28..... | 6339569..... | RELIEF ANGLE POSITIONER KNOB ASSEMBLY |
| 29..... | 6339511..... | FINGER STOP PLATE ASSEMBLY |
| 30..... | 6339512..... | FINGER STOP ADJUSTMENT KNOB |
| 31..... | 6339548..... | FIXED FINGER ASSEMBLY |
| 32..... | 6339549..... | FINGER SUPPORT ROTATE ASSEMBLY |
| 33..... | 6339547..... | CLAMP PLATE FOR RELIEF ASSEMBLY |
| 34..... | 6509007..... | INDEX STOP PIN |
| 35..... | 6509008..... | INDEX SENSOR BLOCK |
| 36..... | 6509239..... | ANTI ROTATE PLATE |
| 37..... | 6509358..... | STOP PLATE |
| 38..... | 6509501..... | TEE KNOB ASSY 10-32 x 3.0 |
| 39..... | 6509230..... | INDEX SENSOR GUARD |
| 40..... | 3707601..... | PROXIMITY SENSOR |
| 41..... | 6539083..... | FINGER POSITION SENSOR CORD |
| 42..... | 3709705..... | NYLON BALL 5/32 DIA. |

PARTS LIST

6339515 GRINDING HEAD




PARTS LIST

6339515 GRINDING HEAD

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---------------------------------------|
| 1..... | B251411..... | 1/4-20 x 7/8 SOCKET HEAD CAP SCREW |
| 2..... | B371611..... | 3/8-16x1 SOCKET HEAD CAP SCREW |
| 3..... | C250627..... | 1/4-20x3/8 SOCKET SET SCREW CAP POINT |
| 4..... | K250001..... | FLAT WASHER 1/4 SAE |
| 5..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 6..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 7..... | R000376..... | SQUARE KEY 1/8 X .75 |
| 8..... | 3707690..... | MOTOR 1HP 120VAC TEFC |
| 9..... | 3708193..... | CONICAL WASHER .882 x 1.362 x .0197 |
| 10..... | 3708194..... | RETAINING RING INTERNAL |
| 11..... | 3708202..... | BELT POLY V 320J4 |
| 12..... | 3708204..... | BALL BRG DBL ROW 5202-2RS |
| 13..... | 3708870..... | RETAINING RING EXT .50 SHAFT HD |
| 14..... | 6329041..... | PLATE MOTOR MOUNT |
| 15..... | 6329042..... | PULLEY POLY V 1.80 DIA. |
| 16..... | 6329089..... | SLEEVE BEARING DBL ROW |
| 17..... | 6329100..... | PULLEY POLY-V 1.44 D STL |
| 18..... | 6329523..... | GR HEAD SPINDLE ASSY |
| 19..... | 6339026..... | GRINDING HEAD HOUSING |
| 20..... | 6509494..... | SPINDLE NUT |
| 21..... | | GRINDING WHEEL (SEE CARTON ASSEMBLY) |
| 22..... | 6509237..... | GRINDING WHEEL KNOB |
| 23..... | R000377..... | SQUARE KEY 3/16 x .75 |

PARTS LIST

6339537 CROSS SLIDE




PARTS LIST

6339537 CROSS SLIDE

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|---|
| 1..... | B160807..... | 8-32 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 2..... | B250816..... | 1/4-20 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 3..... | B252016..... | 1/4-20 x 1-1/4 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B372011..... | 3/8-16 x 1-1/4 SOCKET HEAD CAP SCREW |
| 5..... | H371602..... | ROLL PIN .375 D x 1.0 |
| 6..... | C311220..... | 5/16-18 x 3/4 SOCKET SET SCREW CUP POINT |
| 7..... | J257000..... | 1/4-20 LOCKNUT JAM |
| 8..... | J371000..... | 3/8-16 HEX NUT |
| 9..... | J377000..... | 3/8-16 LOCKNUT JAM |
| 10..... | K161501..... | #8 LOCKWASHER SPLIT |
| 11..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 12..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 13..... | 3109027..... | SPACER .281 IDx.50 OD |
| 14..... | 3579109..... | NYLON PLUG 3/16 DI |
| 15..... | 3708148..... | HANDWHEEL 4.5 DIA . |
| 16..... | 3708581..... | DIAL INDICATOR |
| 17..... | 3708665..... | FLAT WASHER .41 x 1. |
| 18..... | 3708705..... | ADJUSTABLE HANDLE 5/16-18 |
| 19..... | 3708706..... | ADJUSTABLE HANDLE 5/16-18 |
| 20..... | 3709062..... | CONICAL WASHER .38 x .75 x .035 T |
| 21..... | 3709304..... | THRUST WASHER .375 x .812 x .032 T |
| 22..... | 3969065..... | SPACER .406 ID x.75 OD |
| 23..... | 6009035..... | SHAFT LOCKING STUD |
| 24..... | 6009082..... | SUPPORT CROSS SLIDE |
| 25..... | 6009095..... | SHAFT SLIDE |
| 26..... | 6309113..... | SHAFT LOCKING STUD |
| 27..... | 6309114..... | DECAL ORANGE |
| 28..... | 6309115..... | DECAL GREY |
| 29..... | 6339027..... | DIAL INDICATOR MOUNT |
| 30..... | 6339028..... | DIAL INDICATOR STORE |
| 31..... | 6509011..... | CROSS SLIDE |
| 32..... | 6509015..... | SUPPORT CROSS SLIDE |
| 33..... | 6509010..... | ADJUSTER TRAVEL BRACKET |
| 34..... | 6509390..... | ADJUSTING SHAFT |

PARTS LIST

6339505 SPIN DRIVE ASSEMBLY




PARTS LIST**6339505 SPIN DRIVE ASSEMBLY**

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|----------------|--------------|--|
| 1..... | B190613..... | 10-24 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 2..... | B200611..... | M5-.8 x 10 SOCKET HEAD CAP SCREW METRIC |
| 3..... | B253216..... | 1/4-20 x 2 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | C190420..... | 10-24 x 1/4 SOCKET SET SCREW CAP POINT |
| 5..... | E253200..... | CARRB 1/4-20 x 2.00 |
| 6..... | H182002..... | PIN - ROLL .188 D x 1.25 L |
| 7..... | J257000..... | 1/4-20 LOCKNUT JAM NYLON INSERT |
| 8..... | K191501..... | #10 LOCKWASHER SPLIT |
| 9..... | 3109027..... | SPACER .281 ID x .50 OD x .50 L STEEL |
| 10..... | 3706138..... | GAS SPRING 130# 1.97" STROKE |
| 11..... | 3706255..... | GAS SPRING 30# 1.97" STROKE |
| 12..... | 3706155..... | STEEL CLEVIS ROD END FOR M6 x 1 |
| 13..... | 3706156..... | CLEVIS PIN 3/16 x 1-3/4 L |
| 14..... | 3706157..... | CLEVIS PIN 3/16 x 1-1/2 L |
| 15..... | 3706158..... | KNOB T 1.5 1/4-20 F |
| 16..... | 3706159..... | 5/16-18 x .5" BUTTON HEAD SOCKET CAP SCREW W/PATCH |
| 17..... | 3706165..... | MOTOR DRIVE ADAPTER 12MM-1/2 SQUARE |
| 18..... | 3706166..... | 8-32 BALL NOSE SPRING PLUNGER |
| 19..... | 3708861..... | CONICAL WASHER .258 x .688 x .048 |
| 20..... | 3709062..... | CONICAL WASHER .382 x .75 x .035 T |
| 21..... | 6339005..... | SPIN DRIVE UPPER ARM |
| 22..... | 6339006..... | SPIN MOTOR PIVOT BLOCK |
| 23..... | 6339012..... | SPACER .26 ID x .5 OD x 1.0 L |
| 24..... | 6339501..... | SPIN DRIVE LOWER ARM WELDMENT |
| 25..... | 6339503..... | MOTOR HOUSING END CAP |
| 26..... | 6339504..... | SPIN DRIVE BASE PIVOT BLOCK ASSEMBLY |
| 27..... | 6339564..... | MOTOR HOUSING WELDMENT W/ SLOT |
| 28..... | 6339565..... | SPIN MOTOR ASSEMBLY 1.9A |
| NOT SHOWN..... | 3707255..... | CABLE TIE 4 L x .10 W x .038 T |

PARTS LIST

6339530 FRONT TOOLING




PARTS LIST

6339530 FRONT TOOLING

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B251416..... | 1/4-20 x 7/8 BUTTON HEAD SOCKET CAP SCREW |
| 2..... | B251611..... | 1/4-20 x 1 SOCKET HEAD CAP SCREW |
| 3..... | B252416..... | 1/4-20 x 1-1/2 BUTTON HEAD SOCKET CAP SCREW |
| 4..... | B311013..... | 5/16-18 x 5/8 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | B371625..... | 3/8-16 x 1 FLAT HEAD SOCKET CAP SCREW |
| 6..... | B371611..... | 3/8-16 x 1 SOCKET HEAD CAP SCREW |
| 7..... | C250620..... | 1/4-20 x 3/8 SOCKET SET SCREW CAP POINT |
| 8..... | H251202..... | ROLL PIN .25 D x .75 L |
| 9..... | J377000..... | 3/8-16 LOCKNUT JAM NYLON INSERT |
| 10..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 11..... | K310001..... | FLAT WASHER 5/16 STEEL |
| 12..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 13..... | K371501..... | 3/8 LOCKWASHER SPLIT |
| 14..... | 09853..... | KNOB - 4 PRONG 1/2-13F |
| 15..... | 17119..... | STUD - THD 1/2-13 x 6.5 LG |
| 16..... | 3679096..... | SPACER .281IDx.625 OD x .75 L |
| 17..... | 3706189..... | BRG - DU SLEEVE 1/2 ID x 3/4 LG |
| 18..... | 3706190..... | RATCHET WRENCH .625" HEX |
| 19..... | 3706191..... | BRG - OILITE FLANGE .375 x .5 x .25 |
| 20..... | 3706192..... | 1/2"OD x 8" LG SHAFT |
| 21..... | 3706203..... | SPRING COMPRESSION .72 OD x 2 LG |
| 22..... | 3706204..... | RETAINING RING EXTERNAL 5103-62 LOW CLEARANCE FOR 5/8" SHAFT |
| 23..... | 3706234..... | BRG - OILITE SLEEVE .62 x .73 x .50 |
| 24..... | 3706235..... | DAMPER - 10MM SHAFT |
| 25..... | 3708094..... | ADJ HANDLE 5/16-18 x 1.25 LG |
| 26..... | 3708908..... | ADJ HANDLE 3/8-16 x .78 LG |
| 27..... | 6009031..... | SPACER .386 ID x .50 OD x .56 L STEEL |
| 28..... | 6339095..... | FRONT TOOLING TOP PLATE |
| 29..... | 6339099..... | SPRING GUIDE |
| 30..... | 6339100..... | SLIDE CLAMP BLOCK |
| 31..... | 6339103..... | SHAFT SUPPORT BLOCK |
| 32..... | 6339104..... | TOOLING PLATE LONG BRACE |
| 33..... | 6339105..... | TOOLING PLATE SHORT BRACE |
| 34..... | 6339109..... | FRONT TOOLING MOUNT PLATE |
| 35..... | 6339111..... | FRONT TOOLING RIGHT SIDE PLATE |
| 36..... | 6339112..... | FRONT TOOLING LEFT SIDE PLATE |
| 37..... | 6339113..... | LOCK PLATE |
| 38..... | 6339114..... | TOOLING LOCK BLOCK |
| 39..... | 6339207..... | FRONT TOOLING OUTER PLATE |
| 40..... | 6339527..... | FORNT CLAMP WELDMENT |
| 41..... | 6339561..... | FRONT ROLLER MOUNT MACHINED |
| 42..... | 6339562..... | PINION SHAFT WELDMENT |

PARTS LIST

6339534 REAR TOOLING




PARTS LIST

6339534 REAR TOOLING

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B250616..... | 1/4-20 x 3/8 FLAT HEAD SOCKET CAP SCREW |
| 2..... | B250816..... | 1/4-20 x 1/2 FLAT HEAD SOCKET CAP SCREW |
| 3..... | B251216..... | 1/4-20 x 3/4 FLAT HEAD SOCKET CAP SCREW |
| 4..... | B251416..... | 1/4-20 x 7/8 FLAT HEAD SOCKET CAP SCREW |
| 5..... | B311013..... | 5/16-18 x 5/8 FLAT HEAD SOCKET CAP SCREW |
| 6..... | B311413..... | 5/16-18 x 7/8 BUTTON HEAD SOCKET CAP SCREW |
| 7..... | C190320..... | 10-24 x 3/16 SOCKET SET SCREW CAP POINT |
| 8..... | H180901..... | PIN - DOWEL .188 D x |
| 9..... | J311000..... | 5/16-18 HEX NUT FULL |
| 10..... | K121501..... | #5 LOCKWASHER SPLIT |
| 11..... | K251501..... | 1/4 LOCKWASHER SPLIT |
| 12..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 13..... | 3706195..... | BEARING RAIL - 15M |
| 14..... | 3706196..... | LINEAR BEARING 15M |
| 15..... | 3706197..... | M3-.5 X 20MM SOCKET HEAD CAP SCREW |
| 16..... | 3706198..... | M3-.5 X 12MM SOCKET HEAD CAP SCREW |
| 17..... | 3706221..... | COMPRESSION SPRING .25 OD |
| 18..... | 3708214..... | CONICAL WASHER .38 |
| 19..... | 3708914..... | PLUNGER - SPRING |
| 20..... | 6339119..... | BOTTOM PLATE REAR |
| 21..... | 6339120..... | TOP PLATE REAR TOOL |
| 22..... | 6339121..... | CLAMP PLATE REAR |
| 23..... | 6339122..... | POSITION PIN BRACK |
| 24..... | 6339123..... | PAWL RACK REAR TOOL |
| 25..... | 6339124..... | BEARING SIDE PLATE |
| 26..... | 6339125..... | SPARK PLATE |
| 27..... | 6339126..... | REAR TOOLING SUPPORT |
| 28..... | 6339134..... | POINTER KNOB |
| 29..... | 6339135..... | PAWL TOP PLATE |
| 30..... | 6339136..... | LOCATING PIN PLATE |
| 31..... | 6339137..... | PAWL SPACER PLATE |
| 32..... | 6339138..... | PAWL BOTTOM PLATE |
| 33..... | 6339139..... | PAWL PIVOT SHAFT |
| 34..... | 6339141..... | BOTTOM PLATE FRONT |
| 35..... | 6509304..... | DECAL - SCALE HORIZONTAL |
| 36..... | 6339025..... | DECAL SHEET |

PARTS LIST

6339538 ALIGNMENT GAUGE




PARTS LIST

6339538 ALIGNMENT GAUGE

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B110406..... | 4-40 x 1/4 SOCKET HEAD CAP SCREW |
| 2..... | B190302..... | 10-24 x 3/16 ROUND HEAD MACHINE SCREW |
| 3..... | B190611..... | 10-24 x 3/8 SOCKET HEAD SOCKET CAP SCREW |
| 4..... | B190613..... | 10-24 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 5..... | B190813..... | 10-24 x 1/2 BUTTON HEAD SOCKET CAP SCREW |
| 6..... | C190320..... | 10-24 x 3/16 SOCKET HEAD SET SCREW CUP POINT |
| 7..... | J257000..... | 1/4-20 LOCKNUT JAM |
| 8..... | K190101..... | FLAT WASHER .225 ID x .75 OD |
| 9..... | K191501..... | #10 LOCKWASHER SPLIT |
| 10..... | 3706173..... | CAM LOCK HANDLE |
| 11..... | 3706174..... | .25 DIA x 9" LG SHAFT |
| 12..... | 3706175..... | LANYARD 8" |
| 13..... | 3706176..... | SLEAVE BEARING 1/4 ID |
| 14..... | 3706177..... | CONSTANT FORCE SPRING |
| 15..... | 3706180..... | LINEAR BEARING 10M |
| 16..... | 3706209..... | LINEAR SENSOR MACHINED |
| 17..... | 3706210..... | GAUGE CORD ASSEMBLY |
| 18..... | 3706225..... | OILITE BEARING .38 ID X .50 OD |
| 19..... | 3707998..... | LINEAR SENSOR MAGNET |
| 20..... | 3708175..... | COMPRESSION SPRING .36 OD |
| 21..... | 3709526..... | 1" DIA BALL KNOB 1/4-20 THREAD |
| 22..... | 6339142..... | GAUGE TOP CAP |
| 23..... | 6339143..... | GAUGE BOTTOM CAP |
| 24..... | 6339148..... | HEIGHT STOP BLOCK |
| 25..... | 6339152..... | SPRING PLATE |
| 26..... | 6339154..... | GAUGE LATCH |
| 27..... | 6339155..... | PIN LOCK PLATE |
| 28..... | 6339156..... | BEARING BLOCK |
| 29..... | 6339199..... | GAUGE BASE PLATE |
| 30..... | 6339200..... | BEARING SUPPORT BLOCK |
| 31..... | 6339539..... | GAUGE HOUSING WELDMENT |
| 32..... | 3706238..... | STUD 1/4-20 x 3.00 LONG |
| 33..... | 6339025..... | DECAL SHEET |

PARTS LIST

6339541 REAR CLAMP ASSEMBLY




PARTS LIST

6339541 REAR CLAMP ASSEMBLY

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | 09351..... | KNOB - BALL 1.18 OD x 3/8-16 F (B27) |
| 2..... | B252431..... | 1/4-28 x 1.5 SOCKET HEAD CAP SCREW FULL THREAD |
| 3..... | K311501..... | 5/16 LOCKWASHER SPLIT |
| 4..... | B311211..... | 5/16-18 x 3/4 SOCKET HEAD CAP SCREW |
| 5..... | H252807..... | PIN - DRIV LOC .25 D x 1.75 LG |
| 6..... | J252100..... | JAM NUT 1/4-28 |
| 7..... | 3706207..... | COMPR SPRING .84 ID x .88 LG |
| 8..... | 6339160..... | CLAMP BAR |
| 9..... | 6339161..... | CLAMP HOUSING |
| 10..... | 6339163..... | CLAMP RING |
| 11..... | 6339164..... | LEVER HANDLE |
| 12..... | 6339165..... | BASE NADLE |
| 13..... | 6339212..... | CAM LOCK |
| 14..... | 6339540..... | REAR CLAMP WELDMENT |

PARTS LIST

6509574 INFEED STEPPER







PARTS LIST

6509529 INFEED STEPPER

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B190613..... | 10-24 x 3/8 BUTTON HEAD SOCKET CAP SCREW |
| 2..... | C250825..... | 1/4-20 x 1/2 SOCKET SET SCREW |
| 3..... | B252011..... | 1/4-20 x 1-1/4 SOCKET HEAD CAP SCREW |
| 4..... | C251020..... | 1/4-20 x 5/8 SOCKET SET SCREW CUP POINT |
| 5..... | 6509381..... | BASE COVER PLATE |
| 6..... | J377200..... | 3/8-24 LOCKNUT JAM NYLON INSERT |
| 7..... | 6509384..... | ACTUATOR ASSEMBLY |
| 8..... | 3708187..... | BALL BEARING DOUBLE ROW |
| 9..... | 3708189..... | INTERNAL RETAINING RING |
| 10..... | 3708192..... | HOSE CLAMP 2.25 DIAMETER |
| 11..... | 3709304..... | THRUST WASHER .375 |
| 12..... | 6509048..... | HEX PIVOT PIN |
| 13..... | 6509051..... | BLOCK TRUNION |
| 14..... | 6509056..... | BELLOWS 1.88 ID |
| 15..... | 3708629..... | FLEX COUPLING 1 x 1 x .25 BORE |
| 16..... | 3708424..... | RETAINING RING EXTERNAL SPIRAL 1.75 |
| 17..... | B190811..... | 110-24 x 3/8 SOCKET HEAD CAP SCREW |
| 18..... | K191501..... | #10 LOCKWASHER SPLIT |
| 19..... | 6529514..... | STEPPER MOTOR W/CORD ASSEMBLY |

PARTS LIST

6339558 COMMON CARTON




PARTS LIST

6339558 COMMON CARTON

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | 3706130..... | DRIVE ADAPTERS |
| 2..... | 3708205..... | SOCKET HOLDER |
| 3..... | 3700088..... | GRINDING WHEEL 3.5 OD x .38 W x .502 B 24G |
| 4..... | 3700086..... | GRINDING WHEEL 3.5 OD x 1 W x .502 B 24G |
| 5..... | 3700087..... | GRINDING WHEEL 5 OD x.38 W x .502 B 24G |
| 6..... | 3700089..... | GRINDING WHEEL 5 OD x 1 W x .502 B 24G |
| 7..... | 3707603..... | BLUE LENS |
| 8..... | 3707465..... | FLASHER BULB |

PARTS LIST

6539519 ACCUTOUCH 3



PARTS LIST

6539519 ACCU-TOUCH 3


| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|--|
| 1..... | B190634..... | 10-32 x 3/8 FLAT HEAD SOCKET SCREW |
| 2..... | D250800..... | 1/4-20 THREAD CUTTING SCREW |
| 3..... | R000465..... | LOCK WASHER #10 EXTERNAL |
| 4..... | R000536..... | LOCK WASHER 1/4 INTERNAL |
| 5..... | 80419..... | POTENTIOMETER 10K |
| 6..... | 3706105..... | DECAL SHEET (REEL GRINDER) |
| 7..... | 3706223..... | HOLE PLUG .313 DIA |
| 8..... | 3706224..... | HOLE PLUG 1.13 DIA |
| 9..... | 3707009..... | LIQUID TIGHT STRAIN RELIEF .27-.47 DIA |
| 10..... | 3707029..... | LIQUID TIGHT STRAIN RELIEF .19-.30 DIA |
| 11..... | 3707090..... | SLOW-BLOW FUSE - 4 AMP |
| 12..... | 3707093..... | STRAIN RELIEF |
| 13..... | 3707219..... | SLOW-BLOW FUSE - 2 AMP |
| 14..... | 3707342..... | YELLOW E-STOP RING |
| 15..... | 3707367..... | ROCKER SWITCH ON/OFF |
| 16..... | 3707446..... | POTENTIOMETER KNOB W/POINTER |
| 17..... | 3708462..... | DECAL WARNING 4500 RPM MIN |
| 18..... | 3707564..... | GREEN PUSH BUTTON |
| 19..... | 3707565..... | CONTACT BLOCK NO |
| 20..... | 3707566..... | LATCH MOUNTING |
| 21..... | 3707567..... | PUSH / PULL RED BUTTON |
| 22..... | 3707568..... | CONTACT BLOCK NC |
| 23..... | 3707595..... | HOLE PLUG .875 DIA |
| 24..... | 3707597..... | HOLE PLUG .625 DIA |
| 25..... | 3707658..... | LIQUID TIGHT STRAIN RELIEF .54-.71 DIA |
| 26..... | 3707927..... | FUSE HOLDER - PANEL MOUNT |
| 27..... | 3708419..... | WAVE SPRING .78 ID |
| 28..... | 3708421..... | FLAT WASHER .75 x 1.0 OD |
| 29..... | 6539047..... | 7" TOUCH SCREEN |
| 30..... | 3708448..... | ELECTRICAL WARNING DECAL |
| 31..... | 3708872..... | PATENT DECAL |
| 32..... | 3709990..... | FOLEY UNITED DECAL |
| 33..... | 3707601..... | PROXIMITY SWITCH |
| 34..... | 6539078..... | LEFT PROXIMITY SWITCH CORD ASSEMBLY |
| | 6539079..... | RIGHT PROXIMITY SWITCH CORD ASSEMBLY |
| 35..... | 6529019..... | LIGHT BASE ASSEMBLY |
| 36..... | 3707603..... | BLUE LIGHT LENS |
| 37..... | 3707465..... | LIGHT BULB 120VAC - FLASHER |
| 38..... | 6339025..... | DECAL SHEET 633/65 |
| 39..... | 6539001..... | ACCUTOUCH 3 CONTROL DECAL |
| 40..... | 6539046..... | POWER SIWTCH DECAL |
| 41..... | 6539073..... | CONTROL PANEL TOP |
| 42..... | 3706136..... | VELCRO LOOP - 1"W |
| 43..... | 3706135..... | VELCRO HOOK - 1"W |
| 44..... | 3706133..... | CLEAR TUBE 3.5 OD |
| 45..... | 3706134..... | END CAP - 3.5 ID B |
| 46..... | J197200..... | 10-32 HEX LOCKNUT JAM |

ITEMS NOT SHOWN

| | | |
|-------|--------------|-------------------------|
| | 6539065..... | CONTROL CABLE ASSEMBLY |
| | 6539066..... | LIGHT RECEPTACLE CORD |
| | 6539067..... | VACUUM RECEPTACLE CORD |
| | 6539068..... | FLASHER LIGHT CORD |
| | 6539075..... | SPIN DRIVE CORD |
| | 6539084..... | RS232 CONNECTOR - |
| | | ACCUTOUCH SCREEN |
| | 6539085..... | 5PIN MINI DIN CONNECTOR |
| | | PLC |
| | 3707224..... | CABLE TIE MOUNT |
| | 3707225..... | CABLE TIE 6.5Lx.18 |
| | 3707255..... | CABLE TIE 4Lx.10 |
| | 3708378..... | STRIP FOAM .25T |
| | 6309111..... | DECAL UP/DOWN |

PARTS LIST

6539520 ACCU-TOUCH 3 SUB CONTROL




PARTS LIST

6539520 ACCU-TOUCH 3 SUB CONTROL

| DIAGRAM NO. | PART NO. | DESCRIPTION |
|-------------|--------------|-----------------------------------|
| 1..... | D130608..... | 6-32 x .38 PAN HEAD MACHINE SCREW |
| 2..... | D131266..... | 6 x 3/4 PHIL PAN SELF TAP |
| 3..... | D131666..... | 6 x 1 PHIL PAN SELF TAP |
| 4..... | D160866..... | 8 x 1/2 LG PHIL PA |
| 5..... | K160001..... | FLAT WASHER #8 SAE |
| 6..... | 80259..... | CIRCUIT BREAKER 20 |
| 7..... | 3706118..... | PUSH IN CABLE TIE |
| 8..... | 3706148..... | TERMINAL BLOCK RELAY |
| 9..... | 3706149..... | 2-POLE JUMPER FOR |
| 10..... | 3706150..... | 20 POLE JUMPER FOR |
| 11..... | 3707073..... | SOCKET 8 PIN |
| 12..... | 3707163..... | DECAL PRIMARY GROUP |
| 13..... | 3707164..... | LUG GROUND PRIMARY |
| 14..... | 3707695..... | 2 POLE JUMPER |
| 15..... | 3707907..... | DOOR SWITCH MONITOR |
| 16..... | 3707556..... | STARTER MAGNETIC 1 |
| 17..... | 3707557..... | RELAY - OVERLOAD 1 |
| 18..... | 3707625..... | END STOP SCREWLESS |
| 19..... | 3707684..... | TERMINAL BLOCK - 3 |
| 20..... | 3707685..... | TERMINAL BLOCK - 3 |
| 21..... | 3707686..... | END PLATE - TERM B |
| 22..... | 3707626..... | JUMPER ADJACENT |
| 23..... | 3707688..... | LOW VOLTAGE RELAY |
| 24..... | 3707694..... | RELAY TERMINAL BLOCK |
| 25..... | 3707697..... | DRIVE TRAVERSE |
| 26..... | 3707798..... | RELAY TERM BLOCK 8 |
| 27..... | 3707829..... | DIN RAIL 12" |
| 28..... | 3707839..... | 24VDC POWER SUPPLY |
| 29..... | 3707910..... | TERMINAL BLOCK 3-POLE |
| 30..... | 3707913..... | TERMINAL BLOCK 4-POLE |
| 31..... | 3707914..... | TERMINAL BLOCK 4-POLE |
| 32..... | 3707915..... | TERMINAL BLOCK 3-POLE |
| 33..... | 3707916..... | TERMINAL BLOCK 3-POLE |
| 34..... | 3707917..... | TERMINAL BLOCK 4-POLE |
| 35..... | 3707918..... | TERMINAL BLOCK END |
| 36..... | 3707919..... | 2-POLE TERMINAL BLOCK |
| 37..... | 3707923..... | STEPPER DRIVE 2AMP |
| 38..... | 3707925..... | DIN RAIL 9.0 LG |
| 39..... | 3707936..... | CIRCUIT BREAKER 10 |
| 40..... | 3707937..... | RFI LINE FILTER |
| 41..... | 3707940..... | CONTROL BOARD FOR |
| 42..... | 3707942..... | SPIN CONTROL BOARD |
| 43..... | 3707569..... | PLC AROMAT |
| 44..... | 6539074..... | CONTROL SUB PANEL |
| 45..... | 6539059..... | PLC CABLE - INPUTS |
| | 6539060..... | PLC CABLE - OUTPUTS |
| | 6539058..... | PANEL WIRE HARNESS |


WIRING DIAGRAM

6534519 - AC



WIRING DIAGRAM

6534519 - AC




BTX - BLUE TERMINAL BLOCK
ESS - EMERGENCY STOP SWITCH
FS1-2 AMP FUSE (DC PWR)
FS2-4 AMP FUSE (SPIN/ GRIND RELAY)
FS3-4 AMP FUSE (TRAVERSE)
FTR - FILTER
GCB - GRIND MOTOR CIRCUIT BREAKER
GS1 - GAUGE / SPIN INTERFACE
GTX - GREY TERMINAL BLOCK
LVR - LOW VOLTAGE RELAY
MAG - MAGNETIC STARTER
MCB - MAIN CIRCUIT BOARD 20 AMP
REL - GRIND MOTOR RELAY
PLC - PROGRAMMABLE LOGIC CONTROLLER
PSW - POWER SWITCH CONTROL BOX
PWR - DC POWER SUPPLY

SDC - SPIN DRIVE CONTROL
SIC - STEPPER INFEEED CONTROL
SRL - START RELAY
SSM - SAFETY SWITCH MONITOR
SSS - SYSTEM START SWITC
TBX - TERMINAL BLOCK (X: L=LIGHT, V=VACUUM, W=WINCH
 F=FLASHER, T=TRAVERSE, S=SPIN MOTOR, G= GRIND
TCH - TOUCH SCREEN
TDC - TRAVERSE DRIVE CONTROL
TSP - TRAVERSE SPEED POT
TTX - TIER TERMINAL BLOCK
VCB - VACUUM/WINCH CIRCUIT BREAKER
YXX - OUTPUT RELAYS


WIRING DIAGRAM

6534519 - DC




WIRING DIAGRAM

6534519 - DC




WIRING SCHEMATIC




WIRING SCHEMATIC

4




WIRING SCHEMATIC

5




WIRING SCHEMATIC

6




WIRING SCHEMATIC

5



WIRING SCHEMATIC

6




PLC INPUT AND OUTPUT LIGHTS

PLC INPUT LIGHTS

- X0 HIGH SPEED COUNTER - PULSE IN FROM GAUGE CONTROL BOARD
- X1 LEFT TRAVERSE PROX
LIT WHEN ACTIVATED
- X2 RIGHT TRAVERSE PROX
LIT WHEN ACTIVATED
- X3 FINGER POSITION PROX
LIT WHEN FINGER DOWN
- X4 HEAD POSITION PRX
LIT WHEN HEAD IN RELIEF
- X5 LOW VOLTAGE RELAY
LIT WHEN RELAY IS GREEN
- X6 E – STOP - MAIN RELAY
LIT WHEN E-STOP IS DOWN – PUSHED IN
- X7 E – STOP - SECONDARY
LIT WHEN START RELAY IS ON
- X8 DOOR SAFETY SWITCH - REAR
LIT WHEN DOORS CLOSED
- X9 DOOR SAFETY SWITCH - FRONT
LIT WHEN DOORS CLOSED
- XA GRIND MOTOR RELAY
LIT GRIND MOTOR RELAY IS ON
- XB DOOR SWITCH MONITOR
LIT WHEN DOORS ARE CLOSED AND MONITOR CONTACT IS CLOSED (SWITCHES ALIGNED).

PLC



PLC OUTPUT LIGHTS

- Y0 STEP SIGNAL TO INFEED DRIVE
LIT WHEN INFEED MOVING (DIM)
- Y1 DIRECTION SIGNAL TO INFEED DRIVE
LIT WHEN FEEDING OUT
- Y2 NOT USED
- Y3 SPIN ON / TORQUE OFF TO SPIN BOARD
LIT WHEN IN SPIN POSITION
- Y5 GRIND DRIVE POWER
LIT WHEN OUTPUTTING
- Y6 SPIN DRIVE POWER
LIT WHEN OUTPUTTING
- Y7 FLASHING LIGHT
LIT WHEN OUTPUTTING
- Y8 TRAVERSE DRIVE POWER
LIT WHEN OUTPUTTING
- Y9 SPIN MOTOR POWER
LIT WHEN OUTPUTTING
- YA SPIN DRIVE DIRECTION
LIT WHEN SPIN SET TO CW
- YB TRAVERSE RIGHT TO TRAVERSE BOARD
LIT WHEN OUTPUTTING
- YC TRAVERSE LEFT TO TRAVERSE BOARD
LIT WHEN OUTPUTTING
- YD NOT USED
- YE VACUUM POWER
LIT WHEN OUTPUTTING
- YF E – STOP LOOP
LIT WHEN READY TO ACTIVATE E-STOP & LVR IS GREEN

