



4609521 CAM PLATE (SERIVCE) INSTALLATION INSTRUCTIONS

REPLACEMENT OF CAM PLATE ON THE 460 OR 465 ROTARY BLADE GRINDER:

The location of the pin in the cam plate is dependant on the Model number and year of manufacture.

Refer to your existing cam plate to determine which hole to use. This pin will contact the adjustable stop on the carriage once installed. After the proper hole is determined, press the pin into the hole until there is approximately .50" [12.7mm] from the end of the pin to the plate.

