



## PARTS LIST (Continued)

## 6009529 GRINDING HEAD ASSEMBLY

DIA. NO.	PART NO.	PART NAME	DIA. NO.	PART NO.	PART NAME
1	B190831	10-32x1/2 Socket Head Cap Screw	48	3709370	Handle
2	B191233	10-32x3/4 Pan Head Machine Screw	49	3709437	3/8-16 Adj Handle
3	B190633	10-32x3/8 Pan Head Machine Screw	50	3709463	Rod End Bearing
4	B250819	1/4-20x1/2 Truss Head Machine Screw	51	3709620	Conical Washer
5	B251616	1/4-20x1 Button Head Cap Screw	52	3709764	V-Belt
6	B255011	1/4-20x3-1/8 Socket Head Cap Screw	53	3709809	.375 Dia x .38 Lg Shoulder Bolt
7	B310811	5/16-18x1/2 Socket Head Cap Screw	54	3809047	Clear Indicator
8	B311001	5/16-18x5/8 Hex Head Cap Screw	55	3889059	1.13 OD 2.0 Lg Compr. Spring
9	B311401	5/16-18x7/8 Hex Head Cap Screw	56	3889088	.62 Bore Pulley
10	C250420	1/4-20x1/4 Socket Setscrew Cup Pt.	57	6009040	Belt Guard Weldment
11	C251020	1/4-20x5/8 Socket Setscrew Cup Pt.	58	3969027	Adjusting Arm
12	C252420	1/4-20x1-1/2 Socket Setscrew Cup Pt.	59	3969057	Reel Guide Finger
13	C310420	5/16-18x1/4 Socket Setscrew Cup Pt.	60	3969058	Guide Finger Support
14	C372020	3/8-16x1-1/4 Socket Setscrew Cup Pt.	61	3969065	.406ID x 1Lg Steel Spacer
15	H252802	.25 Dia x 1.75Lg Roll Pin	62	4509385	Rotation Decal
16	H311602	.31 Dia x 1 Lg Roll Pin	63	6009024	1/2-10 ACME Backlash Nut
17	H372002	.38 Dia x 1.25 Lg Roll Pin	64	6009025	Gib Plate
18	H502001	.50 Dia x 1.25 Lg Dowel Pin	65	6009026	Tapped Pivot Sleeve
19	J251000	1/4-20 Hex Nut	66	6009027	ACME Adjusting Shaft
20	J252000	1/4-20 Hex Jam Nut	67	6009029	Keeper Plate
21	J257000	1/4-20 Thin Locknut	68	6009030	Shaft Locking Stud
22	J371100	3/8-24 Hex Nut	69	6009031	.386 ID x .56Lg Steel Spacer
23	J377000	3/8-16 Locknut Jam Nylon	70	6009034	Calibrated Ring
24	J377100	3/8-16 Locknut Hex Nylok Full	71	6009037	Wheel Guard
25	J502100	1/2-20 Hex Jam Nut	72	6009041	Angle Locking Pin
26	6009126	Rubber Gasket	73	6009044	4.50 Dia Modified Handwheel
27	K190001	#10 Flat Washer	74	6009083	Grinding Head Slide Base
28	K250001	1/4 Flat Washer	75	6009084	Grinding Head Pivot Base
29	K251501	1/4 Split Lock Washer	76	6009088	Grinding Head Swivel Base
30	K310001	5/16 Flat Washer	77	6009136	Feed Screw Guide
31	K311501	5/16 Split Lock Washer	78	6009216	Rear Belt Guard
32	K370001	3/8 Flat Washer	79	6009023	ACME Adjusting Shaft
33	K371501	3/8 Split Lock Washer	80	6009535	Tee Handle Assembly
34	6009125	Rubber Washer	81	6009587	Grinding Head Arbor Assembly
35	6009039	Grind Head Spash Guard	82	6009598	1/4-20 x .5Lg Tee Knob Assy.
36	3579109	Nylon Plug 3/16 Dia.	83	3708448	Electrical Warning Decal
37	3589081	Spacer .191 ID x .438 OD x .43 Lg	84	3707155	Black Wire Nut w/Setscrew
38	3649018	Outer Flange	85	6009195	Grind Motor Cord
39	3700090	Grinding Wheel 6" Dia x .75" Wide	86	3707976	3/8 Cable Connector
40	3707933	Cord Clip	87	3709372	.50 Dia Hole Plug
41	3708148	Handwheel 4.5 Dia	88	3707991	3/4 HP Motor
42	3708213	.24 OD x .62 Lg Comp. Spring	89	B311211	5/16-18x3/4 Socket Head Screw
43	3708458	Sharp Warning Decal	90	R000453	Flat Washer
44	3708461	RPM Warning Decal	91	6009133	Small Relief Guide Finger
45	3708561	3/8-16x1.56Lg Adj. Handle	90	3702508	Dressing Stick
46	3709062	Conical Washer			
47	3709304	Thrust Washer			