

6529060 TOUCH SCREEN CONVERSION KIT INSTALLATION INSTRUCTIONS

TO CONVERT AN OLDER CIMREX TOUCH SCREEN TO A NEW EXTER TOUCH SCREEN

THIS TOUCH SCREEN CONVERSION KIT APPLIES TO 652 ACCU-MASTER AND 632 ACCU-PRO GRINDERS WITH THE ACCUTOUCH CONTROL USING A CIMREX SCREEN.

Unplug the Grinder to remove all power to the machine. Next remove the old screen and cable that connects the screen to the PLC. You may have to remove the control panel top to access the screws that hold the touchscreen to the control panel top. The control panel top is sealed around the edges with clear silicon. Set the new screen in hole where the old screen was using the sizing adaptor. Install the new cord that connects to the PLC. **THE OLD CORD WILL NOT WORK WITH THE NEW SCREEN!** Now install and tighten the clips that hold the Touch screen to the control panel top. Reseal the control panel top to prevent any liquids from entering the control box.

Plug the cord into the PLC. The triangular arrow on the black connector of the cord should be on the side closest to the touch screen. Reconnect the power to the machine and turn on.

