

MADE IN THE U.S.A

OPERATORS AND PARTS MANUAL

TAILGATE & BUMPER MOUNTED LEAF VACUUMS SWING AWAY BUMPER MOUNT



TAILGATE MOUNT



BUMPER MOUNT VACUUM



BUMPER MOUNT VACUUM & SWING MOUNT

MANUFACTURER OF OUTDOOR POWER EQUIPMENT

Products for Turf & Lawncare, Rental, Construction, Tree care, Wood Processing, Nursery & Farm Industries
Other Salsco Equipment

3-1/2" - 18", Gas, Diesel, and P.T.O, Wood/Brush Chippers Chipper Shredder Vacuums - Tailgate & Truckloader Vacuums Shaving Mills - Gas and Electric Greens Rollers

Quality of Workmanship, Innovative Design, Built to Last!

105 School House Road Cheshire, CT 06410 U.S.A. 800-872-5726, 203-271-1682, 203-271-2596 (Fax) sales@salsco.com, www.salsco.com

TABLE OF CONTENTS

TAILGATE MOUNT LEAF VACUUMS

COVER & TABLE OF CONTENTSPages	1 - 2
STATEMENT OF FACT P	age 3
SPECIFICATIONS & FEATURESP	age 4
MACHINE REGISTRATIONP	age 5
SAFETY & OPERATING INSTRUCTIONS	es 6-7
SERVICE & MAINTENANCE INSTRUCTIONSP	age 7
PARTS DIAGRAMSPages	8-10
TORQUE CHARTSPa	age 11
WARRANTY POLICY/PROCEDUREPa	ige 12
COPY OF WARRANTY CLAIM FORMPa	ige 13
SERVICE SCHEDULE LOGPa	ge 14

SALSCO, INC. 105 School House Road Cheshire, CT 06410 800-872-5726, 203-271-1682 203-271-2596 (Fax) www.salsco.com, sales@salsco.com

STATEMENT OF FACT

You have just purchased the highest quality, most dependable, Tailgate Mount Leaf Vacuum, on the market today. This unit has the ability to meet exact standards and perform for years with minimum downtime. HOWEVER, it cannot read nor will it understand this manual no matter how long you leave it on top of the machine.

It is your responsibility to read and understand this manual; it is also your responsibility to be certain this information is passed along to anyone who is expected to operate this equipment. Should you choose not to read, understand and pass along the information provided you, please expect equipment failure and possible injuries to persons around this equipment.

For the safety of the operator, it is **imperative** that this manual is carefully read and understood.

Once you have read this manual, it is your responsibility to be sure that all new operators read and understand this manual, especially all cautions stated.

As a manufacturer of equipment, we have a responsibility to design a safe piece of equipment. NOTE: The important safeguards and instructions in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors, which cannot be built into any product. These factors must be supplied by the person(s) caring for and operating this equipment.

ONLY YOU CAN PREVENT ACCIDENTS!!

SPECIFICATIONS & FEATURES TAILGATE MOUNT LEAF VACUUMS

All units have lever clamp tailgate mounts and easily attach to the tailgate of any truck without tools or vehicle modifications. Another advantage of this type of mount is that with the latch and lock mechanisms on the outer side of the tailgate, the unit can be easily removed, even from a loaded truck.

All units use heavy-duty, re-enforced vacuum hoses, and come standard with a steel vacuum hose handle. Built tough to withstand the hard work these units must perform! The swivel boom hose assembly, means less fatigue for the operator and convenience in transport.

The discharge swivels a full 360 degrees, which means you can vacuum out your collection box if necessary. Discharge direction is easily adjusted so that debris can be directed where desired.

Salsco offers many different options, as listed below, for ease and convenience of operation, transport and performance.

Swing Away Bumper Mount – No need to remove the unit when dumping your collection box. Simply un-pin the latch and "swing away" your tailgate vacuum to dump debris. Landscape trailers or other towing units can be towed behind the Swing Away Bumper Mount.

Snow Plow Mounting – Optional mounting for either Minute Mount or Speed Cast provides the operator with other attachment options.

24" Exhaust Extension – We'll even make to order the size extension you need to reach the inlet hose on your collection box. Most customers need the 24" Standard Extension.

Square to Round Reducer Connection – Another option, just to make your application easier, by being able to add an exhaust hose to the exhaust.

45-Degree Swivel Reducer – Provides extra height and 45-degree angle to discharge at a higher level.

Hose Connectors, 10" or 8" can be provided if the customer wants to extend the length of the vacuum hose.

No matter which Model you've chosen to purchase, you can be assured you will have many years of reliable service. No other Leaf Vacuum on the market today is built stronger and designed with you the operator in mind.

MACHINE REGISTRATION

MANUFACTURED BY:	SALSCO, INC. 105 School House Rd., Cheshire, CT 06410 800-872-5726, 203-271-1682, 203-271-2596 (Fax) sales@salsco.com www.salsco.com
THIS MANUAL COVERS MODEL (s): T	AILGATE MOUNT LEAF VACUUM;
	nue, add improvements to, or change the design of any model improve existing machines, either by changing the design or
	y of SALSCO to update existing machines at its own s will be made in such a way that they can be "Retro Fit" if so
Record in the space provided below the mod numbers for future reference.	del and serial number of this unit. Please retain these
No parts orders will be accepted WITHOU numbers are listed in this manual.	T MODEL NUMBERS OR PART NUMBERS. All part
Serial Number	Model Number
NOTE: Be sure to complete your warranty claims.	card. This will insure immediate processing of any warranty
READ AND UNDERSTAND THIS	MANUAL BEFORE STARTING THE MACHINE
1/06	

 $O: \label{lem:condition} O: \label{lem:condition} And Bumper Mounted Leaf Vacuums \label{lem:condition} Truck Mounted Vacuums Swing Mount Manual_rev. 10$

5

-30-2017.doc

SAFETY INSTRUCTIONS

BEFORE YOU START THIS MACHINE:

- 1. **READ** and **UNDERSTAND** this owner's manual.
- 2. **DO NOT** run machine without guards and other safety covers in place.
- 3. **DO NOT** run machine with discharge hose removed. (A safety inlet cover can be purchased to cover inlet while hose is removed.)
- 4. **NEVER** leave machine running while unattended.
- 5. **NEVER** reach under or into machine for any reason while machine is running as it can cause serious injury.
- 6. **ALWAYS** remove spark plug wire, **MAKE SURE** engine is off, throttle is in stop position, and shut gas off when working on or checking inside machine.
- 7. **NEVER** clean inlet tube or outlet tubes while engine is running.
- 8. **EYE PROTECTION** should **ALWAYS BE WORN** when running machine.
- 9. **BE SURE** air intake on engine is clear of leaves and debris.
- 10. **DO NOT** refuel while engine is hot.
- 11. Clear area of all debris around unit before refueling.
- 12. **DO NOT** remove caution decals.
- 13. Safety decals should be replaced immediately after repainting or when they become illegible. Safety is a prime concern at Salsco and the safety decals on your machine are a highly visible and constant reminder to all operators. Replacement safety decals may be obtained from your local dealer or by calling Salsco at (203) 271-1682 or 1-800-872-5726.

OPERATING INSTRUCTIONS

- 1. READ MANUAL THOROUGHLY!
- 2. <u>BE SURE</u> intake hose is connected to blower housing. <u>NEVER RUN</u> UNIT WITH INTAKE HOSE DISCONNECTED.
- 3. Adjust clamping mechanism to fit your tailgate.
- 4. Before starting motor, **make sure everyone is clear of machine** and **discharge chute is pointing in the correct position**. Start the motor, and let it idle until engine warms up (see engine manual provided)
- 5. Bring up to full R.P.M. slowly, **checking for vibration**.
- 6. Pass inlet tube over material to be picked up.

SAFETY DECALS



- Do not direct outlet toward people, animals or buildings.



Warning

Moving Parts Hazard

To prevent serious injury or death from moving parts:

Close and secure guards and shield before starting engine. Keep hands, feet, hair, and clothing away from moving

parts. Stop engine to adjust or service.

Do not stand or climb on machine while operating.

Danger

To prevent serious injury or death, operate only with vacuum tube securely installed.


ADJUSTING CLAMP TO FIT TAILGATE

- Remove two bolts on each arm. 1.
- 2. Adjust for approximate length on both sides to fit tailgate.
- 3. Reinsert two bolts on each arm.
- 4. Press each clamp lever into lowest position.
- 5. Lock each lever by tightening the knob.
- Lower the safety lock on each side. 6.
- 7. Tighten knob to secure lock in place.

SERVICE & MAINTENANCE SCHEDULE					
Check Engine Oil (See Engine Manual)	Daily				
Check for Vibration	Daily				
Check for Torn or Damaged Hose	Daily				
Visually Check for Loose Bolts or Damage	Daily				
Clean Machine	Daily				
Check Battery for Water & Electrical Connections	Weekly				


-30-2017.doc

TAILGATE MOUNT LEAF VACUUMS




MAIN FRAME ASSEMBLY						
Item#	Description	Part #	Qty			
1	Frame, Main (708)	M501	1			
	Frame, Main (713)	0219066	1			
	Frame, Main (716)	0219132	1			
2	Hsg., Blower (708)	W500	1			
	Hsg., Blower (713,716)	0228153	1			
3	Impeller (708)	L205	1			
	Impeller (713)	0205036	1			
	Impeller (716)	0205058	1			
4	Tube, Straight Exhaust	T223	1			
5	Tube, 90° Exhaust	S223	1			
6	Plate, Tube Mounting	D239	1			
7	Cover, Exhaust Tube	Y223	1			
8	Spacer, Tube	N135	3			
9	Knob, Fluted	0332004	3			
27	Engine, 8HP Honda	0337021	1			
	Engine, 13HP Honda	0337023	1			
	Engine 16HP B & S	0337102	1			
43	Key, Square	0431131	1			


CLAMP ASSEMBLY						
Item #	Item # Description Pa					
9	Knob, Fluted	0332004	4			
14	Yoke, Tailgate Clamp	0274016	1			
15	Bracket, Right Tailgate	N231	1			
16	Bracket, Left	0231	1			
17	Pad, Clamp	I224	2			
18	Link, Clamp	Q231	2			
19	Link, Safety Lock	R231	2			
20	Grip, Lever-Black	N104	2			
21	Lever, Clamp-Right	0433073	1			
22	Lever, Clamp-Left	0433074	1			
23	Tailgate Clamp Assy.	0210046	2			
40	Clamp Pad (Rubber)	0410082	2			
41	Rubber Strip	P104	1			





VACUUM HOSE ASSEMBLY TAILGATE MOUNT LEAF VACUUMS




VACUUM HOSE ASSEMBLY						
Item #	Description	Part #	Qty.			
3	Grip	0332009	1			
10	Tube, Inlet Hose Connecting (708)	F223	1			
	Tube, Inlet Hose Connecting (713, 716)	0467043	1			
11	Collar, Hose & Handle (708)	E103	1			
	Collar, Hose & Handle (713, 716)	0211025	1			
12	Hose, Flex Intake 8" (708)	0327052	1			
	Hose, Flex Intake 10" (713, 716)	0327054	1			
13	Clamp, Hose (713, 716)	0310071	2			
	Clamp Hose (708)	B224	2			
24	Bar, Upper Hanger	W215	1			
25	Bungie, Hanger Cord	L219	1			
26	Hook, Bungie	M219	2			
27	Bar, Lower Hanger	X215	1			







SWING AWAY BUMPER MOUNT




	SWING AWAY BUMPER MOUNT OPTION						
Item #	Description	Part #	Qty.				
1	Hitch Swing Mount, Lower	0225059	1				
13	Bushing, Bronze	0307022	1				
16	Hitch, Swing Mount, Upper	0225060	1				
27	Rod, Swing Lock	0145096	1				
34	Spring, Compression.	0350031	1				
38	Bar, Swing Hitch Mount	0470099	1				
39	Spacer, Pivot Pin	0449101	1				
40	Bolt, Hex HD. 3/8-16 x 2-3/4	0346210	1				
41	Nut, Hex Lock (3/8-16-Nylon)	0338102	1				

Below is a quick reference chart for various "Flat Head Cap Screws" and the torque recommendations.

VALUES ARE STATED IN FOOT POUNDS

BOLT SIZE	Thds Per Inch	SAE Grade 5	SAE Grade 8
1/4	20	10	14
	28		
5/16	18	19	29
	24		
3/8	16	33	47
	24		
7/16	14	54	78
	20		
1/2	13	78	119
	20		
9/16	12	114	169
	18		
5/8	11	154	230
	11		
3/4	10	257	380
	10		
7/8	9	382	600
	9		
1	8	587	700
	8		

Drive Belt Tension Measurement by Deflection



WARRANTY POLICY

Please remember to complete and return your Warranty Card and Dealer Delivery Report. Warranty Claims will not be considered if the Warranty Card and Dealer Delivery Report have not been returned to Salsco.

Your Salsco Commercial or Turf Equipment product is a commercial type product and is normally manufactured and sold for commercial or industrial use. Salsco will, for the original purchaser, for one (1) year from the date of purchase (90 days if used for rental purposes) repair or replace, free of charge, any SALSCO part or parts found to be defective in material, workmanship or both. Any transportation or shipping charges will be borne by the purchaser. If, during the warranty period stated above, the product does not function properly due to defect, simply contact Salsco and follow the Warranty Procedures included in this manual.

This warranty does not include:

- Incidental or consequential damages and is exclusive of any implied warranties.
- Normal maintenance parts, including, but not limited to hoses, chains, belts, filters, lubricants, etc.
- Parts or components, which are covered under the original manufacturer warranty, including, but not limited to engines, pumps, and
 motors.

WARRANTY PROCEDURE

In order for Salsco to consider your warranty claims in a timely manner you must follow the simple procedures listed below:

MACHINE OR PART FAILURE

- a) Call our service department for helpful instruction on how to correct or repair the problem. Preventive maintenance will also be suggested.
- b) When ordering parts for Warranty issues, you MUST retain possession of the old parts in question until notified with respect to returning the parts to Salsco or other disposition.
- c) Warranty Claims MUST be filed within 30-days from completion of the work performed. Contact our office for an electronic warranty claim form.
- d) Fill in all information requested on warranty claim form, a copy of which is included in this manual, (date of purchase, company name, address, etc.). List all parts used. Make sure part numbers are correct. You can obtain these from your manual. (include good description of problem; i.e. "leaking from spool" rather than "leaking").
- e) It is our goal to consider and reach a disposition on each Warranty Claim within 30-days from the date that it is received. Therefore it is important that you respond promptly to any request for further information. Claims with no response to inquiries will be closed as "denied for lack of response" 90-days from the date of request.
- f) Email, Fax or Send Warranty Claim form to our Warranty Department. **Warranty on parts most often requires return of the parts that were replaced.** DO NOT DISCARD OLD PARTS UNTIL YOU HAVE RECEIVED A DETERMINATION AS TO WHETHER THESE PARTS MUST BE RETURNED.
- g) Our Warranty Department will contact and instruct you on how to return the Parts to Salsco on an RA #. Returns MUST be made within 30-Days from issuance of RA #. FREIGHT CHARGES ON RETURN OF PARTS IS THE RESPONSIBILITY OF THE CUSTOMER. Normal pre-delivery adjustments are not covered under warranty. Labor Warranties are based on reasonable time allowances as determined by Salsco, Inc. and paid at 75% of posted labor rate. TRAVEL TIME IS NOT REIMBURSED UNDER THE WARRANTY POLICY.
- h) Be sure to put the RA form inside the box that you are shipping back, also be sure to put on the outside of the box "Return of Goods" and the RA #.
- Ship returns via a traceable method such as UPS Ground Service. Be sure that the shipment is insured for the appropriate value. If uninsured
 parts are lost, we cannot issue a credit.

PLEASE NOTE: Warranty forms should be filled out completely.

PREVENTIVE MAINTENANCE IS YOUR BEST INSURANCE AGAINST EQUIPMENT FAILURE. BE SURE TO READ THIS MANUAL, ESPECIALLY THE MAINTENANCE, OPERATING AND CAUTION SECTIONS.

SALSCO, INC., 105 School House Rd. Cheshire, CT 06410 800-872-5726, 203-271-1682 203-271-2596 (Fax) sales@salsco.com, www.salsco.com

WARRANTY CLAIM FORM

SALSCO, INC. 105 School House Rd. Cheshire, CT 06410 Phone:(203) 271-1682,(800) 872-5726

Fax: (203) 271-2596 Email: s.clark@salsco.com Website: www.salsco.com

END OWNER			Date Subii	iilleu.						
Name:				Phone:			Work Order	#:		
Email:				Fax:			Office Use (Only		
Address:							Date Rec'd			
							Cust ID:			
							Salsco WC			
							Salsco RA			
PURCHASED FROM	l						Date Appro	ved:		
Name:				Phone:			Date Reject	ed:		
Email:				Fax:			Processed	Ву:		
Address:							Dir. Del Rep	ort on File:	YES NO	
							Warranty Ca	ard on File:	YES NO	
							Part(s) Tota	ıl:	All the second s	
Equipment/Warranty	/ Informatio	n (Must be	complete)				Labor Total	:		
Purchase Date:		Invoice #			Date Failed	d:	Total Appro	ved:		
Model #:	Serial #:				Repair Dat	e:	Approved/R	Rejected:		
IVIOGO, II.							Name:			
Hrs Used:		Primary Us	e:				Reason for	Rejection:		
1110 0000.										
Warranty Claim/Worl	Order#:									
Transfer of the second		nin -								
Was a Salsco Return	Authorizatio	n # issued f	or repairs o	r						
Return of Parts?	YES	NO		Name and the second second			Suggested Preventative Maint:			
Probable Cause of Fa										
Work Performed/Cor	nments on R	epair:								
Shop Labor Rate:						Submitted By:				
Total Labor Hours to	Repair:					Printed Name:				
Parts Required for re								,	,	
Salsco Part #: Descri						Qty.	Price Each	Total	Inv #	
		-								
								\$		
								\$		
								\$		
								\$		
					mr St. St. St.					

Fill in all information requested on warranty claim form.

INCOMPLETE FORMS CANNOT BE PROCESSED & WILL BE RETURNED

List all parts used. Make sure part numbers are correct. Any parts that you believe to be defective or any parts that break should be retained for possible inspection until after the warranty has been paid or part has been replaced.

800-872-5726, 203-271-1682 203-271-2596 (Fax)	SALSCO, INC. 105 School House Road Cheshire, CT 06410 EALER DELIVERY RE	PORT	www.salsco.com sales@salsco.com
MODEL: SERIAL NO:			
DEALER: CITY:	STATE:	ZIP:	
PURCHASER: ADDRESS:	CITY:	ST:	ZIP:
The undersigned dealer warrants that the above-descr was carefully inspected, adjusted and prepared for delivery to the purchaser; that both the operation and of the machine were explained to the purchaser; and the Owner's instruction Manual were given to the purchater; and the Owner's instruction Manual ware given to the purchater and the Owner's instruction and any operating included in the manual and caution notes.	very before described machine har the Owner's Instruction hat a copy of haser and his and make Salsco manu	ve been explained to n Manual and Our W lotes. I also understa	ne operation and maintenance of the abov him; acknowledges receipt of a copy of Aurranty Policy printed in said instruction and that it is my responsibility to explain operators.
DATE:	DATE: SIGN BY:	PURCH	ASER:
JIGN D1.	SIGN BT:		

SALES MANAGER'S NAME_

SALESMAN ID #_____

MODEL:	SERIAL NO:					
	SALSCO LIMITED	WARRA	NTY CARE)		
DATE PURCHASED:				-		
PURCHASER:	ADDRESS:	CITY:	ST:	ZIP:		
EMAIL:		PHONE:				
DEALER:		STATE: CT				
Will this equipment	be used commercially?		Yes		No	
Did Dealer service t	his equipment and instruct you in its ca	are and safe op	eration? Yes		No	
Did you receive an '	'Operation & Service Manual" and safe	ty pamphlet?	Yes	AMERICAN SAL	No	
	Signed					
			Puro	haser		
NOTICE:	IMPORTANT: THIS CARD MUST FACTORY WITHIN 10 DAYS OF P BE VOIDED.					

SERVICE RECORD

If kept properly, this schedule will help track problems in the future.

	0,	D- : "	D	Hanna Haad	Total Hours to Date
Date	Qty.	Part #	Description of Work Done	Hours Used	to Date

			# 100 M 100 M		
	~				
					~
				L	

MODEL#	S/N	
		DATE PURCHASED: